NO FUEL OR INSUFFICIENT FUEL (Cont.)

FUEL FLOW—Cont.

TEMPERATURE LESS THAN 10°F. ABOVE THE POUR POINT OF FUEL—Refer to "Fuel Oil Specifications."

RESTRICTED FITTING MISSING FROM RETURN MANIFOLD—Install new restricted fitting.

FAULTY FUEL PUMP

RELIEF VALVE NOT SEATING—Make "Fuel Pressure Test" and clean and inspect valve and seat assembly.

WORN GEARS OR PUMP HOUSING—Replace gear and shaft assembly and fuel pump if housing is damaged.

FUEL PUMP NOT ROTATING—Check condition of fuel pump drive and blower drive and replace if necessary.

High Lubricating Oil Consumption

Trouble—Cause—Remedy

EXTERNAL LEAKS

OIL LINES AND CONNECTIONS LEAKING—Tighten or replace defective parts.

GASKET OR OIL SEAL LEAKS—Replace defective gaskets or oil seals.

HIGH CRANKCASE PRESSURE—Refer to "High Crankcase Pressure" chart.

EXCESSIVE OIL IN AIR BOX—Refer to "Detonation" in "Abnormal Engine Operation" chart.

INTERNAL LEAKS

BLOWER OIL SEAL LEAKING—Remove and overhaul blower.

OIL COOLER CORE LEAKING—Replace oil cooler core and use a good cooling system cleaner to remove oil from water passages.

ENGINE BLOCK END PLATE GASKETS LEAKING—Replace block to end plate gaskets.