ABNORMAL ENGINE COOLANT TEMPERATURES (Cont.)

ABOVE NORMAL OPERATING TEMPERATURES

POOR CIRCULATION—Check for the following:

1. Coolant Level too Low—Fill radiator to filler neck.
2. Hoses Collapsed or Disintegrated—Replace hoses.
3. Thermostat Damaged—Replace thermostat.
4. Water Pump Impeller Loose on Shaft—Replace impeller and pin to shaft.
5. Inadequate Water Supply on Suction Side of Pump—Caused by:
   a. Radiator Clogged—Clean radiator.
   b. Combustion Gases in Cooling Water—Replace all head gaskets and inspect cylinder head for cracks on injector tube leaking.
   c. Air in Cooling System—Caused by:
      (1) Air Leak on Suction Side of Water Pump—Replace defective parts.
      (2) Thermostat Housing Vent Not Open When Filling System—Open vent valve while filling system.

BELOW NORMAL

POOR CIRCULATION—Check for the following:

1. Thermostat Housing Vent Valve Open or Not Seating—Remove and clean up vent valve and seat in housing.
2. Thermostat Inoperative—Replace thermostat.
3. Thermostat Seat Damaged—Replace thermostat.