| AIR BOX PRESSURE-FULL LOAD (In Inches of Mercury) Min. with Max. Exhaust Back Pressure | | | | |
|---|---|---|---|---|
| Engine | Speed (rpm) | | | |
| | 1200 | 1800 | 2000 | 2100 |
| V-71 (2 Valve) | 2.9 | 6.7 | - | 9.2 |
| V-71 (4 Valve) "N" | 2.3 | 6.4 | - | 8.2 |
| 8V-71T(T1865-1.50 A/R Housing Turbocharger N65 Injector | - | 22.8 | 27.7 | 30.5 |
| N75 Injector | - | 24.5 | 30.5 | 33.0 |
| 8V-71T(T18A40-1.70 A/R Housing Turbocharger N65 Injector | - | 16.4 | 21.8 | 24.5 |
| N70 Injector | - | 19.9 | 25.3 | 28.0 |
| N75 Injector | - | 20.9 | 26.3 | 29.0 |
| 12V-71T(T1805 Turbocharger) N70 Injector | - | 22.0 | 26.5 | 29.0 |

The difference between the two readings, with and without the air cleaner and ducting, is the actual restriction caused by the air cleaner and ducting.

Check the normal air intake vacuum at various speeds (at no load) and compare the results with the specifications in Table 5.

### Air Box Pressure

Proper air box pressure is required to maintain sufficient air for combustion and scavenging of the burned gases. Low air box pressure is caused by a high air inlet restriction, damaged blower rotors, an air leak from the air box (such as leaking end plate gaskets), or a clogged blower air inlet screen. Lack of power or black or grey exhaust smoke are indications of low air