CHILTONLIBRARY




Removal & Installation

REMOVAL AND INSTALLATION

REMOVAL



- 1. Disconnect and isolate the negative battery cable. If equipped with an Intelligent Battery Sensor (IBS), disconnect the IBS connector first before disconnecting the negative battery cable.
- 2. Using a pry tool, gently remove the switch assembly (1) from the door trim panel.
- 3. Disconnect the wire harness connector (2).



4. Using trim stick


Trim Stick




or equivalent, release and remove the trim panel (1).




5. Using a trim stick or equivalent, remove the door handle closeout trim (1).




6. Remove the door handle bolts (1).



7. Using a trim stick or equivalent, release the 11 push pin fasteners (1).




8. Remove the trim panel (2) from the inner door panel (1).



9. Separate the interior handle (1) from the trim panel (2).


INSTALLATION




NOTE

Replace any damaged or missing push pin fasteners as necessary.


1. Install the interior handle assembly (1) onto the trim panel (2) and seat fully.



2. Position the trim panel (2) back into place onto the inner door panel (1).




3. Seat the 11 push pin fasteners (1) fully.



4. Install the door handle bolts (1) and tighten to the proper (Torque Specifications).



5. Install the door handle closeout trim (1) and seat fully.



6. Install the trim piece (1) onto the mounting fixtures (2) and seat fully.



- 7. Connect the wire harness connector (2) and install the switch (1).
- 8. Seat the switch assembly (1) into the trim panel fully
- 9. Connect the negative battery cable. If equipped with an Intelligent Battery Sensor (IBS), connect the IBS connector to the negative battery cable.