# **CHILTON**LIBRARY



## **Removal & Installation**

### **REMOVAL AND INSTALLATION**

### **REMOVAL**



- 1. Remove the screw located in the media hub bezel (3) opening.
- 2. Open the bin (2), and using a trim stick remove the media hub bezel.
- 3. If equipped, remove the DVD player (Refer to 08 Electrical/8A Audio and Video/PLAYER, DVD/Removal and Installation)(Refer To List 1).



4. Remove the six screws (2) and drop the bin (1) down to remove.

### **INSTALLATION**



- 1. Position the bin (1) and install the screws (2).
- 2. If equipped, install the DVD player (Refer to 08 Electrical/8A Audio and Video/PLAYER, DVD/Removal and Installation)(Refer To List 1).



- 3. Position the media hub bezel (3) and hand tap to engage the retaining clips.
- 4. Install the screw located in the media hub bezel opening, and tighten securely.

### **Refer To List:**

### List 1

- 08 Electrical / 8A Audio/Video/Entertainment/Connectivity / PLAYER, DVD / Removal and Installation
- 08 Electrical / 8A Audio/Video/Entertainment/Connectivity / PLAYER, Overhead DVD / Removal and Installation