
# **CHILTON**LIBRARY



## **Removal & Installation**

#### **REMOVAL AND INSTALLATION**

### **REMOVAL**




- 1. Remove the quarter glass (Refer to Body/Stationary Glass/GLASS, Quarter/Removal and Installation). (Refer To List 1)
- 2. Using trim stick

Trim Stick




or equivalent, release the nine upper push pin fasteners (1) and the four lower tabs (3) and remove the window molding (4).

- 3. Open sliding door to the mid point of its travel.
- 4. Support sliding door on a suitable lifting device.



- 5. Mark outline of the center hinge (2) on the inner door panel to aid installation.
- 6. Remove the bolts (1) attaching the center hinge to the sliding door.
- 7. Remove the center hinge from the door.
- 8. Roll the center hinge to rear of roller channel and remove from the vehicle.


#### **INSTALLATION**



### **NOTE**

A suitable body sealant should be used when removing or moving the hinges.

- 1. Place the center hinge (2) into position on the center track.
- 2. Roll the hinge (2) forward in roller track.
- 3. Place the hinge into position on the sliding door and align with the marks made during removal.
- 4. Install the bolts (1) attaching center hinge to sliding door and tighten to the proper (Torque Specifications).



- 5. Install the quarter glass (Refer to Body/Stationary Glass/GLASS, Quarter/Removal and Installation). (Refer To List 1)
- 6. Install the glass molding (4) and seat the nine upper push pin fasteners (1) and the lower tabs (3) fully.
- 7. Verify sliding door alignment and operation.

#### **Refer To List:**

#### List 1

- 23 Body / Stationary Glass / GLASS, Liftgate / Removal and Installation
- 23 Body / Stationary Glass / GLASS, Quarter / Removal and Installation
- 23 Body / Stationary Glass / GLASS, Sunroof / Removal and Installation