Radio Shack TRS-80 Expansion Interface: Operator's Manual

Contents

Chapt	ter 1. Introduction	3
Е	Electrical Connections	. 3
Р	Parts List	. 3

Chapter 1. Introduction

This document describes the TRS-80Expansion Interface, the parts that come with it, and what it can be used for.

The TRS-80 Expansion Interfaceconsists of the Case, a DC Power Supply, a Ribbon Cable, a Cassette Recorder Jumper Cable and an additional Cassette Recorder Cable for Cassette Recorder number 2. Notice that the DC Power Supply is not installed in the Case upon receipt. It must be installed using the procedures under the heading "SETTING UP".

Electrical Connections

Keep the following parts and peripheral handy:

- Expansion Interface
- Parts List (on page 3)

Perform the following instructions to setup the electrical connections for peripheral devices attaching to the TRS-80computer.

- 1. Turn the TRS-80 so that it faces away from you. Locate the port Door (1400083); it's at the right end of the rear panel.
- 2. To remove the Door, raise it up and slide it to the right—then lift it up and away from the TRS-80
- 3. Place the TRS-80 and Expansion Interface Hoods (1400217 and 1400214) on the Ribbon Cable Connectors as shown in Figure 4. The Hoods replace the Door on the TRS-80 and fill the opening on the Expansion Interface. These Hoods are designed so that it is not possible to insert the connectors upside down. They function as keyways for the connectors.
- 4. Now connect the Ribbon Cable between the left front Expansion Interface port and the TRS-80 port.
- Connect the DC Power Cord (DIN connector) to the POWER connector on the right rear of the TRS-80 and connect both AC Power Cords to standard 120 VAC outlets.

Parts List

A description of the individual parts and part numbers comprising the TRS-80 Expansion Interface

EXPANSION INTERFACE	#
Door, Mini-Disk	1400212
Door, Line Printer	1400212

EXPANSION INTERFACE

Door, Screen Printer 1400216

Door, Future Expansion Board 1400216

Hood, Mini-Disk 1400213

Radio Shack TRS-80Expansion Interface : Operator's Manual | 1 - Introduction | 4

Expansion Interface

Hood, Line Printer 1400213

Hood, Screen Printer 1400218

Hood, Future Expansion Board 1400218

Hood, TRS-80 Microcomputer System 1400214

MICROCOMPUTER SYSTEM

Door 1400083

Hood 1400217