## MonitoringBox Manual

Raspberry pi

Team MonitoringBox

2017

## Contents

1	Introduction			2
2	Requirements/parts 2.1 Hardware			
	2.2		are	3
3	Installation 4			
	3.1	Hardw	rare	4
	3.2	OS		5
		3.2.1	Download	5
		3.2.2	Flash the SD card	6
	3.3	Softwa	re	8
		3.3.1	Required packages	8
		3.3.2	Install MonitoringBox mangement software	9
		3.3.3	Setup auto login	9
		3.3.4	Setup better shell (optional)	10
		3.3.5	From now on run the commands as root	10
		3.3.6	Startup script	10
		3.3.7	Access point/WiFi setup	11
		3.3.8	Enable remote access (SSH) (optional)	14
		3.3.9	Reduce space consumption (optional)	14
4	4 Problems			23

### Introduction

The base of the monitoring box is the Raspberry Pi, as you can see figure 1.1




Figure 1.1: Example of setup of sensors connected to the Pi.

The Raspberry Pi contains the software that knows how to interpret the sensor data, allows for exporting of the data and converting it to the wanted format. The user can connect to the Raspberry Pi via WiFi.

# Requirements/parts

The hardware and software described in this chapter are required to complete the MonitoringBox.

#### 2.1 Hardware

The hardware required for the base of the MonitoringBox:

- Raspberry Pi 3 (https://www.raspberrypi.org/products/raspberry-pi-3-model-b/)
- Touchscreen (...) @todo
- Casing (optional) (see github .... ) @todo

#### 2.2 Software

The operating system used for the Raspberry Pi is Raspbian (lite) which can be download from https://www.raspberrypi.org/downloads/raspbian/

The management software that is required for the MonitoringBox to function is available on https://github.com/pjotrscholtze/MonitoringBox

## Installation

The installation of the base of the MonitoringBox can be divided into two parts: the hardware part and software part.

### 3.1 Hardware

@todo show how to insert the SD card and put it into the box, and how to connect the display (don forget the jumper on the screen)

### 3.2 OS

### 3.2.1 Download

Download Raspbian Lite from: https://www.raspberrypi.org/downloads/raspbian/




Figure 3.1: Download Raspbian Lite

And download Etcher from: https://etcher.io/ (works on Windows, Linux and OS X).



Figure 3.2: Download Etcher

### 3.2.2 Flash the SD card

Start Etcher.



Figure 3.3: Etcher start up state.

And press "Select image": Go to the location of the downloaded Rasp-




Figure 3.4: The Mikroe Gas Detector

bian file.



Figure 3.5: The Mikroe Gas Detector



Figure 3.6: The Mikroe Gas Detector




Figure 3.7: The Mikroe Gas Detector

#### 3.3 Software

@todo get the user here.

#### 3.3.1 Required packages

Install the required base software with the following command (single line).

sudo apt-get -y install network-manager xorg openbox xdm xfce4-terminal xfce4-panel vim dbus-x11 hostapd lxappearance numix-gtk-theme git python3-pip feh faenza-icon-theme gnome-system-monitor dnsmasq python3-pyqt4

#### 3.3.2 Install MonitoringBox mangement software

```
cd /opt
mkdir MonitoringBox
chmod -c 0777 ./MonitoringBox
git clone git@github.com:pjotrscholtze/MonitoringBox.git ./
    MonitoringBox
chmod +x /opt/MonitoringBox/Portal/main.py
pip3 install flask pyserial
mkdir /var/opt/monitoringbox
echo "{}" > /var/opt/monitoringbox/config.json
```

#### 3.3.3 Setup auto login

Edit the file

```
/lib/systemd/system/getty@.service
```

With for example nano (other editors are also okay):

```
sudo nano /lib/systemd/system/getty@.service
```

Change the following line:

```
ExecStart=-/sbin/agetty --noclear %I $TERM
```

To the following:

```
ExecStart=-/sbin/agetty ---noclear -a root %I $TERM
```

(You can save the file with ctrl+o and quite with ctrl+x)

 $Source: \ https://superuser.com/questions/969923/automatic-root-login-in-debian-8-0-console-only$ 

#### 3.3.4 Setup better shell (optional)

Can be useful when needing to work directly on the device (on the shell if you do not know what that means, than it is most likely not something you are going to use).

```
apt-get install zsh
chsh -s $(which zsh) pi
sudo chsh -s $(which zsh) root
```

#### 3.3.5 From now on run the commands as root

```
sudo –s
cd ~
```

#### 3.3.6 Startup script

This isn't used anymore? Create the file:

```
~/.xinitrc_feh
```

with for example nano (other text editors are also okay):

```
sudo nano ~/.xinitrc_feh
```

And write the following content.

```
#!/bin/sh
sleep 0.2
feh --bg-fill ~/background.jpg &
```

This isn't used anymore?

Now create the file

```
~/.xinitrc
```

with for example nano (other text editors are also okay):

```
sudo nano ~/.xinitrc
```

And write the following content in it:

```
python3 /opt/MonitoringBox/Portal/main.py & exec openbox-session
```

#### When **NOT** using **ZSH** do the following: Append to the

```
^/.bashrc
```

file, with for example nano (other text editors are also okay).

```
sudo nano ~/.bashrc
```

The following content:

```
if [ -z "$DISPLAY" ] && [ -n "$XDG_VTNR" ] &&
   [ "$XDG_VTNR" -eq 1 ]; then
   exec startx
fi
```

#### When using ZSH do the following: Append to the

```
^/.zshrc
```

file, with for example nano (other text editors are also okay).

```
sudo nano ~/.zshrc
```

The following content:

```
if [ -z "$DISPLAY" ] && [ -n "$XDG_VTNR" ] &&
    [ "$XDG_VTNR" -eq 1 ]; then
    exec startx
fi
```

#### 3.3.7 Access point/WiFi setup

https://frillip.com/using-your-raspberry-pi-3-as-a-wifi-access-point-with-hostapd/https://superuser.com/questions/985082/is-there-a-way-to-disable-the-dhcp-client-in-raspbian-linux-on-a-rasperry-pi

**Network interface** First setup the network interface (disable DHCP), by editing the following file:

```
/etc/network/interfaces
```

With for example nano (other text editors are also okay).

```
sudo nano /etc/network/interfaces
```

And make sure the following:

```
allow-hotplug wlan0
iface wlan0 inet dhcp @todo
```

Is changed to the following:

```
allow-hotplug wlan0
iface wlan0 inet static
address 172.24.1.1
netmask 255.255.255.0
network 172.24.1.0
broadcast 172.24.1.255
```

And finish with the following commands:

```
sudo systemctl disable dhcpcd.service
sudo systemctl stop dhcpcd.service

----sudo apt-get remove dhcpcd5 @todo check this part
```

**Access point** After the network interface was prepared the access point needs to be setup. First we need to create the following file:

```
/etc/hostapd/hostapd.conf
Create the directory first:
sudo mkdir /etc/hostapd
```

Then create the file with for example nano (any other text is also okay). sudo nano /etc/hostapd/hostapd.conf

And write the following content inside:

```
# This is the name of the WiFi interface we configured above
interface=wlan0
# Use the nl80211 driver with the brcmfmac driver
driver=nl80211
# This is the name of the network
ssid=Pi3-AP
# Use the 2.4GHz band
hw_mode=g
# Use channel 6
channel=6
# Enable 802.11n
ieee80211n=1
# Enable WMM
wmm_enabled=1
# Enable 40MHz channels with 20ns guard interval
ht_capab = [HT40] [SHORT-GI-20] [DSSS_CCK-40]
# Accept all MAC addresses
macaddr_acl=0
# Use WPA authentication
auth_algs=1
# Require clients to know the network name
ignore_broadcast_ssid=0
# Use WPA2
wpa=2
# Use a pre-shared key
wpa_key_mgmt=WPA-PSK
# The network passphrase
wpa_passphrase=raspberry
# Use AES, instead of TKIP
rsn_pairwise=CCMP
```

Now configure the deamon to use the config file. This is done by changing the following file:

```
/etc/default/hostapd
```

With for example nano (any other text editor is also okay).

```
sudo nano /etc/default/hostapd
```

Change the following line from:

```
#DAEMON_CONF=""

DAEMON_CONF="/etc/hostapd/hostapd.conf"
```

Afterwards we need to setup the DNS server so that any address will be forwarded to the PI. This is done by editing the:

```
/etc/dnsmasq.conf
```

file with for example nano (any other text editor is also okay).

```
sudo nano /etc/dnsmasq.conf
```

And make sure it contains the following content:

```
# Use interface wlan0
interface=wlan0
listen-address=172.24.1.1 # Explicitly specify the address to
    listen on
                     # Bind to the interface to make sure we
bind-interfaces
   aren't sending things elsewhere
server = 8.8.8.8
                     # Forward DNS requests to Google DNS
domain-needed
                     # Don't forward short names
bogus-priv
                     # Never forward addresses in the non-
   routed address spaces.
dhcp-range=172.24.1.50,172.24.1.150,12h # Assign IP addresses
    between 172.24.1.50 and 172.24.1.150 with a 12 hour
   lease time
address = /\#/172.24.1.1
```

Finally we need to enable the deamons so you can connect to it.

```
systemetl enable hostapd
systemetl enable dnsmasq
```

#### 3.3.8 Enable remote access (SSH) (optional)

The following command will allow you change settings easily on the Pi:

```
sudo raspi-config
```

Go to "interfaces" -; SSH and enable the option.

#### 3.3.9 Reduce space consumption (optional)

Remove unused packages:

```
apt-get -y remove bluetooth blackbird-gtk-theme
bluebird-gtk-theme scrot samba-common
unattended-upgrades xserver-xorg-video-amdgpu
xserver-xorg-video-ati xserver-xorg-video-nouveau
xserver-xorg-video-radeon xserver-xorg-video-vesa

apt-get -y purge bluetooth blackbird-gtk-theme
bluebird-gtk-theme scrot samba-common
unattended-upgrades xserver-xorg-video-amdgpu
xserver-xorg-video-ati xserver-xorg-video-nouveau
xserver-xorg-video-radeon xserver-xorg-video-vesa

apt-get -y autoremove
apt-get -y autoclean
```

Warning this will remove the unused icons, however this is officially still part of the containing packages so this is not recommended.

```
rm -rf /usr/share/icons/elementaryXubuntu-dark
rm -rf /usr/share/icons/Faenza-*
```

Warning disabling the swap file can lead to unstable performance, however if you use this Raspberry Pi you can safely disable it.

```
sudo dphys-swapfile swapoff
sudo dphys-swapfile uninstall
sudo update-rc.d dphys-swapfile remove
```



Figure 3.8: The Mikroe Gas Detector



Figure 3.9: The Mikroe Gas Detector




Figure 3.10: The Mikroe Gas Detector

```
UN | Started LSB: Suitch to ondenand cpu governor (unless shift key is pressed).

UN | Started LSB: Suitch to ondenand cpu governor (unless shift key is pressed).

UN | Started LSB: Busines the root filesystem to fill partition.

Starting Load-Sauce BR Kill Switch Status.

UN | Started Configure Bluetooth Hodens connected by UART.

Starting Bluetooth service...

UN | Started Bluetooth service...

UN | Started Bluetooth service...

UN | Started Hostones Service...

Starting Permit User Sessions...

Starting Permit User Sessions...

UN | Started Permit User Sessions...

Starting Terminate Plymouth Boot Screen...

Starting Hold until boot process finishes up...

Raspbian GHU/Linux 9 raspberrypi tty1 raspberrypi login: ______
```

Figure 3.11: The Mikroe Gas Detector

Figure 3.12: The Mikroe Gas Detector

```
I ON 1 Started darped on all interfaces.

Starting /etc/rc.local Compatibility...

I ON 1 Started Permit User Sessions...

Starting /etc/rc.local Compatibility...

I Started Permit User Sessions...

Starting Terminate Plymouth Boot Screen...

Starting Hold until boot process finishes up...

Raspbian GNU/Linux 9 raspberrypi tty1
raspberrypi login: pi
Password:

Linux raspberrypi 4.9.59-u7+ #1047 SMP Sun Oct 29 12:19:23 GMT 2017 armu

The programs included with the Debian GNU/Linux system are free software the exact distribution terms for each program are described in the individual files in /usr/share/doc/*/copyright.

Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent permitted by applicable law.

pi@raspberrypi: $ sudo raspi-config_
```

Figure 3.13: The Mikroe Gas Detector



Figure 3.14: The Mikroe Gas Detector



Figure 3.15: The Mikroe Gas Detector



Figure 3.16: The Mikroe Gas Detector



Figure 3.17: The Mikroe Gas Detector




Figure 3.18: The Mikroe Gas Detector

Figure 3.19: The Mikroe Gas Detector



Figure 3.20: The Mikroe Gas Detector

The authenticity of host '192.168.0.81 (192.168.0.81)' can't be established. ECDSA key fingerprint is SHA256:7YzGZWZEYGfNi8MF/9tFjwcqFt0X5jvmI57jUnTohGs. Are you sure you want to continue connecting (yes/no)? yes

Figure 3.21: The Mikroe Gas Detector

The authenticity of host '192.168.0.81 (192.168.0.81)' can't be established. ECDSA key fingerprint is SHA256:7YzGZWZEYGfNi8MF/9tFjwcqFt0X5jvmI57jUnTohGs. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added '192.168.0.81' (ECDSA) to the list of known hosts. pi@192.168.0.81's password:

Figure 3.22: The Mikroe Gas Detector

```
The authenticity of host '192.168.0.81 (192.168.0.81)' can't be established. ECDSA key fingerprint is SHA256:7Y26ZWZEYGfNi8MF/9tFjwcqFt0X5jwm157jUnTohGs. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added '192.168.0.81' (ECDSA) to the list of known hosts. pi@192.168.0.81's password:
Linux raspberrypi 4.9.59-v7+ #1047 SMP Sun Oct 29 12:19:23 GMT 2017 armv7l

The programs included with the Debian GNU/Linux system are free software; the exact distribution terms for each program are described in the individual files in /usr/share/doc/*/copyright.

Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent permitted by applicable law.
Last login: Wed Nov 29 02:38:10 2017

SSH is enabled and the default password for the 'pi' user has not been changed. This is a security risk - please login as the 'pi' user and type 'passwd' to set a new password. pi@raspberrypi:~ $
```

Figure 3.23: The Mikroe Gas Detector

### **Problems**

What to do when you cann't connect to the internet while you've pluggedin the ethernet cable. Run the following command:

sudo service dnsmasq stop

This will disable DNS and DHCP, thus you cannot connect propperly to the pi via wifi any more but after reboot (or with: sudo service dnsmasq start) you can access it again