

当前文件在印刷时是有效的。更新的版本可以在线获得。

WM 270555 更换蓄电池传感器

更换蓄电池传感器

更换蓄电池传感器

1. 拆下旧蓄电池传感器。 → 270519 拆卸和安装蓄电池传感器 - “拆卸”部分
2. 安装新的蓄电池传感器。 → 270519 拆卸和安装蓄电池传感器 - “安装”部分
3. 新的蓄电池传感器由网关控制单元自动检测并记录。

982120, 982121, 982130, 982131, 982140, 982141, 982150, 982151, 982320, 982321, 982330, 982331, 982340, 982341, 982350, 982351, 982510, 982511, 982810, 982811

年款 起始时间 2017

C00, C02, C05, C06, C07, C08, C09, C10, C11, C12, C13, C14, C15, C16, C17, C18, C19, C20, C21, C22, C23, C24, C25, C26, C27, C28, C32, C33, C34, C35, C36, C37, C38, C39, C41, C45, C45, C46, C96, C97, C98, C99

baochi123D

baochimingcheservice@gmail.com

Aug 23, 2019

