

当前文件在印刷时是有效的。更新的版本可以在线获得。

WM 943619 拆卸和安装制动灯开关

拆卸和安装制动灯开关

拆卸和安装制动灯开关



信息

制动灯开关集成在制动总泵内，无法单独拆卸。如果制动灯开关发生故障，则必须更换制动总泵。

1. 更换制动总泵。 → 471519 *拆卸和安装制动总泵*

982120, 982121, 982130, 982131, 982140, 982141, 982150, 982151, 982320, 982321, 982330, 982331, 982340, 982341, 982350, 982351, 982510, 982511, 982810, 982811

年款 起始时间 2017

C00, C02, C05, C06, C07, C08, C09, C10, C11, C12, C13, C14, C15, C16, C17, C18, C19, C20, C21, C22, C23, C24, C25, C26, C27, C28, C32, C33, C34, C35, C36, C37, C38, C39, C41, C45, C45, C46, C96, C97, C98, C99

baochi123D

baochimingcheservice@gmail.com

Aug 24, 2019

