

991/ 982, MY 2017-

Diagnosis information - DME (DFI)

P000A.....	1
P000B.....	2
P000C.....	3
P000D.....	4
P0010.....	5
P0011.....	6
P0013.....	7
P0014.....	8
P0016.....	9
P0017.....	10
P0018.....	11
P0019.....	12
P0020.....	13
P0021.....	14
P0023.....	15
P0024.....	16
P0030.....	17
P0031.....	18
P0032.....	19
P0033.....	20
P0034.....	21
P0035.....	22
P0036.....	23
P0037.....	24
P0038.....	25
P0050.....	26
P0051.....	27
P0052.....	28
P0056.....	29
P0057.....	30
P0058.....	31
P0068.....	32
P0071.....	33
P0072.....	34
P0073.....	35
P0074.....	36
P0076.....	37
P0077.....	38
P0079.....	39

P0080.....	40
P0082.....	41
P0083.....	42
P0085.....	43
P0086.....	44
P0087.....	45
P0088.....	47
P0089.....	49
P008A.....	50
P008B.....	51
P0090.....	52
P0091.....	53
P0092.....	54
P00B7.....	55
P0105.....	56
P0106.....	57
P0107.....	58
P0108.....	59
P0110.....	60
P0111.....	61
P0114.....	62
P0116.....	63
P0117.....	65
P0118.....	66
P0119.....	67
P0121.....	68
P0122.....	69
P0123.....	70
P0131.....	71
P0132.....	72
P0133.....	73
P0135.....	74
P0136.....	75
P0137.....	76
P0138.....	77
P013A.....	78
P013B.....	79
P013C.....	80
P013D.....	81

P013E.....	82
P013F.....	83
P0141.....	84
P014A.....	85
P014B.....	86
P0151.....	87
P0152.....	88
P0153.....	89
P0155.....	90
P0156.....	91
P0157.....	92
P0158.....	93
P0161.....	94
P016E.....	95
P016F.....	96
P0171.....	97
P0172.....	98
P0174.....	99
P0175.....	100
P0190.....	101
P0191.....	102
P0192.....	104
P0195.....	105
P0197.....	106
P0198.....	107
P0199.....	108
P0201.....	109
P0202.....	110
P0203.....	111
P0204.....	112
P0205.....	113
P0206.....	114
P0222.....	115
P0223.....	116
P0234.....	117
P0235.....	118
P0236.....	119
P0237.....	120
P0238.....	121

P0243.....	122
P0245.....	123
P0246.....	124
P0247.....	125
P0249.....	126
P0250.....	127
P025A.....	128
P025A.....	129
P025C.....	130
P025C.....	131
P025D.....	132
P025D.....	133
P0261.....	134
P0262.....	135
P0264.....	136
P0265.....	137
P0267.....	138
P0268.....	139
P0270.....	140
P0271.....	141
P0273.....	142
P0274.....	143
P0276.....	144
P0277.....	145
P0298.....	146
P0299.....	147
P02CC.....	148
P02CD.....	149
P02CE.....	150
P02CF.....	151
P02D0.....	152
P02D1.....	153
P02D2.....	154
P02D3.....	155
P02D4.....	156
P02D5.....	157
P02D6.....	158
P02D7.....	159
P02EE.....	160

P02EF.....	161
P02F0.....	162
P02F1.....	163
P02F2.....	164
P02F3.....	165
P0300.....	166
P0301.....	169
P0302.....	172
P0303.....	175
P0304.....	178
P0305.....	181
P0306.....	184
P0313.....	187
P0326.....	190
P0327.....	191
P0331.....	192
P0332.....	193
P0335.....	194
P0336.....	195
P0341.....	196
P0342.....	197
P0343.....	198
P0344.....	199
P0346.....	200
P0347.....	201
P0348.....	202
P0349.....	203
P034A.....	204
P0351.....	205
P0352.....	206
P0353.....	207
P0354.....	208
P0355.....	209
P0356.....	210
P0366.....	211
P0367.....	212
P0368.....	213
P0369.....	214
P0370.....	215

P0371.....	216
P0373.....	217
P0391.....	218
P0392.....	219
P0393.....	220
P0394.....	221
P0411.....	222
P0418.....	223
P0420.....	224
P0430.....	225
P043E.....	226
P043F.....	227
P0441.....	228
P0442.....	229
P0444.....	230
P0447.....	231
P0448.....	232
P0456.....	233
P0458.....	234
P0459.....	235
P0464.....	236
P0480.....	237
P0481.....	238
P0491.....	239
P0492.....	240
P04DB.....	241
P04F0.....	242
P0503.....	244
P0506.....	245
P0507.....	246
P050A.....	247
P050B.....	248
P050C.....	249
P050D.....	251
P0513.....	252
P0521.....	253
P0522.....	254
P0523.....	255
P0524.....	256

P052A.....	257
P052C.....	258
P053F.....	259
P054A.....	261
P054C.....	262
P0556.....	263
P0557.....	264
P0558.....	265
P0564.....	266
P0568.....	267
P0571.....	268
P0597.....	269
P0598.....	270
P0599.....	271
P059F.....	272
P05A0.....	273
P05A1.....	274
P05A3.....	275
P05AE.....	276
P05AF.....	277
P05B0.....	278
P05B2.....	279
P05C0.....	280
P05C1.....	281
P0601.....	282
P0603.....	283
P0604.....	284
P0605.....	285
P0606.....	286
P0607.....	287
P0610.....	288
P0611.....	289
P061B.....	290
P061C.....	291
P0627.....	292
P0628.....	293
P0629.....	294
P0638.....	295
P0642.....	296

P0643.....	297
P0652.....	298
P0653.....	299
P0658.....	300
P0659.....	301
P0685.....	302
P0686.....	304
P0687.....	305
P0698.....	306
P0699.....	307
P0700.....	308
P0701.....	309
P0705.....	310
P0716.....	311
P0717.....	312
P0718.....	313
P0832.....	314
P0834.....	315
P0835.....	316
P083F.....	317
P0850.....	318
P0851.....	319
P0857.....	320
P1023.....	321
P1024.....	323
P1025.....	324
P1027.....	325
P1031.....	326
P1038.....	327
P1039.....	328
P1044.....	329
P1045.....	330
P1046.....	331
P1047.....	332
P1048.....	333
P1049.....	334
P1058.....	335
P1084.....	336
P1085.....	337

P1086.....	338
P1087.....	339
P1088.....	340
P1089.....	341
P1147.....	342
P1148.....	343
P1149.....	344
P1150.....	345
P1151.....	346
P1152.....	347
P1157.....	348
P1158.....	349
P1165.....	350
P1166.....	351
P1167.....	352
P1168.....	353
P1169.....	354
P1170.....	355
P117A.....	356
P117B.....	357
P1186.....	358
P1191.....	359
P1192.....	360
P1193.....	361
P1194.....	362
P1195.....	363
P1196.....	364
P119A.....	365
P119E.....	366
P11A1.....	367
P11A5.....	368
P11A8.....	369
P11A9.....	370
P11AA.....	371
P11AB.....	372
P11AC.....	373
P11AF.....	374
P11B0.....	375
P11B1.....	376

P11B2.....	377
P11B3.....	378
P11B6.....	379
P11B7.....	380
P11B8.....	381
P11B9.....	382
P11BA.....	383
P1251.....	384
P1252.....	385
P1253.....	386
P1254.....	387
P1255.....	388
P1256.....	389
P1257.....	390
P1258.....	391
P1261.....	392
P1262.....	393
P1265.....	394
P1280.....	395
P1280.....	396
P1281.....	397
P1281.....	398
P1282.....	399
P1283.....	400
P1283.....	401
P1284.....	402
P1285.....	403
P1286.....	404
P1300.....	405
P1301.....	406
P1302.....	407
P1303.....	408
P1346.....	409
P1347.....	410
P1359.....	411
P1360.....	412
P1361.....	413
P1362.....	414
P1363.....	415

P1364.....	416
P1372.....	417
P1373.....	418
P13A3.....	419
P13EA.....	422
P1432.....	423
P1433.....	425
P1440.....	427
P1441.....	428
P1442.....	429
P1443.....	430
P1444.....	431
P1445.....	432
P1446.....	433
P1447.....	434
P1448.....	435
P1449.....	436
P1458.....	437
P1459.....	438
P1460.....	439
P1461.....	440
P1462.....	441
P1463.....	442
P1464.....	443
P1465.....	444
P1466.....	445
P1467.....	446
P1468.....	447
P1469.....	448
P1477.....	449
P1478.....	450
P1509.....	451
P1533.....	452
P1536.....	453
P1537.....	454
P1538.....	455
P1539.....	456
P1546.....	457
P1547.....	458

P1548.....	459
P1549.....	460
P1553.....	461
P1559.....	462
P1563.....	463
P1565.....	464
P1575.....	465
P1577.....	466
P1590.....	467
P1591.....	468
P1592.....	469
P1593.....	470
P1594.....	471
P1599.....	472
P15A0.....	473
P15A1.....	474
P15A2.....	475
P1600.....	476
P1603.....	477
P1615.....	478
P161A.....	479
P1620.....	480
P1626.....	481
P1647.....	482
P1649.....	483
P1650.....	484
P1651.....	485
P1652.....	486
P1653.....	487
P1654.....	488
P1655.....	489
P1656.....	490
P1660.....	491
P1661.....	492
P1662.....	493
P1670.....	494
P1671.....	496
P1672.....	497
P1673.....	499

P1675.....	500
P1676.....	501
P1677.....	502
P167D.....	503
P167E.....	504
P167F.....	505
P1687.....	506
P1688.....	507
P168D.....	508
P168E.....	509
P168F.....	510
P169B.....	511
P169C.....	512
P169D.....	513
P169E.....	514
P169F.....	515
P16A0.....	516
P18A9.....	517
P1940.....	518
P1941.....	519
P1942.....	520
P194A.....	521
P194B.....	522
P194C.....	523
P194D.....	524
P1987.....	525
P199C.....	526
P199D.....	527
P199E.....	528
P2072.....	529
P2073.....	530
P2074.....	531
P2080.....	532
P2082.....	533
P2088.....	534
P2089.....	535
P2090.....	536
P2091.....	537
P2092.....	538

P2093.....	539
P2094.....	540
P2095.....	541
P2096.....	542
P2097.....	543
P2098.....	544
P2099.....	545
P2100.....	546
P2103.....	547
P2108.....	548
P2119.....	549
P2121.....	550
P2122.....	551
P2123.....	552
P2126.....	553
P2127.....	554
P2128.....	555
P2138.....	556
P2176.....	557
P2177.....	558
P2178.....	559
P2179.....	560
P2180.....	561
P2181.....	562
P2184.....	563
P2185.....	564
P2186.....	565
P2187.....	566
P2188.....	567
P2189.....	568
P2190.....	569
P2195.....	570
P2196.....	571
P2197.....	572
P2198.....	573
P2227.....	574
P2228.....	575
P2229.....	576
P2230.....	577

P2237.....	578
P2240.....	579
P2243.....	580
P2247.....	581
P2251.....	582
P2254.....	583
P2257.....	584
P2258.....	585
P2262.....	586
P2270.....	588
P2271.....	589
P2272.....	590
P2273.....	591
P228F.....	592
P2294.....	593
P2295.....	594
P2296.....	595
P2297.....	596
P2298.....	597
P2300.....	598
P2301.....	599
P2303.....	600
P2304.....	601
P2306.....	602
P2307.....	603
P2309.....	604
P2310.....	605
P2312.....	606
P2313.....	607
P2315.....	608
P2316.....	609
P2400.....	610
P2401.....	611
P2402.....	612
P2407.....	613
P240A.....	614
P240B.....	615
P240C.....	616
P2414.....	617

P2415.....	619
P2450.....	621
P24D6.....	622
P24D7.....	623
P24D8.....	624
P250C.....	625
P250D.....	626
P2531.....	627
P2532.....	628
P2539.....	629
P2541.....	630
P2545.....	631
P2610.....	632
P2626.....	633
P2629.....	634
P3052.....	635
P3053.....	636
U0073.....	637
U0101.....	638
U0111.....	639
U0114.....	640
U0126.....	641
U0128.....	642
U0129.....	643
U0131.....	644
U0139.....	645
U0141.....	646
U0142.....	647
U0146.....	648
U0155.....	649
U0159.....	650
U0164.....	651
U0169.....	652
U0199.....	653
U0212.....	654
U0235.....	655
U0300.....	656
U0302.....	657
U0314.....	658

U0318.....	659
U0402.....	660
U0412.....	661
U0414.....	662
U0417.....	663
U0418.....	664
U0422.....	665
U0423.....	666
U0424.....	667
U0428.....	668
U0429.....	669
U0431.....	670
U0433.....	671
U0443.....	672
U0447.....	673
U046A.....	674
U0609.....	675
U060B.....	676
U1103.....	677
U1104.....	678
U3001.....	679

P000A

Diagnostic information - DME (DFI) control unit

Bank 1 intake camshaft adjustment

Diagnostic conditions

- Perform a short test

or:

- **Engine oil temperature** -10 ... +120 °C (14 ... 248 °F)
- **Engine speed** 1,200 ... 6,000 rpm
- None of the following faults stored: P0010, P0020, P2088, P2089, P2092, P2093

Possible fault causes

- ♦ Dynamic driving style when oil level is near minimum (oil foaming)
- ♦ Solenoid valve for hydraulic camshaft adjustment faulty
⇒ (e.g. mechanical fault or dirt (oil circuit))
- ♦ Engine oil pressure too low
⇒ (e.g. oil thinning, oil thickening, wrong oil quality, oil pressure control or oil pump faulty)
- ♦ Camshaft adjustment faulty
- ♦ Intake camshaft stuck

Fault setting condition(s)

- Actual value/setpoint deviation > 10° on intake camshaft

or

- Intake camshaft adjustment slow

P000B

Diagnostic information - DME (DFI) control unit

Bank 1 exhaust camshaft adjustment

Diagnostic conditions

- Perform a short test

or:

- Engine oil temperature -10 ... +120 °C (14 ... 248 °F)
- Engine speed 1,200 ... 6,000 rpm
- None of the following faults stored: P0013, P0023, P2090, P2091, P2094, P2095

Possible fault causes

- ♦ Dynamic driving style when oil level is near minimum (oil foaming)
- ♦ Solenoid valve for hydraulic camshaft adjustment faulty
⇒ (e.g. mechanical fault or dirt (oil circuit))
- ♦ Engine oil pressure too low
⇒ (e.g. oil thinning, oil thickening, wrong oil quality, oil pressure control or oil pump faulty)
- ♦ Camshaft adjustment faulty
- ♦ Exhaust camshaft stuck

Fault setting condition(s)

- Actual value/setpoint deviation > 10° on exhaust camshaft

or

- Exhaust camshaft adjustment slow

P000C

Diagnostic information - DME (DFI) control unit

Bank 2 intake camshaft adjustment

Diagnostic conditions

- Perform a short test
- or:
- Engine oil temperature -10 ... +120 °C (14 ... 248 °F)
 - Engine speed 1,200 6,000 rpm
 - None of the following faults stored: P0010, P0020, P2088, P2089, P2092, P2093

Possible fault causes

- ♦ Dynamic driving style when oil level is near minimum (oil foaming)
- ♦ Solenoid valve for hydraulic camshaft adjustment faulty
⇒ (e.g. mechanical fault or dirt (oil circuit))
- ♦ Engine oil pressure too low
⇒ (e.g. oil thinning, oil thickening, wrong oil quality, oil pressure control or oil pump faulty)
- ♦ Camshaft adjustment faulty
- ♦ Intake camshaft stuck

Fault setting condition(s)

- Actual value/setpoint deviation > 10° on intake camshaft
- or
- Intake camshaft adjustment slow

P000D

Diagnostic information - DME (DFI) control unit

Bank 1 exhaust camshaft adjustment

Diagnostic conditions

- Perform a short test
- or:
- Engine oil temperature -10 ... +120 °C (14 ... 248 °F)
 - Engine speed 1,200 ... 6,000 rpm
 - None of the following faults stored: P0013, P0023, P2090, P2091, P2094, P2095

Possible fault causes

- ♦ Dynamic driving style when oil level is near minimum (oil foaming)
- ♦ Solenoid valve for hydraulic camshaft adjustment faulty
⇒ (e.g. mechanical fault or dirt (oil circuit))
- ♦ Engine oil pressure too low
⇒ (e.g. oil thinning, oil thickening, wrong oil quality, oil pressure control or oil pump faulty)
- ♦ Camshaft adjustment faulty
- ♦ Exhaust camshaft stuck

Fault setting condition(s)

- Actual value/setpoint deviation > 10° on exhaust camshaft
- or
- Exhaust camshaft adjustment slow

P0010

Diagnostic information - DME (DFI) control unit

Intake camshaft adjustment output stage, bank 1

Diagnostic conditions

- Time since engine start > 10 second(s)
- None of the following faults stored: P1556, P1557, P1558

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line (activation)
- ♦ Short circuit to ground or open circuit in the lines (power supply)
- ♦ Fuse faulty
- ♦ Solenoid valve for hydraulic camshaft adjustment faulty

P0011

Diagnostic information - DME (DFI) control unit

Bank 1 intake camshaft adjustment

Diagnostic conditions

- Perform a short test

or:

- **Engine oil temperature** -10 ... +120 °C (14 ... 248 °F)
- **Engine speed** 1,200 ... 6,000 rpm
- None of the following faults stored: P0010, P0020, P2088, P2089, P2092, P2093

Possible fault causes

- ♦ Dynamic driving style when oil level is near minimum (oil foaming)
- ♦ Solenoid valve for hydraulic camshaft adjustment faulty
⇒ (e.g. mechanical fault or dirt (oil circuit))
- ♦ Engine oil pressure too low
⇒ (e.g. oil thinning, oil thickening, wrong oil quality, oil pressure control or oil pump faulty)
- ♦ Camshaft adjustment faulty
- ♦ Intake camshaft stuck

Fault setting condition(s)

- Actual value/setpoint deviation > 10° on intake camshaft

or

- Intake camshaft adjustment slow

P0013

Diagnostic information - DME (DFI) control unit

Bank 1 exhaust camshaft adjustment output stage

Diagnostic conditions

- Time since engine start > 10 second(s)
- None of the following faults stored: P1556, P1557, P1558

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line (activation)
- ♦ Short circuit to ground or open circuit in the lines (power supply)
- ♦ Fuse faulty
- ♦ Solenoid valve for hydraulic camshaft adjustment faulty

P0014

Diagnostic information - DME (DFI) control unit

Bank 1 exhaust camshaft adjustment

Diagnostic conditions

- Perform a short test

or:

- Engine oil temperature -10 ... +120 °C (14 ... 248 °F)
- Engine speed 1,200 ... 6,000 rpm
- None of the following faults stored: P0013, P0023, P2090, P2091, P2094, P2095

Possible fault causes

- ♦ Dynamic driving style when oil level is near minimum (oil foaming)
- ♦ Solenoid valve for hydraulic camshaft adjustment faulty
⇒ (e.g. mechanical fault or dirt (oil circuit))
- ♦ Engine oil pressure too low
⇒ (e.g. oil thinning, oil thickening, wrong oil quality, oil pressure control or oil pump faulty)
- ♦ Camshaft adjustment faulty
- ♦ Exhaust camshaft stuck

Fault setting condition(s)

- Actual value/setpoint deviation > 10° on exhaust camshaft
- or
- Exhaust camshaft adjustment slow

Diagnostic information - DME (DFI) control unit

Crankshaft position in relation to bank 1 intake camshaft

Diagnostic conditions

- Time since engine start > 10 second(s)

Possible fault causes

- ♦ Timing wrong due to:
 - ♦ Timing chain stretched
 - ♦ Chain jump
 - ♦ Engine repairs
- ♦ Camshaft adjustment faulty (locking)
- ♦ Intake camshaft sensor wrong
- ♦ Camshaft sensor loose
- ♦ Phase sensor on camshaft wrong or damaged

Fault setting condition(s)

- Current timing does not match stored timing (last engine run)
- or
- Adaptation not within the valid value range

Diagnostic information - DME (DFI) control unit

Crankshaft position in relation to bank 1 exhaust camshaft

Diagnostic conditions

- Time since engine start > 10 second(s)

Possible fault causes

- ♦ Timing wrong due to:
 - ♦ Timing chain stretched
 - ♦ Chain jump
 - ♦ Engine repairs
- ♦ Camshaft adjustment faulty (locking)
- ♦ Exhaust camshaft sensor wrong
- ♦ Camshaft sensor loose
- ♦ Phase sensor on camshaft wrong or damaged

Fault setting condition(s)

- Current timing does not match stored timing (last engine run)
- or
- Adaptation not within the valid value range

Diagnostic information - DME (DFI) control unit

Crankshaft position in relation to bank 2 intake camshaft

Diagnostic conditions

- Time since engine start > 10 second(s)

Possible fault causes

- ♦ Timing wrong due to:
 - ♦ Timing chain stretched
 - ♦ Chain jump
 - ♦ Engine repairs
- ♦ Camshaft adjustment faulty (locking)
- ♦ Intake camshaft sensor wrong
- ♦ Camshaft sensor loose
- ♦ Phase sensor on camshaft wrong or damaged

Fault setting condition(s)

- Current timing does not match stored timing (last engine run)
- or
- Adaptation not within the valid value range

Diagnostic information - DME (DFI) control unit

Crankshaft position in relation to bank 2 exhaust camshaft

Diagnostic conditions

- Time since engine start > 10 second(s)

Possible fault causes

- ♦ Timing wrong due to:
 - ♦ Timing chain stretched
 - ♦ Chain jump
 - ♦ Engine repairs
- ♦ Camshaft adjustment faulty (locking)
- ♦ Exhaust camshaft sensor wrong
- ♦ Camshaft sensor loose
- ♦ Phase sensor on camshaft wrong or damaged

Fault setting condition(s)

- Current timing does not match stored timing (last engine run)
- or
- Adaptation not within the valid value range

Diagnostic information - DME (DFI) control unit

Intake camshaft adjustment output stage, bank 2

Diagnostic conditions

- Time since engine start > 10 second(s)
- None of the following faults stored: P1556, P1557, P1558

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line (activation)
- ♦ Short circuit to ground or open circuit in the lines (power supply)
- ♦ Fuse faulty
- ♦ Solenoid valve for hydraulic camshaft adjustment faulty

P0021

Diagnostic information - DME (DFI) control unit

Bank 2 intake camshaft adjustment

Diagnostic conditions

- Perform a short test
- or:
- Engine oil temperature -10 ... +120 °C (14 ... 248 °F)
 - Engine speed 1,200 6,000 rpm
 - None of the following faults stored: P0010, P0020, P2088, P2089, P2092, P2093

Possible fault causes

- ♦ Dynamic driving style when oil level is near minimum (oil foaming)
- ♦ Solenoid valve for hydraulic camshaft adjustment faulty
⇒ (e.g. mechanical fault or dirt (oil circuit))
- ♦ Engine oil pressure too low
⇒ (e.g. oil thinning, oil thickening, wrong oil quality, oil pressure control or oil pump faulty)
- ♦ Camshaft adjustment faulty
- ♦ Intake camshaft stuck

Fault setting condition(s)

- Actual value/setpoint deviation > 10° on intake camshaft
- or
- Intake camshaft adjustment slow

P0023

Diagnostic information - DME (DFI) control unit

Bank 2 exhaust camshaft adjustment output stage

Diagnostic conditions

- Time since engine start > 10 second(s)
- None of the following faults stored: P1556, P1557, P1558

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line (activation)
- ♦ Short circuit to ground or open circuit in the lines (power supply)
- ♦ Fuse faulty
- ♦ Solenoid valve for hydraulic camshaft adjustment faulty

P0024

Diagnostic information - DME (DFI) control unit

Bank 1 exhaust camshaft adjustment

Diagnostic conditions

- Perform a short test
- or:
- Engine oil temperature -10 ... +120 °C (14 ... 248 °F)
 - Engine speed 1,200 ... 6,000 rpm
 - None of the following faults stored: P0013, P0023, P2090, P2091, P2094, P2095

Possible fault causes

- ♦ Dynamic driving style when oil level is near minimum (oil foaming)
- ♦ Solenoid valve for hydraulic camshaft adjustment faulty
⇒ (e.g. mechanical fault or dirt (oil circuit))
- ♦ Engine oil pressure too low
⇒ (e.g. oil thinning, oil thickening, wrong oil quality, oil pressure control or oil pump faulty)
- ♦ Camshaft adjustment faulty
- ♦ Exhaust camshaft stuck

Fault setting condition(s)

- Actual value/setpoint deviation > 10° on exhaust camshaft
- or
- Exhaust camshaft adjustment slow

P0030

Diagnostic information - DME (DFI) control unit

Oxygen sensor heater driver for oxygen sensor upstream of catalytic converter, bank 1

NOTE

Plug connection disconnected = reference-air duct open!

Damage to oxygen sensor!

♦ **DO NOT** use spray, grease, fluid or similar products on the oxygen sensor plug connections.

INFORMATION

- ♦ Do not interchange the oxygen sensor upstream of the catalytic converter with the sensor downstream of the catalytic converter as this will result in implausible fault entries.
- ♦ The connectors themselves are coded and cannot be interchanged.

Diagnostic conditions

- Engine running > 10 second(s)

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground or open circuit in the line (power supply or activation)
- ♦ Oxygen sensor upstream of catalytic converter, bank 1 faulty

P0031

Diagnostic information - DME (DFI) control unit

Oxygen sensor heater driver for oxygen sensor upstream of catalytic converter, bank 1

NOTE

Plug connection disconnected = reference-air duct open!

Damage to oxygen sensor!

♦ **DO NOT** use spray, grease, fluid or similar products on the oxygen sensor plug connections.

INFORMATION

- ♦ Do not interchange the oxygen sensor upstream of the catalytic converter with the sensor downstream of the catalytic converter as this will result in implausible fault entries.
- ♦ The connectors themselves are coded and cannot be interchanged.

Diagnostic conditions

- Engine running > 10 second(s)

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground or open circuit in the line (power supply or activation)
- ♦ Oxygen sensor upstream of catalytic converter, bank 1 faulty

P0032

Diagnostic information - DME (DFI) control unit

Oxygen sensor heater driver for oxygen sensor upstream of catalytic converter, bank 1

NOTE

Plug connection disconnected = reference-air duct open!

Damage to oxygen sensor!

♦ **DO NOT** use spray, grease, fluid or similar products on the oxygen sensor plug connections.

INFORMATION

- ♦ Do not interchange the oxygen sensor upstream of the catalytic converter with the sensor downstream of the catalytic converter as this will result in implausible fault entries.
- ♦ The connectors themselves are coded and cannot be interchanged.

Diagnostic conditions

- Engine running > 10 second(s)

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground or open circuit in the line (power supply or activation)
- ♦ Oxygen sensor upstream of catalytic converter, bank 1 faulty

Diagnostic information - DME (DFI) control unit

Diverter solenoid valve

Diagnostic conditions

- Driving with 1 full-load acceleration and 1 overrun phase

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Diverter solenoid valve faulty

Diagnostic information - DME (DFI) control unit

Diverter solenoid valve

Diagnostic conditions

- Driving with 1 full-load acceleration and 1 overrun phase

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Diverter solenoid valve faulty

Diagnostic information - DME (DFI) control unit

Diverter solenoid valve

Diagnostic conditions

- Driving with 1 full-load acceleration and 1 overrun phase

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Diverter solenoid valve faulty

Diagnostic information - DME (DFI) control unit

Oxygen sensor heater driver downstream of catalytic converter, bank 1

NOTE

Plug connection disconnected = reference-air duct open!

Damage to oxygen sensor!

♦ **DO NOT** use spray, grease, fluid or similar products on the oxygen sensor plug connections.

INFORMATION

♦ Do not interchange oxygen sensor upstream of catalytic converter with oxygen sensor downstream of catalytic converter as this will result in implausible fault entries.

♦ The connectors themselves are coded and cannot be interchanged.

Diagnostic conditions

- Engine running > 10 second(s)
- Oxygen sensor heater active

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground or open circuit in the line (power supply or activation)
- ♦ Oxygen sensor downstream of catalytic converter, bank 1 faulty