

P1565

Diagnostic information - DME (DFI) control unit

Adaptive cruise control (ACC) implausible

Diagnostic conditions

- Driving

Possible fault causes

- ♦ Fault in adaptive cruise control (ACC) area

Fault setting condition(s)

- Simultaneous detection of
 - ♦ Request: Acceleration - adaptive cruise control (ACC)
 - and
 - ♦ Input signal: Brake light switch

P1575

Diagnostic information - DME (DFI) control unit

Accelerator pedal potentiometer implausible

Diagnostic conditions

- Ignition on > 3 second(s)
- then accelerator pedal pressed down fully > 3 second(s)
- then release accelerator pedal fully
- then idling > 10 second(s)

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in wiring to potentiometer 1 and 2
- ♦ Accelerator pedal potentiometer 1 and 2 faulty

Fault setting condition(s)

- Both potentiometers detected as faulty.
- Individual faults are also entered in most cases.

Fault effects

- ♦ Engine does not respond to throttle, engine speed 1,000 rpm

P1577

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

P1590

Diagnostic information - DME (DFI) control unit

Engine mount output stage: electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ One of the two engine mounts faulty (dynamic engine mounts)

P1591

Diagnostic information - DME (DFI) control unit

Engine mount output stage: electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ One of the two engine mounts faulty (dynamic engine mounts)

P1592

Diagnostic information - DME (DFI) control unit

Engine mount output stage: electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ One of the two engine mounts faulty (dynamic engine mounts)

P1593

Diagnostic information - DME (DFI) control unit

Transmission mount output stage: electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ One of the two transmission mounts faulty (dynamic transmission mounts)

P1594

Diagnostic information - DME (DFI) control unit

Transmission mount output stage: electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ One of the two transmission mounts faulty (dynamic transmission mounts)

P1599

Diagnostic information - DME (DFI) control unit

Neutral position implausible - without power transmission

Diagnostic conditions

- Engine running
- Vehicle speed 0 km/h (0 mph)
- Clutch pedal NOT pressed

Possible fault causes

- ♦ Neutral position sensor loose
- ♦ Neutral position sensor faulty
- ♦ Faults in the area of the shift lever on the transmission/shift module (loose, worn out, ...)

Fault setting condition(s)

- The detected angle of the neutral sensor (C014) deviates by more than 11.25° from the adapted neutral position mean value (C020), and the DME control unit detects power transmission interrupted (See Diagnostic conditions).

⇒ This means that the fault is detected when the neutral position is NOT detected although there is clearly NO power transmission in the powertrain when the clutch is closed.

Fault effects

- ♦ Start/Stop system does not function

P15A0

Diagnostic information - DME (DFI) control unit

Neutral position sensor: open circuit/short circuit to B+

Diagnostic conditions

- Ignition on
- Shift lever in lower shift gate (2, 4, 6)

Possible fault causes

- ♦ Short circuit to B+ or open circuit in the lines
- ♦ Neutral position sensor faulty

Fault setting condition(s)

- PWM signal 100% (normal range 10 ... 90%)

Fault effects

- ♦ Start/Stop system does not function

P15A1

Diagnostic information - DME (DFI) control unit

Neutral position implausible - with power transmission

Diagnostic conditions

- In upper (1, 3, 5, 7) and lower (2, 4, 6) shift gate, respectively:
 - Driving under load > 90 Nm for > 1 second, with:
 - Clutch pedal NOT pressed
 - then driving in overrun mode for > 1 second, with:
 - Clutch pedal NOT pressed

Possible fault causes

- ♦ Neutral position sensor loose
- ♦ Neutral position sensor faulty
- ♦ Faults in the area of the shift lever on the transmission/shift module (loose, worn out, ...)

Fault setting condition(s)

- The detected angle of the neutral sensor (C014) is within the range of around 11.25° compared to the adapted neutral position mean value (C020), and the DME control unit detects power transmission present (See Diagnostic conditions).

⇒ This means that the fault is detected when the neutral position is detected although there is clearly power transmission in the powertrain.

Fault effects

- ♦ Start/Stop system does not function

P15A2

Diagnostic information - DME (DFI) control unit

Neutral position sensor: short circuit to ground or solenoid missing

Diagnostic conditions

- Ignition on
- Shift lever in upper shift gate (1, 3, 5, 7, R)

Possible fault causes

- ♦ Solenoid in transmission faulty, with PWM signal = 5% (See [C010](#))
- ♦ Short circuit to ground in line(s)
- ♦ Neutral position sensor faulty, with PWM signal = 0% (See [C010](#))

Fault setting condition(s)

- PWM signal 0% ⇒ Short circuit to ground
- or
- PWM signal 5% ⇒ Solenoid in transmission is not recognized (normal range 10 ... 90%)

Fault effects

- ♦ Start/Stop system does not function

P1600

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

P1603

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

P1615

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

P161A

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

P1620

Diagnostic information - DME (DFI) control unit

Crash signal monitoring

INFORMATION

This entry in the fault memory merely indicates that an airbag triggering event resulted in the deactivation of the fuel supply and may have caused the engine to stall.

Diagnostic conditions

- Engine start

Possible fault causes

- ♦ Airbag drive link test
- ♦ Accident detection

P1626

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - DME (DFI) control unit

Coolant run-on pump output stage

Diagnostic conditions

- Coolant run-on pump activated

► see 

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Coolant run-on pump faulty

INFORMATION

The coolant run-on pump can be activated via drive link activation only if there is NO request from the DME control unit.

- The DME control unit activates the coolant run-on pump under the following conditions:

1. For diagnostics: 10 seconds after starting the engine, for a duration of 10 seconds.
2. If engine temperature (**T020**) > 111 °C (232 °F): The pump is activated continuously until the engine speed (**A020**) is 2,528 rpm. (Switch-off conditions < 107 °C (224 °F) or < 2,016 rpm).
3. After the ignition is switched off and depending on the engine stop temperature (**T080**), the pump is activated for 5 ... 20 minutes, depending also on the engine oil temperature (**T030**) and turbocharger exhaust temperature (**T210/T220**).

The minimum switch-on conditions are:

- **T080** > 83.25 °C (181.85 °F)

or

- **T030** > 85 °C (185 °F)

or

- **T210/T220** > 600 °C (1,112 °F)

Diagnostic information - DME (DFI) control unit

Coolant run-on pump output stage

Diagnostic conditions

- Coolant run-on pump activated
 - ▶ see 

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Coolant run-on pump faulty

INFORMATION

The coolant run-on pump can be activated via drive link activation only if there is NO request from the DME control unit.

- The DME control unit activates the coolant run-on pump under the following conditions:
 1. For diagnostics: 10 seconds after starting the engine, for a duration of 10 seconds.
 2. If engine temperature (**T020**) > 111 °C (232 °F): The pump is activated continuously until the engine speed (**A020**) is 2,528 rpm. (Switch-off conditions < 107 °C (224 °F) or < 2,016 rpm).
 3. After the ignition is switched off and depending on the engine stop temperature (**T080**), the pump is activated for 5 ... 20 minutes, depending also on the engine oil temperature (**T030**) and turbocharger exhaust temperature (**T210/T220**).

The minimum switch-on conditions are:

- **T080** > 83.25 °C (181.85 °F)
- or
- **T030** > 85 °C (185 °F)
- or
- **T210/T220** > 600 °C (1,112 °F)

Diagnostic information - DME (DFI) control unit

Coolant run-on pump output stage

Diagnostic conditions

- Coolant run-on pump activated

► see 

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Coolant run-on pump faulty

INFORMATION

The coolant run-on pump can be activated via drive link activation only if there is NO request from the DME control unit.

- The DME control unit activates the coolant run-on pump under the following conditions:

1. For diagnostics: 10 seconds after starting the engine, for a duration of 10 seconds.
2. If engine temperature (**T020**) > 111 °C (232 °F): The pump is activated continuously until the engine speed (**A020**) is 2,528 rpm. (Switch-off conditions < 107 °C (224 °F) or < 2,016 rpm).
3. After the ignition is switched off and depending on the engine stop temperature (**T080**), the pump is activated for 5 ... 20 minutes, depending also on the engine oil temperature (**T030**) and turbocharger exhaust temperature (**T210/T220**).

The minimum switch-on conditions are:

- **T080** > 83.25 °C (181.85 °F)

or

- **T030** > 85 °C (185 °F)

or

- **T210/T220** > 600 °C (1,112 °F)

P1651

Diagnostic information - DME (DFI) control unit

Coolant switch-over valve driver for transmission oil

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Coolant switch-over valve for transmission oil faulty

P1652

Diagnostic information - DME (DFI) control unit

Coolant switch-over valve driver for transmission oil

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Coolant switch-over valve for transmission oil faulty

P1653

Diagnostic information - DME (DFI) control unit

Coolant switch-over valve driver for transmission oil

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Coolant switch-over valve for transmission oil faulty

P1654

Diagnostic information - DME (DFI) control unit

Coolant switch-over valve driver for clutch oil (PDK)

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Coolant switchover valve for ATF faulty

P1655

Diagnostic information - DME (DFI) control unit

Coolant switch-over valve driver for clutch oil (PDK)

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Coolant switchover valve for ATF faulty

P1656

Diagnostic information - DME (DFI) control unit

Coolant switch-over valve driver for clutch oil (PDK)

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Coolant switchover valve for ATF faulty

P1660

Diagnostic information - DME (DFI) control unit

Coolant switch-over valve driver for engine

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Engine coolant switchover valve faulty

P1661

Diagnostic information - DME (DFI) control unit

Coolant switch-over valve driver for engine

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Engine coolant switchover valve faulty

P1662

Diagnostic information - DME (DFI) control unit

Coolant switch-over valve driver for engine

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Engine coolant switchover valve faulty

Diagnostic information - DME (DFI) control unit

Engine compartment purge fan 1: electrical fault

⚠ WARNING

Exposed running fan blades!

Danger of limbs being severed!

Risk of serious injury due to ejected foreign bodies!

- ♦ **ALWAYS** keep hair or clothing out of the rotating range of the fan.
- ♦ DO NOT reach into the rotating fan.
- ♦ **DO NOT** place tools or other items in the rotating range of the fan.
- ♦ Perform work on the fan only after disconnecting the plug connection to the spoiler module first.

i INFORMATION

The run-on duration of the engine compartment purge fan AFTER ignition off depends on the engine compartment temperature.

- ♦ It is as follows for the following engine compartment temperatures:
 - ♦ < 45 °C (113 °F) for approx. 50 seconds
 - ♦ 45 ... 70 °C (113 ... 158 °F) for approx. 200 seconds
 - ♦ > 70 °C (158 °F) for up to 20 minutes

Diagnostic conditions

- Vehicle voltage 10 ... 15 V
- Ignition on or engine running or control unit run-on
- **LOW** stage activated for > 25 seconds (drive links)

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines ► Engine compartment purge fan relay activation
- ♦ Engine compartment purge fan relay activation faulty
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines ► Engine compartment purge fan 1
- ♦ Engine compartment purge fan 1 faulty
- ♦ Short circuit to B+/ground or open circuit in the line ► Diagnostic line to DME (DFI) control unit

Fault setting condition(s)

- Diagnostic voltage for engine compartment purge fan on DME control unit 10 ... 12 V, with:
 - Engine compartment purge fan activated at **LOW** stage
(only engine compartment purge fan relay activation)

Fault effects

- ♦ Engine compartment purge fan activated at **HIGH** stage
- ♦ Resulting diagnostic voltage approx. 12 V

i HIGH stage is canceled only after an ignition change (off ► on), and as long as the fault is not active.

Diagnostic information - DME (DFI) control unit

Engine compartment purge fan 1: blocked

⚠ WARNING

Exposed running fan blades!

Danger of limbs being severed!

Risk of serious injury due to ejected foreign bodies!

- ♦ **ALWAYS** keep hair or clothing out of the rotating range of the fan.
- ♦ DO NOT reach into the rotating fan.
- ♦ **DO NOT** place tools or other items in the rotating range of the fan.
- ♦ Perform work on the fan only after disconnecting the plug connection to the spoiler module first.

i INFORMATION

The run-on duration of the engine compartment purge fan AFTER ignition off depends on the engine compartment temperature.

- ♦ It is as follows for the following engine compartment temperatures:
 - ♦ < 45 °C (113 °F) for approx. 50 seconds
 - ♦ 45 ... 70 °C (113 ... 158 °F) for approx. 200 seconds
 - ♦ > 70 °C (158 °F) for up to 20 minutes

Diagnostic conditions

- Vehicle voltage 10 ... 15 V
- Ignition on or engine running or control unit run-on
- **LOW** stage activated for > 25 seconds (drive links)

Possible fault causes

- ♦ Engine compartment purge fan 1 mechanically blocked
- ♦ Short circuit to B+/ground or open circuit in the line ► Diagnostic line to DME (DFI) control unit

Fault setting condition(s)

- Diagnostic voltage for engine compartment purge fan on DME control unit 8 ... 10 V, with:
 - Engine compartment purge fan activated at **LOW** stage
(only engine compartment purge fan relay activation)

Diagnostic information - DME (DFI) control unit

Engine compartment purge fan 2: electrical fault

⚠ WARNING

Exposed running fan blades!

Danger of limbs being severed!

Risk of serious injury due to ejected foreign bodies!

- ♦ **ALWAYS** keep hair or clothing out of the rotating range of the fan.
- ♦ DO NOT reach into the rotating fan.
- ♦ **DO NOT** place tools or other items in the rotating range of the fan.
- ♦ Perform work on the fan only after disconnecting the plug connection to the spoiler module first.

i INFORMATION

The run-on duration of the engine compartment purge fan AFTER ignition off depends on the engine compartment temperature.

- ♦ It is as follows for the following engine compartment temperatures:
 - ♦ < 45 °C (113 °F) for approx. 50 seconds
 - ♦ 45 ... 70 °C (113 ... 158 °F) for approx. 200 seconds
 - ♦ > 70 °C (158 °F) for up to 20 minutes

Diagnostic conditions

- Vehicle voltage 10 ... 15 V
- Ignition on or engine running or control unit run-on
- **LOW** stage activated for > 25 seconds (drive links)

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines ► Engine compartment purge fan relay activation
- ♦ Engine compartment purge fan relay activation faulty
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines ► Engine compartment purge fan 2
- ♦ Engine compartment purge fan 2 faulty
- ♦ Short circuit to B+/ground or open circuit in the line ► Diagnostic line to DME (DFI) control unit

Fault setting condition(s)

- Diagnostic voltage for engine compartment purge fan on DME control unit 2 ... 0 V, with:
 - Engine compartment purge fan activated at **LOW** stage
(only engine compartment purge fan relay activation)

Fault effects

- ♦ Engine compartment purge fan activated at **HIGH** stage
- ♦ Resulting diagnostic voltage approx. 12 V

i HIGH stage is canceled only after an ignition change (off ► on), and as long as the fault is not active.

Diagnostic information - DME (DFI) control unit

Engine compartment purge fan 2: blocked

⚠ WARNING

Exposed running fan blades!

Danger of limbs being severed!

Risk of serious injury due to ejected foreign bodies!

- ♦ **ALWAYS** keep hair or clothing out of the rotating range of the fan.
- ♦ DO NOT reach into the rotating fan.
- ♦ **DO NOT** place tools or other items in the rotating range of the fan.
- ♦ Perform work on the fan only after disconnecting the plug connection to the spoiler module first.

i INFORMATION

The run-on duration of the engine compartment purge fan AFTER ignition off depends on the engine compartment temperature.

- ♦ It is as follows for the following engine compartment temperatures:
 - ♦ < 45 °C (113 °F) for approx. 50 seconds
 - ♦ 45 ... 70 °C (113 ... 158 °F) for approx. 200 seconds
 - ♦ > 70 °C (158 °F) for up to 20 minutes

Diagnostic conditions

- Vehicle voltage 10 ... 15 V
- Ignition on or engine running or control unit run-on
- **LOW** stage activated for > 25 seconds (drive links)

Possible fault causes

- ♦ Engine compartment purge fan 2 mechanically blocked
- ♦ Short circuit to B+/ground or open circuit in the line ► Diagnostic line to DME (DFI) control unit

Fault setting condition(s)

- Diagnostic voltage for engine compartment purge fan on DME control unit 4 ... 2 V, with:
 - Engine compartment purge fan activated at **LOW** stage
(only engine compartment purge fan relay activation)

Diagnostic information - DME (DFI) control unit

Engine compartment purge fan: function

⚠ WARNING

Exposed running fan blades!

Danger of limbs being severed!

Risk of serious injury due to ejected foreign bodies!

- ♦ **ALWAYS** keep hair or clothing out of the rotating range of the fan.
- ♦ DO NOT reach into the rotating fan.
- ♦ **DO NOT** place tools or other items in the rotating range of the fan.
- ♦ Perform work on the fan only after disconnecting the plug connection to the spoiler module first.

i INFORMATION

The run-on duration of the engine compartment purge fan AFTER ignition off depends on the engine compartment temperature.

- ♦ It is as follows for the following engine compartment temperatures:
 - ♦ < 45 °C (113 °F) for approx. 50 seconds
 - ♦ 45 ... 70 °C (113 ... 158 °F) for approx. 200 seconds
 - ♦ > 70 °C (158 °F) for up to 20 minutes

Diagnostic conditions

- Engine compartment purge fan activated > 200 second(s)

Possible fault causes

- ♦ Air intake covered or blocked (vehicle tarp)
- ♦ Engine compartment temperature sensor has fallen out of holder (sensor is lying on engine)
- ♦ Engine compartment purge fan faulty (electrical fault, stiff, blocked)
- ♦ Engine compartment purge fan relay faulty (mechanical or electrical fault)
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Engine compartment temperature sensor faulty

Fault setting condition(s)

- Engine compartment temperature > 110 °C (230 °F), with:
 - Engine compartment purge fan activated > 200 second(s)

Diagnostic information - DME (DFI) control unit

Engine compartment purge fan relay switchover HIGH/ LOW

INFORMATION

The run-on duration of the engine compartment purge fan AFTER ignition off depends on the engine compartment temperature.

- ◆ It is as follows for the following engine compartment temperatures:
 - ◆ < 45 °C (113 °F) for approx. 50 seconds
 - ◆ 45 ... 70 °C (113 ... 158 °F) for approx. 200 seconds
 - ◆ > 70 °C (158 °F) for up to 20 minutes

Diagnostic conditions

- Vehicle voltage 10 ... 15 V
- Ignition on or engine running or control unit run-on
- **HIGH** stage activated for > 25 seconds (drive links)

Possible fault causes

- ◆ Short circuit to B+/ground/between lines or open circuit in the lines ► Engine compartment purge fan relay switchover HIGH/ LOW
- ◆ Engine compartment purge fan relay switchover HIGH/LOW faulty

Diagnostic information - DME (DFI) control unit

Engine compartment purge fan relay switchover HIGH/ LOW

INFORMATION

The run-on duration of the engine compartment purge fan AFTER ignition off depends on the engine compartment temperature.

- ◆ It is as follows for the following engine compartment temperatures:
 - ◆ < 45 °C (113 °F) for approx. 50 seconds
 - ◆ 45 ... 70 °C (113 ... 158 °F) for approx. 200 seconds
 - ◆ > 70 °C (158 °F) for up to 20 minutes

Diagnostic conditions

- Vehicle voltage 10 ... 15 V
- Ignition on or engine running or control unit run-on
- **HIGH** stage activated for > 25 seconds (drive links)

Possible fault causes

- ◆ Short circuit to B+/ground/between lines or open circuit in the lines ► Engine compartment purge fan relay switchover HIGH/ LOW
- ◆ Engine compartment purge fan relay switchover HIGH/LOW faulty

Diagnostic information - DME (DFI) control unit

Engine compartment purge fan 1 activation: electrical fault

- ♦ 911 Carrera - right
- ♦ 718 Boxster/Cayman - left

⚠ WARNING

Exposed running fan blades!

Danger of limbs being severed!

Risk of serious injury due to ejected foreign bodies!

- ♦ **ALWAYS** keep hair or clothing out of the rotating range of the fan.
- ♦ DO NOT reach into the rotating fan.
- ♦ **DO NOT** place tools or other items in the rotating range of the fan.
- ♦ Perform work on the fan only with the ignition switched off.
- ♦ Secure the ignition to prevent it from being switched on accidentally by other persons.

NOTE

Sensitive electronics!

Risk of irreparable damage to electronic components!

- ♦ **DO NOT** carry out electrical tests.
- ♦ **DO NOT** connect external power sources.

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Short circuit to ground or open circuit in lines (power supply to radiator fan control unit terminal 30)
- ♦ Short circuit to B+/ground or open circuit in the line (radiator fan control unit activation)
- ♦ Engine compartment purge fan 1 faulty