

U0418

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

U0422

Diagnostic information - DME (DFI) control unit

Ambient temperature via CAN

(See Air-conditioning system regulator)

Diagnostic conditions

- Ignition on > 5 second(s)

Possible fault causes

- ♦ Outside temperature sensor fault
- ♦ The expected signal or message deviates from the specified value.

Fault effects

- ♦ Substitute value from model

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

U0424

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

U0431

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ♦ Fault in the designated control unit
- ♦ Note in the designated control unit

Fault effects

- ♦ Functions in the control unit are available only with restrictions
- ♦ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ♦ Fault in the designated control unit
- ♦ Note in the designated control unit

Fault effects

- ♦ Functions in the control unit are available only with restrictions
- ♦ Functions in the control unit are not available

Diagnostic information - DME (DFI) control unit

Intake manifold pressure sensor: electrical fault

Diagnostic conditions

- Ignition on or engine running

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ 5 V power supply faulty
- ♦ Ground supply faulty
- ♦ Intake manifold pressure sensor faulty

Fault effects

- ♦ Substitute value from model

U060B

Diagnostic information - DME (DFI) control unit

Boost pressure sensor (pressure sensor ahead of throttle valve): electrical fault

Diagnostic conditions

- Ignition on or engine running

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ 5 V power supply faulty
- ♦ Ground supply faulty
- ♦ Pressure sensor ahead of throttle valve faulty

Fault effects

- ♦ Substitute value from model

U1103

Diagnostic information - DME (DFI) control unit

Transport or Production mode active

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Vehicle handover has not yet been performed
 - Perform vehicle handover using the PIWIS Tester.

U1104

Diagnostic information - DME (DFI) control unit

Transport or Production mode active

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Vehicle handover has not yet been performed
 - Perform vehicle handover using the PIWIS Tester.

Diagnostic information - DME (DFI) control unit

DME control unit: run-on fault

Diagnostic conditions

- Vehicle voltage > 11 V
- Engine running, then:
 - Switch off ignition
 - Switch on ignition after approx. 25 minutes

Possible fault causes

- ♦ Power supply or ground supply for DME control unit faulty
- ♦ During control unit operation (engine on, ignition on or control unit run-on):
 - ♦ Connector B unlocked or unplugged from DME (DFI) control unit
 - ♦ Power supply to DME (DFI) control unit interrupted

Fault setting condition(s)

- Control unit run-on was ended too early 10 times or lasted longer than permitted.

INFORMATION

After the ignition is switched off (terminal 15), the DME control unit switches to control unit run-on mode.

- ♦ The run-on period depends on many underlying conditions (e.g. engine compartment temperature for purge fan activation).

The run-on duration can be 1 minute when the engine is cold and up to 25 minutes when the engine is hot.