

991 + 981 , MY 2012 =>

Diagnosis information - Selector lever

P0562.....	1
P0563.....	2
P0600.....	3
P0602.....	4
P0605.....	5
P060C.....	6
P0705.....	7
P1801.....	8
P1802.....	9
P18E0.....	10

P0562

Diagnosis information - **Selector lever**

Undervoltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Terminal 15 below 9 V
- **Terminal 86S** below 9 V

P0563

Diagnosis information - **Selector lever**

Overvoltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Terminal 15 or **Terminal 86S** above 16.5 V

P0600

Diagnosis information - **Selector lever**

Fault in serial communication to PDK

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Message check detects fault

P0602

Diagnosis information - Selector lever

Control unit not programmed

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Control unit software not valid

P0605

Diagnosis information - Selector lever

Software error

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Internal software test reports an error

P060C

Diagnosis information - Selector lever

Control unit faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Internal hardware fault in CAN controller
- Internal sensor voltage implausible
- Internal key-lock signal implausible

P0705

Diagnosis information - **Selector lever**

Position information implausible

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Position sensor detects selector lever in several positions at same time.

P1801

Diagnosis information - **Selector lever**

Position information for M gate implausible

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Position sensor detects the selector lever in several positions between D position and M gate at the same time

P1802

Diagnosis information - **Selector lever**

Position information Actuator solenoid for R/P interlock implausible

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Actuator solenoid not detected in any limit position

P18E0

Diagnosis information - **Selector lever**

Undervoltage at Terminal 86S

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Terminal 15 between 9 V and 16 V
- **Terminal 86S** below 4 V