

000211

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

Diagnosis information - PDCC control unit

Control module PDCC Faulty

NOTE

The fault code is >present< only when the engine is running or when the vehicle is being driven.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Incorrect interpretation in the **Control module**
- ◆ **Control module** PDCC Faulty

Fault effects

- ◆ Limited function

Diagnosis information - PDCC control unit

Control module PDCC Faulty

NOTE

The fault code is >present< only when the engine is running or when the vehicle is being driven.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Incorrect interpretation in the **Control module**
- ◆ **Control module** PDCC Faulty

Fault effects

- ◆ Limited function

000220

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

000221

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

000222

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

000223

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

Diagnosis information - PDCC control unit

Control module PDCC Faulty

NOTE

The fault code is >present< only when the engine is running or when the vehicle is being driven.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Incorrect interpretation in the **Control module**
- ◆ **Control module** PDCC Faulty

Fault effects

- ◆ Limited function

Diagnosis information - PDCC control unit

Control module PDCC Faulty

NOTE

The fault code is >present< only when the engine is running or when the vehicle is being driven.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Incorrect interpretation in the **Control module**
- ◆ **Control module** PDCC Faulty

Fault effects

- ◆ Limited function

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

000231

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

000233

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PDCC control unit

Control module PDCC Faulty

NOTE

The fault code is >present< only when the engine is running or when the vehicle is being driven.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Incorrect interpretation in the **Control module**
- ◆ **Control module** PDCC Faulty

Fault effects

- ◆ Limited function

Diagnosis information - PDCC control unit

Control module PDCC Faulty

NOTE

The fault code is >present< only when the engine is running or when the vehicle is being driven.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Incorrect interpretation in the **Control module**
- ◆ **Control module** PDCC Faulty

Fault effects

- ◆ Limited function

000240

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

000241

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

000242

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

000243

Diagnosis information - PDCC control unit

Valve - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Valve block** Faulty

Fault effects

- ♦ No function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

000250

Diagnosis information - PDCC control unit

Suction throttle valve Hydraulic pump - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Suction throttle valve** Faulty

Fault effects

- ♦ none or Limited function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

000251

Diagnosis information - PDCC control unit

Suction throttle valve Hydraulic pump - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Suction throttle valve** Faulty

Fault effects

- ♦ none or Limited function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

000252

Diagnosis information - PDCC control unit

Suction throttle valve Hydraulic pump - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Suction throttle valve** Faulty

Fault effects

- ♦ none or Limited function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

000253

Diagnosis information - PDCC control unit

Suction throttle valve Hydraulic pump - Electrical fault

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** PDCC Function restriction
- ♦ **Suction throttle valve** Faulty

Fault effects

- ♦ none or Limited function

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PDCC control unit

Control module PDCC Faulty

NOTE

The fault code is >present< only when the engine is running or when the vehicle is being driven.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Incorrect interpretation in the **Control module**
- ◆ **Control module** PDCC Faulty

Fault effects

- ◆ Limited function

Diagnosis information - PDCC control unit

Control module PDCC Faulty

NOTE

The fault code is >present< only when the engine is running or when the vehicle is being driven.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Incorrect interpretation in the **Control module**
- ◆ **Control module** PDCC Faulty

Fault effects

- ◆ Limited function

001000

Diagnosis information - PDCC control unit

Hydraulic system Fault read in again

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

♦ **Hydraulic system** Fault was read in again after delete .

Fault effects

♦ No function

001001

Diagnosis information - PDCC control unit

Hydraulic system - Pressure too high Front axle

Diagnostic conditions

- Engine running

or while driving or Commissioning performed

Possible fault causes

- ♦ **Suction throttle valve Hydraulic pump** Faulty
- ♦ **Valve block Front axle** Faulty :
 - Pressure-regulating valve Front axle** stuck Closed
 - Pressure sensor Front axle** Faulty

Fault effects

- ♦ No function / Limp-home

001002

Diagnosis information - PDCC control unit

Hydraulic system - Pressure too high Rear axle

Diagnostic conditions

- Engine running

or while driving or Commissioning performed

Possible fault causes

- ♦ **Suction throttle valve Hydraulic pump** Faulty
- ♦ **Valve block** Rear axle Faulty :
 - Pressure-regulating valve** stuck Closed
 - Pressure sensor** Faulty

Fault effects

- ♦ No function / Limp-home

001003

Diagnosis information - PDCC control unit

Valve block - Front axle

Diagnostic conditions

- Engine running

or while driving or Commissioning performed

Possible fault causes

- ♦ **Valve block Front axle** Faulty :
 Direction valve Front axle stuck
 Pressure sensor Front axle Faulty

Fault effects

- ♦ No function / Limp-home

001004

Diagnosis information - PDCC control unit

Pressure relief valve stuck open

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ **Pressure relief valve** stuck open

Fault effects

- ♦ No function

Diagnosis information - PDCC control unit

Hydraulic system - Pressure too low Front axle

Diagnostic conditions

- Engine running

or while driving or Commissioning performed

Possible fault causes

- ♦ Hydraulic fluid too low / Leak
- ♦ **Suction throttle valve Hydraulic pump** Faulty
- ♦ **Valve block Front axle** Faulty :
 - Pressure relief valve** stuck Closed
 - Pressure-regulating valve Front axle** stuck open
 - Pressure sensor Front axle** Faulty
- ♦ **Hydraulic system Front axle** Mechanical fault
- ♦ **Hydraulic pump** Function restriction

Fault effects

- ♦ No function / Limp-home

Diagnosis information - PDCC control unit

Hydraulic system - Pressure too low Rear axle

Diagnostic conditions

- Engine running

or while driving or Commissioning performed

Possible fault causes

- ♦ Hydraulic fluid too low / Leak
- ♦ **Suction throttle valve Hydraulic pump** Faulty
- ♦ **Valve block** Rear axle Faulty :
 - Pressure-regulating valve** Rear axle stuck open
 - Pressure sensor** Rear axle Faulty
- ♦ **Hydraulic system** Rear axle Mechanical fault
- ♦ **Hydraulic pump** Function restriction

Fault effects

- ♦ No function / Limp-home

001007

Diagnosis information - PDCC control unit

Valve block - Rear axle

Diagnostic conditions

- Engine running

or while driving or Commissioning performed

Possible fault causes

- ♦ **Valve block** Rear axle Faulty :
 - Direction valve** Rear axle stuck
 - Pressure sensor** Rear axle Faulty

Fault effects

- ♦ No function / Limp-home

Diagnosis information - PDCC control unit

Roll angle exceeded

Diagnostic conditions

- Engine running

or while driving

Possible fault causes

- ♦ Fault entry **PSM control module** , **Level-control control unit (PASM)** , **Steering wheel electronics control module**
- ♦ Signal **Combination sensor** implausible
- ♦ Signal **Speed sensor / Vehicle speed** implausible
- ♦ Signal **Body acceleration sensor** implausible
- ♦ Signal **Steering-angle sensor** implausible
- ♦ **Hydraulic system Front axle / Rear axle** Mechanical fault

Fault effects

- ♦ No function / Limp-home

Diagnosis information - PDCC control unit

Hydraulic system - Pressure too high Rear axle

Diagnostic conditions

- Engine running

or while driving or Commissioning performed

Possible fault causes

- ♦ **Suction throttle valve Hydraulic pump** Faulty
- ♦ **Valve block** Rear axle Faulty :
 - Pressure-regulating valve** stuck Closed
 - Pressure sensor** Faulty

Fault effects

- ♦ No function / Limp-home

Diagnosis information - PDCC control unit

Hydraulic system - Pressure too low Rear axle

Diagnostic conditions

- Engine running

or while driving or Commissioning performed

Possible fault causes

- ♦ Hydraulic fluid too low / Leak
- ♦ **Suction throttle valve Hydraulic pump** Faulty
- ♦ **Valve block** Rear axle Faulty :
 - Pressure-regulating valve** Rear axle stuck open
 - Pressure sensor** Rear axle Faulty
- ♦ **Hydraulic system** Rear axle Mechanical fault
- ♦ **Hydraulic pump** Function restriction

Fault effects

- ♦ No function / Limp-home

Diagnosis information - PDCC control unit

Hydraulic system - Pressure too high Front axle

Diagnostic conditions

- Engine running

or while driving or Commissioning performed

Possible fault causes

- ♦ **Suction throttle valve Hydraulic pump** Faulty
- ♦ **Valve block Front axle** Faulty :
 - Pressure-regulating valve Front axle** stuck Closed
 - Pressure sensor Front axle** Faulty

Fault effects

- ♦ No function / Limp-home

Diagnosis information - PDCC control unit

Hydraulic system - Pressure too low Front axle

Diagnostic conditions

- Engine running

or while driving or Commissioning performed

Possible fault causes

- ♦ Hydraulic fluid too low / Leak
- ♦ **Suction throttle valve Hydraulic pump** Faulty
- ♦ **Valve block Front axle** Faulty :
 - Pressure relief valve** stuck Closed
 - Pressure-regulating valve Front axle** stuck open
 - Pressure sensor Front axle** Faulty
- ♦ **Hydraulic system Front axle** Mechanical fault
- ♦ **Hydraulic pump** Function restriction

Fault effects

- ♦ No function / Limp-home