

991 + 981 , MY 2012 =>

Diagnosis information - PASM

000001.....	1
000110.....	2
000111.....	3
000112.....	4
000113.....	5
000114.....	6
000115.....	7
000116.....	8
000117.....	9
000118.....	10
000120.....	11
000121.....	12
000122.....	13
000123.....	14
000124.....	15
000125.....	16
000126.....	17
000127.....	18
000128.....	19
000130.....	20
000131.....	21
000132.....	22
000133.....	23
000134.....	24
000135.....	25
000136.....	26
000137.....	27
000138.....	28
000140.....	29
000141.....	30
000142.....	31
000143.....	32
000144.....	33
000145.....	34
000146.....	35
000147.....	36
000148.....	37
000155.....	38
000156.....	39

000230.....	40
000231.....	41
000232.....	42
000233.....	43
000235.....	44
000236.....	45
000237.....	46
000238.....	47
00023C.....	48
00023D.....	49
000242.....	50
000243.....	51
000247.....	52
000248.....	53
00024C.....	54
00024D.....	55
000252.....	56
000253.....	57
001010.....	58
001011.....	59
001012.....	60
001013.....	61
001014.....	62
001022.....	63
001023.....	64
001024.....	65
001030.....	66
001031.....	67
001032.....	68
001033.....	69
001034.....	70
001035.....	71
001036.....	72
001040.....	73
001041.....	74
001042.....	75
001043.....	76
001044.....	77
001045.....	78

001046.....	79
C11004.....	80
C11005.....	81
C11006.....	82
C11007.....	83

000001

Diagnosis information - Level-control control unit (PASM)

Deviation VIN

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Level-control control unit (PASM) off another Vehicle installed

Fault effects

- ♦ Limited function
- ♦ Warning light yellow

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault (sporadic)

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

This fault is set if an electrical fault occurs 10 times per minute and does not yet meet the fault setting conditions of the other electrical faults.

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault (sporadic)

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

This fault is set if an electrical fault occurs 10 times per minute and does not yet meet the fault setting conditions of the other electrical faults.

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault (sporadic)

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

This fault is set if an electrical fault occurs 10 times per minute and does not yet meet the fault setting conditions of the other electrical faults.

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Valve **Vibration damper** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Valve

Setpoint resistance Valve **Vibration damper** at 20°C (°F) :

- ♦ **2.26 ... 2.65 Ohm**

Diagnosis information - Level-control control unit (PASM)

Valve Vibration damper - Electrical fault (sporadic)

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

This fault is set if an electrical fault occurs 10 times per minute and does not yet meet the fault setting conditions of the other electrical faults.

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**