

Diagnosis information - Level-control control unit (PASM)

Control module Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault setting condition(s)

- Ignition on

Possible fault causes

- **Control module** Faulty

Fault effects

- ♦ **Level-control control unit (PASM)** No function
- ♦ Warning light yellow

Diagnosis information - Level-control control unit (PASM)

Control module Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault setting condition(s)

- Ignition on

Possible fault causes

- **Control module** Faulty

Fault effects

- ♦ **Level-control control unit (PASM)** No function
- ♦ Warning light yellow

Diagnosis information - Level-control control unit (PASM)

Sensors Vehicle level - Short circuit Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Supply voltage Sensors** Vehicle level Short circuit to B+
- ♦ **Supply voltage Sensors** Vehicle level Short circuit to ground
- ♦ **Sensor** Vehicle level Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Sensor Vehicle level

- ♦ **Supply voltage:** **4.85 ... 5.15 V**

Diagnosis information - Level-control control unit (PASM)

Sensors Vehicle level - Short circuit Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Supply voltage Sensors** Vehicle level Short circuit to B+
- ♦ **Supply voltage Sensors** Vehicle level Short circuit to ground
- ♦ **Sensor** Vehicle level Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Nominal values Sensor Vehicle level

- ♦ **Supply voltage:** **4.85 ... 5.15 V**

Diagnosis information - Level-control control unit (PASM)

Sensor Vehicle level

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines (signal)
- ♦ Damage **Sensor** Vehicle level

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensor Vehicle level

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines (signal)
- ♦ Damage **Sensor** Vehicle level

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensors Body acceleration - Short circuit Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Supply voltage Sensors** Body acceleration Short circuit to B+
- ♦ **Supply voltage Sensors** Body acceleration Short circuit to ground
- ♦ **Sensors** Body acceleration Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensors Body acceleration - Short circuit Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Supply voltage Sensors** Body acceleration Short circuit to B+
- ♦ **Supply voltage Sensors** Body acceleration Short circuit to ground
- ♦ **Sensors** Body acceleration Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensor Vehicle level

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines (signal)
- ♦ Damage **Sensor** Vehicle level

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensor Vehicle level

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines (signal)
- ♦ Damage **Sensor** Vehicle level

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensor Vehicle level

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines (signal)
- ♦ Damage **Sensor** Vehicle level

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensor Vehicle level

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines (signal)
- ♦ Damage **Sensor** Vehicle level

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensor Vehicle level

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines (signal)
- ♦ Damage **Sensor** Vehicle level

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensor Vehicle level

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines (signal)
- ♦ Damage **Sensor** Vehicle level

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensor Body acceleration - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensor Body acceleration - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensor Body acceleration - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensor Body acceleration - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensor Body acceleration - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Level-control control unit (PASM)

Sensor Body acceleration - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **Level-control control unit (PASM)** Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Short circuit Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Supply voltage Unit support** Short circuit to B+
- ♦ **Supply voltage Unit support** Short circuit to ground
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Short circuit Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Supply voltage Unit support** Short circuit to B+
- ♦ **Supply voltage Unit support** Short circuit to ground
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault (sporadic)

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

This fault is set if an electrical fault occurs 10 times per minute and does not yet meet the fault setting conditions of the other electrical faults.

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**