

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault (sporadic)

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

This fault is set if an electrical fault occurs 10 times per minute and does not yet meet the fault setting conditions of the other electrical faults.

Possible fault causes

- ♦ Loose contact or corrosion on connectors or lines
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PASM/PADM control unit

Unit support - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Unit support** Faulty
- ♦ PASM/PADM control unit Faulty

Fault effects

- ♦ none or Limited function
- ♦ Warning light yellow

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

C11004

Diagnosis information - Level-control control unit (PASM)

Programming

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Control unit data record is faulty or incorrect

Possible fault causes

- ♦ Incorrect data record programmed
- ♦ Data record faulty

Fault effects

- ♦ Limited functionality **Level-control control unit (PASM)**

Diagnosis information - Level-control control unit (PASM)

Control module Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault setting condition(s)

- Ignition on

Possible fault causes

- **Control module** Faulty

Fault effects

- ♦ **Level-control control unit (PASM)** No function
- ♦ Warning light yellow

C11006

Diagnosis information - Level-control control unit (PASM)

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Level-control control unit (PASM)** incorrectly coded
- ♦ **Level-control control unit (PASM)** not coded

Fault effects

- ♦ **Control module** No function / Limited function
- ♦ Warning light yellow

Diagnosis information - Level-control control unit (PASM)

Control module Calibration

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Level-control control unit (PASM)** Calibration incorrect or not carried out

Fault effects

- ♦ Limited function
- ♦ Warning light yellow