

991 + 981 , MY 2012 =>

Diagnosis information - Tire Pressure Monitoring (TPM)

00C058.....	1
800301.....	2
800302.....	3
800303.....	4
800401.....	5
800402.....	6
800403.....	7
800404.....	8
801101.....	9
801102.....	10
801103.....	11
801104.....	12
801201.....	13
801202.....	14
801203.....	15
801204.....	16
801301.....	17
801302.....	18
801303.....	19
801304.....	20
801401.....	21
801402.....	22
801403.....	23
801404.....	24
802101.....	25
802102.....	26
802103.....	27
802201.....	28
802202.....	29
802203.....	30
802301.....	31
802302.....	32
802303.....	33
802401.....	34
802402.....	35
802403.....	36
803100.....	37
C11005.....	38
C11006.....	39

C11007.....	40
D01100.....	41
D01200.....	42

Diagnostic information - Tire pressure monitoring system control module

No or incorrect coding

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ◆ Wheel electronics contain batteries with lithium thionyl chloride.
- ◆ Do not disposed of these batteries in normal trash (see Environment Manual).
- ◆ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- **Control module** Tire Pressure Monitoring (TPM) - internal function test
- Ignition on
- Approx. 1 minute of driving

Fault setting condition(s)

- No or incorrect coding/parameters set for Tire Pressure Monitoring (TPM) control unit
- Tire Pressure Monitoring (TPM) control unit is in wrong mode (production) --> perform coding
- Tire Pressure Monitoring (TPM) control unit faulty

Fault effects

- ◆ System does not function
- ◆ Display on instrument cluster

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics - no Reception

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ◆ Wheel electronics contain batteries with lithium thionyl chloride.
- ◆ Do not disposed of these batteries in normal trash (see Environment Manual).
- ◆ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- while driving

Possible fault causes

- 1 - 2 Wheel electronics not being received (Fault 800303)
- 3 - 4 Wheel electronics not being received (Fault 800301)

❗ In order to remedy the faults, the faults in the individual wheel electronics must be remedied first.

Fault effects

- ◆ No monitoring of the tire pressure for the affected wheel
- ◆ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Data record **Instrument cluster** implausible

Diagnostic conditions

- Wheel set selection performed / Modification loading

Possible fault causes

- Setpoint pressure **Instrument cluster** implausible :
Outside the valid value range (1.7 ... 5.1 bar)
- Setpoint pressure **Instrument cluster** not present

❗ This fault indicates an incorrect data record in the instrument cluster or an instrument cluster with incorrect parameter assignment.

Fault effects

- ♦ none or Limited function

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics - no Reception

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ◆ Wheel electronics contain batteries with lithium thionyl chloride.
- ◆ Do not disposed of these batteries in normal trash (see Environment Manual).
- ◆ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- while driving

Possible fault causes

- 1 - 2 Wheel electronics not being received (Fault 800303)
- 3 - 4 Wheel electronics not being received (Fault 800301)

❗ In order to remedy the faults, the faults in the individual wheel electronics must be remedied first.

Fault effects

- ◆ No monitoring of the tire pressure for the affected wheel
- ◆ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Radio interference

Diagnostic conditions

- while driving (to approx. **9 min**)

Possible fault causes

- More than one wheel electronics unit transmits from the specified position. This can be caused by transporting a wheel in the vehicle, for example.
- Radio interference, e.g. due to other radio-transmitting components (wireless headphones, etc.)

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Radio interference

Diagnostic conditions

- while driving (to approx. **9 min**)

Possible fault causes

- More than one wheel electronics unit transmits from the specified position. This can be caused by transporting a wheel in the vehicle, for example.
- Radio interference, e.g. due to other radio-transmitting components (wireless headphones, etc.)

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Radio interference

Diagnostic conditions

- while driving (to approx. **9 min**)

Possible fault causes

- More than one wheel electronics unit transmits from the specified position. This can be caused by transporting a wheel in the vehicle, for example.
- Radio interference, e.g. due to other radio-transmitting components (wireless headphones, etc.)

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Radio interference

Diagnostic conditions

- while driving (to approx. **9 min**)

Possible fault causes

- More than one wheel electronics unit transmits from the specified position. This can be caused by transporting a wheel in the vehicle, for example.
- Radio interference, e.g. due to other radio-transmitting components (wireless headphones, etc.)

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Transmitter, trigger signal TPM - Electrical fault

Diagnostic conditions

- Ignition on

Possible fault causes

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Transmitter, trigger signal TPM** Faulty

NOTE

If **all 4 transmitter triggers** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **-0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics Faulty

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ◆ Wheel electronics contain batteries with lithium thionyl chloride.
- ◆ Do not disposed of these batteries in normal trash (see Environment Manual).
- ◆ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- while driving

Possible fault causes

- **Wheel electronics** Faulty

NOTE

If **all 4 wheel electronics** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ◆ No monitoring of the tire pressure for the affected wheel
- ◆ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics - no Reception

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ♦ Wheel electronics contain batteries with lithium thionyl chloride.
- ♦ Do not disposed of these batteries in normal trash (see Environment Manual).
- ♦ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- Ignition on
- After a waiting time of approx. **10 min** / while driving

Possible fault causes

- none **Wheel electronics** installed
- incorrect component(s) **Wheel electronics** installed
- **Wheel electronics** Faulty

NOTE

If **all 4 wheel electronics** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics - Overtemperature

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ◆ Wheel electronics contain batteries with lithium thionyl chloride.
- ◆ Do not disposed of these batteries in normal trash (see Environment Manual).
- ◆ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- while driving

Possible fault causes

- **Temperature Wheel electronics** > 120 °C (°F) (reversible)
- **Wheel electronics** Faulty

Fault effects

- ◆ No monitoring of the tire pressure for the affected wheel

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics Faulty

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ◆ Wheel electronics contain batteries with lithium thionyl chloride.
- ◆ Do not disposed of these batteries in normal trash (see Environment Manual).
- ◆ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- while driving

Possible fault causes

- **Wheel electronics** Faulty

NOTE

If **all 4 wheel electronics** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ◆ No monitoring of the tire pressure for the affected wheel
- ◆ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics - no Reception

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ♦ Wheel electronics contain batteries with lithium thionyl chloride.
- ♦ Do not disposed of these batteries in normal trash (see Environment Manual).
- ♦ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- Ignition on
- After a waiting time of approx. **10 min** / while driving

Possible fault causes

- none **Wheel electronics** installed
- incorrect component(s) **Wheel electronics** installed
- **Wheel electronics** Faulty

NOTE

If **all 4 wheel electronics** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics - Overtemperature

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ◆ Wheel electronics contain batteries with lithium thionyl chloride.
- ◆ Do not disposed of these batteries in normal trash (see Environment Manual).
- ◆ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- while driving

Possible fault causes

- **Temperature Wheel electronics** > 120 °C (°F) (reversible)
- **Wheel electronics** Faulty

Fault effects

- ◆ No monitoring of the tire pressure for the affected wheel

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics Faulty

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ◆ Wheel electronics contain batteries with lithium thionyl chloride.
- ◆ Do not disposed of these batteries in normal trash (see Environment Manual).
- ◆ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- while driving

Possible fault causes

- **Wheel electronics** Faulty

NOTE

If **all 4 wheel electronics** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ◆ No monitoring of the tire pressure for the affected wheel
- ◆ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics - no Reception

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ♦ Wheel electronics contain batteries with lithium thionyl chloride.
- ♦ Do not disposed of these batteries in normal trash (see Environment Manual).
- ♦ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- Ignition on
- After a waiting time of approx. **10 min** / while driving

Possible fault causes

- none **Wheel electronics** installed
- incorrect component(s) **Wheel electronics** installed
- **Wheel electronics** Faulty

NOTE

If **all 4 wheel electronics** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics - Overtemperature

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ◆ Wheel electronics contain batteries with lithium thionyl chloride.
- ◆ Do not disposed of these batteries in normal trash (see Environment Manual).
- ◆ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- while driving

Possible fault causes

- **Temperature Wheel electronics** > 120 °C (°F) (reversible)
- **Wheel electronics** Faulty

Fault effects

- ◆ No monitoring of the tire pressure for the affected wheel

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics Faulty

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ♦ Wheel electronics contain batteries with lithium thionyl chloride.
- ♦ Do not disposed of these batteries in normal trash (see Environment Manual).
- ♦ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- while driving

Possible fault causes

- **Wheel electronics** Faulty

NOTE

If **all 4 wheel electronics** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics - no Reception

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ◆ Wheel electronics contain batteries with lithium thionyl chloride.
- ◆ Do not disposed of these batteries in normal trash (see Environment Manual).
- ◆ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- Ignition on
- After a waiting time of approx. **10 min** / while driving

Possible fault causes

- none **Wheel electronics** installed
- incorrect component(s) **Wheel electronics** installed
- **Wheel electronics** Faulty

NOTE

If **all 4 wheel electronics** are entered as a fault code, the cause may be a fault in the **TPM control unit**.

Fault effects

- ◆ No monitoring of the tire pressure for the affected wheel
- ◆ Warning light **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Wheel electronics - Overtemperature

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ◆ Wheel electronics contain batteries with lithium thionyl chloride.
- ◆ Do not disposed of these batteries in normal trash (see Environment Manual).
- ◆ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- while driving

Possible fault causes

- **Temperature Wheel electronics** > 120 °C (°F) (reversible)
- **Wheel electronics** Faulty

Fault effects

- ◆ No monitoring of the tire pressure for the affected wheel

Diagnosis information - Tire pressure monitoring system control module

Radio interference

Diagnostic conditions

- while driving (to approx. **9 min**)

Possible fault causes

- More than one wheel electronics unit transmits from the specified position. This can be caused by transporting a wheel in the vehicle, for example.
- Radio interference, e.g. due to other radio-transmitting components (wireless headphones, etc.)

Fault effects

- ♦ No monitoring of the tire pressure for the affected wheel
- ♦ Warning light **Tire Pressure Monitoring (TPM)**

C11005

Diagnosis information - Tire pressure monitoring system control module

Control module Faulty

Diagnostic conditions

- Ignition on

Possible fault causes

- Tire pressure monitoring system control module Faulty

Fault effects

- ♦ none Tire Pressure Monitoring (TPM)
- ♦ Warning light Tire Pressure Monitoring (TPM)