

Diagnostic information - Tire pressure monitoring system control module

No or incorrect coding

NOTE

Pollution of the environment if wheel electronics are not disposed of correctly.

- ◆ Wheel electronics contain batteries with lithium thionyl chloride.
- ◆ Do not disposed of these batteries in normal trash (see Environment Manual).
- ◆ Used or faulty wheel electronics must be brought to the specified return centers for batteries.

Diagnostic conditions

- **Control module** Tire Pressure Monitoring (TPM) - internal function test
- Ignition on
- Approx. 1 minute of driving

Fault setting condition(s)

- No or incorrect coding/parameters set for Tire Pressure Monitoring (TPM) control unit
- Tire Pressure Monitoring (TPM) control unit is in wrong mode (production) --> perform coding
- Tire Pressure Monitoring (TPM) control unit faulty

Fault effects

- ◆ System does not function
- ◆ Display on instrument cluster

Diagnosis information - Tire pressure monitoring system control module

Wheel set selection necessary

Diagnostic conditions

- while driving

Possible fault causes

- **Wheel electronics** new
- Position **Wheel electronics** interchanged

① After selection of the wheel set in the instrument cluster, the TPM system changes to learning mode and the new or replaced wheel electronics are learned and assigned.

Fault effects

- ♦ none **Tire Pressure Monitoring (TPM)**

Diagnosis information - Tire pressure monitoring system control module

Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- **Supply voltage** Limit exceeded (Voltage 60 s > 17.5 V)
- **Supply voltage** Below limit (Voltage 60 s < 9.0 V)

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Tire pressure monitoring system control module

Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- **Supply voltage** Limit exceeded (Voltage 60 s > 17.5 V)
- **Supply voltage** Below limit (Voltage 60 s < 9.0 V)

Fault effects

- ♦ Function not available or available only to a limited extent