

991 + 981 , MY 2012 =>

Diagnosis information - PSM

004000.....	1
004008.....	2
004010.....	3
004020.....	4
004030.....	5
004031.....	6
004040.....	7
004200.....	8
004201.....	9
004202.....	10
004203.....	11
004210.....	12
004211.....	13
004212.....	14
004213.....	15
004220.....	16
004221.....	17
004222.....	18
004223.....	19
004230.....	20
004231.....	21
004232.....	22
004233.....	23
004240.....	24
004340.....	25
005000.....	26
005070.....	27
006000.....	28
007000.....	29
00C058.....	30
0C1106.....	31
B20050.....	32
C11002.....	33
C11003.....	34
C11004.....	35
C11005.....	36
C11006.....	37
C11007.....	38
C12187.....	39

D10000.....	40
EA6100.....	41
EA6200.....	42
EA6300.....	43
EA6400.....	44

Diagnosis information - PSM

PSM hydraulic unit - Function restriction

INFORMATION

The faults treated here are caused by faulty components or malfunctions within the hydraulic unit.

Diagnostic conditions

There are several fault paths for the faults in the hydraulic unit. This means that several diagnostic conditions can result in the existing fault entry.

- to Ignition on
- All models: 60 seconds to Ignition on
- while driving (**Vehicle speed** > 30 km/h)

Fault setting condition(s)

- Power supply Short circuit to B+/ground/between lines or open circuit in the lines
- Fuses **PSM hydraulic unit** Faulty
- Ventil unit overheated (Overload / reversible)
- **Sensor** Brake pressure Faulty
- Ventil unit Faulty
- **Hydraulic pump** Faulty

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

CAN bus Fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- ♦ Loose contact or corrosion on connectors or lines
- ♦ **CAN high / CAN low**
Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ none or Limited function PSM

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PSM

PSM hydraulic unit - Function restriction

INFORMATION

The faults treated here are caused by faulty components or malfunctions within the hydraulic unit.

Diagnostic conditions

There are several fault paths for the faults in the hydraulic unit. This means that several diagnostic conditions can result in the existing fault entry.

- to Ignition on
- All models: 60 seconds to Ignition on
- while driving (**Vehicle speed** > 30 km/h)

Fault setting condition(s)

- Power supply Short circuit to B+/ground/between lines or open circuit in the lines
- Fuses **PSM hydraulic unit** Faulty
- Ventil unit overheated (Overload / reversible)
- **Sensor** Brake pressure Faulty
- Ventil unit Faulty
- **Hydraulic pump** Faulty

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM

PSM hydraulic unit - Function restriction

INFORMATION

The faults treated here are caused by faulty components or malfunctions within the hydraulic unit.

Diagnostic conditions

There are several fault paths for the faults in the hydraulic unit. This means that several diagnostic conditions can result in the existing fault entry.

- to Ignition on
- All models: 60 seconds to Ignition on
- while driving (**Vehicle speed** > 30 km/h)

Fault setting condition(s)

- Power supply Short circuit to B+/ground/between lines or open circuit in the lines
- Fuses **PSM hydraulic unit** Faulty
- Ventil unit overheated (Overload / reversible)
- **Sensor** Brake pressure Faulty
- Ventil unit Faulty
- **Hydraulic pump** Faulty

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM

PSM hydraulic unit - Function restriction

INFORMATION

The faults treated here are caused by faulty components or malfunctions within the hydraulic unit.

Diagnostic conditions

There are several fault paths for the faults in the hydraulic unit. This means that several diagnostic conditions can result in the existing fault entry.

- to Ignition on
- All models: 60 seconds to Ignition on
- while driving (**Vehicle speed** > 30 km/h)

Fault setting condition(s)

- Power supply Short circuit to B+/ground/between lines or open circuit in the lines
- Fuses **PSM hydraulic unit** Faulty
- Ventil unit overheated (Overload / reversible)
- **Sensor** Brake pressure Faulty
- Ventil unit Faulty
- **Hydraulic pump** Faulty

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM

PSM hydraulic unit - Function restriction

INFORMATION

The faults treated here are caused by faulty components or malfunctions within the hydraulic unit.

Diagnostic conditions

There are several fault paths for the faults in the hydraulic unit. This means that several diagnostic conditions can result in the existing fault entry.

- to Ignition on
- All models: 60 seconds to Ignition on
- while driving (**Vehicle speed** > 30 km/h)

Fault setting condition(s)

- Power supply Short circuit to B+/ground/between lines or open circuit in the lines
- Fuses **PSM hydraulic unit** Faulty
- Ventil unit overheated (Overload / reversible)
- **Sensor** Brake pressure Faulty
- Ventil unit Faulty
- **Hydraulic pump** Faulty

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM

PSM hydraulic unit - Function restriction

INFORMATION

The faults treated here are caused by faulty components or malfunctions within the hydraulic unit.

Diagnostic conditions

There are several fault paths for the faults in the hydraulic unit. This means that several diagnostic conditions can result in the existing fault entry.

- to Ignition on
- All models: 60 seconds to Ignition on
- while driving (**Vehicle speed** > 30 km/h)

Fault setting condition(s)

- Power supply Short circuit to B+/ground/between lines or open circuit in the lines
- Fuses **PSM hydraulic unit** Faulty
- Ventil unit overheated (Overload / reversible)
- **Sensor** Brake pressure Faulty
- Ventil unit Faulty
- **Hydraulic pump** Faulty

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Speed sensor - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PSM control module

Speed sensor - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PSM control module

ABS control for affected wheel deactivated temporarily

INFORMATION

If electrical faults are stored for the rpm sensors, please remedy the electrical faults first before continuing with remedying the following faults.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- while driving

Fault setting condition(s)

Wheel was temporarily excluded from ABS control

- Incorrect signal or no signal from speed sensor
- Spinning of affected wheel detected
- Flat tire detected on affected wheel

NOTE

The fault can also be entered if a wheel loses contact with the road during a PSM control operation, e.g. as a result of an uneven road surface. The PSM control unit then blocks ABS control as a corrective measure for this one wheel for a short period of time since no roll-on movement of the wheel is registered following braking.

In this case, the fault is merely an indication of this event and does not indicate a possible implausible signal from the speed sensor.

Fault effects

- ♦ Temporary loss of ABS control for the affected wheel

Diagnosis information - PSM control module

Speed sensor - Mechanical fault

INFORMATION

If electrical faults are stored for the rpm sensors, please remedy the electrical faults first before continuing with remedying the following faults.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- while driving

Fault setting condition(s)

- **Speed sensor** installed incorrectly
- **Speed sensor** Faulty
- Wheel bearing installed incorrectly
- Wheel bearing (**Multi-pole ring**) Faulty
- Wheel carrier damaged
- **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Speed sensor - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PSM control module

Speed sensor - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PSM control module

ABS control for affected wheel deactivated temporarily

INFORMATION

If electrical faults are stored for the rpm sensors, please remedy the electrical faults first before continuing with remedying the following faults.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- while driving

Fault setting condition(s)

Wheel was temporarily excluded from ABS control

- Incorrect signal or no signal from speed sensor
- Spinning of affected wheel detected
- Flat tire detected on affected wheel

NOTE

The fault can also be entered if a wheel loses contact with the road during a PSM control operation, e.g. as a result of an uneven road surface. The PSM control unit then blocks ABS control as a corrective measure for this one wheel for a short period of time since no roll-on movement of the wheel is registered following braking.

In this case, the fault is merely an indication of this event and does not indicate a possible implausible signal from the speed sensor.

Fault effects

- ♦ Temporary loss of ABS control for the affected wheel

Diagnosis information - PSM control module

Speed sensor - Mechanical fault

INFORMATION

If electrical faults are stored for the rpm sensors, please remedy the electrical faults first before continuing with remedying the following faults.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- while driving

Fault setting condition(s)

- **Speed sensor** installed incorrectly
- **Speed sensor** Faulty
- Wheel bearing installed incorrectly
- Wheel bearing (**Multi-pole ring**) Faulty
- Wheel carrier damaged
- **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Speed sensor - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PSM control module

Speed sensor - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PSM control module

ABS control for affected wheel deactivated temporarily

INFORMATION

If electrical faults are stored for the rpm sensors, please remedy the electrical faults first before continuing with remedying the following faults.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- while driving

Fault setting condition(s)

Wheel was temporarily excluded from ABS control

- Incorrect signal or no signal from speed sensor
- Spinning of affected wheel detected
- Flat tire detected on affected wheel

NOTE

The fault can also be entered if a wheel loses contact with the road during a PSM control operation, e.g. as a result of an uneven road surface. The PSM control unit then blocks ABS control as a corrective measure for this one wheel for a short period of time since no roll-on movement of the wheel is registered following braking.

In this case, the fault is merely an indication of this event and does not indicate a possible implausible signal from the speed sensor.

Fault effects

- ♦ Temporary loss of ABS control for the affected wheel

Diagnosis information - PSM control module

Speed sensor - Mechanical fault

INFORMATION

If electrical faults are stored for the rpm sensors, please remedy the electrical faults first before continuing with remedying the following faults.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- while driving

Fault setting condition(s)

- **Speed sensor** installed incorrectly
- **Speed sensor** Faulty
- Wheel bearing installed incorrectly
- Wheel bearing (**Multi-pole ring**) Faulty
- Wheel carrier damaged
- **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Speed sensor - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PSM control module

Speed sensor - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Sensor** Faulty
- ♦ **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PSM control module

ABS control for affected wheel deactivated temporarily

INFORMATION

If electrical faults are stored for the rpm sensors, please remedy the electrical faults first before continuing with remedying the following faults.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- while driving

Fault setting condition(s)

Wheel was temporarily excluded from ABS control

- Incorrect signal or no signal from speed sensor
- Spinning of affected wheel detected
- Flat tire detected on affected wheel

NOTE

The fault can also be entered if a wheel loses contact with the road during a PSM control operation, e.g. as a result of an uneven road surface. The PSM control unit then blocks ABS control as a corrective measure for this one wheel for a short period of time since no roll-on movement of the wheel is registered following braking.

In this case, the fault is merely an indication of this event and does not indicate a possible implausible signal from the speed sensor.

Fault effects

- ♦ Temporary loss of ABS control for the affected wheel

Diagnosis information - PSM control module

Speed sensor - Mechanical fault

INFORMATION

If electrical faults are stored for the rpm sensors, please remedy the electrical faults first before continuing with remedying the following faults.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- while driving

Fault setting condition(s)

- **Speed sensor** installed incorrectly
- **Speed sensor** Faulty
- Wheel bearing installed incorrectly
- Wheel bearing (**Multi-pole ring**) Faulty
- Wheel carrier damaged
- **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Speed sensor - Signal implausible

INFORMATION

This fault is set if one or more rpm sensors supply an implausible signal. Therefore, first check the fault memory of the PSM control unit for faults of the individual rpm sensors and remedy them before continuing with this general collective fault.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- while driving

Fault setting condition(s)

- **Speed sensor** installed incorrectly
- **Speed sensor** Short circuit to B+/ground/between lines or open circuit in the lines
- **Speed sensor** Faulty
- Wheel bearing installed incorrectly
- Wheel bearing (**Multi-pole ring**) Faulty
- **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM

Stop light switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- **PSM control module** internal function test
- Actuate foot brake and then release it again

Fault setting condition(s)

- Adjustment of the **Stop light switch** not OK ⇒ See Workshop Manual (Incorrect operation: pedal pushed/pulled up)
- System not bled
- Mechanism of the **Stop light switch** not OK
- Short circuit to B+/ground or open circuit in the line
- **DME control module** Function restriction

❗ The measured value >Brake light switch (CAN, DME)< can also be used to test the signal.

Diagnosis information - PSM control module

Combination sensor - CAN bus Fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- ♦ Loose contact or corrosion on connectors or lines
- ♦ **Combination sensor CAN high / CAN low**
Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ none or Limited function PSM

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PSM control module

Wiring harness - Electrical fault

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Nominal values Line test

Short circuit to B+ :

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - PSM control module

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- incorrectly programmed
- not programmed

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Network diagnostics fault (NWDF)

❗ The NWDF state is set by the gateway control unit in certain situations, e.g. during an engine restart from a start/stop situation. The purpose of the state is to suppress faults occurring during this NWDF phase, e.g. overvoltage errors during a restart.
If a fault occurs in an affected control unit during the NWDF phase, the actual fault is not set. The DWDF substitute fault for this is set instead.

Diagnostic conditions

- Ignition on
- Fault during NWDF state

Possible fault causes

- The NWDF substitute fault is set if the SWDF state is activated by the gateway control unit and a fault occurs in the respective control unit.

Fault effects

- ♦ none

Diagnosis information - PSM control module

Production mode

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- Production mode Active

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- No/incorrect coding

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- incorrectly programmed
- not programmed

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Temperature

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- **Temperature** Limit exceeded
- **Temperature** Below limit
- **Control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

C11003

Diagnosis information - PSM control module

Temperature

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- **Temperature** Limit exceeded
- **Temperature** Below limit
- **Control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- incorrectly programmed
- not programmed

Fault effects

- ♦ none or Limited function PSM

C11005

Diagnosis information - PSM control module

Control module Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- **Control module** Faulty

Fault effects

- ♦ none or Limited function PSM

C11006

Diagnosis information - PSM control module

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- No/incorrect coding

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Combination sensor Calibration

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- **Combination sensor** - No/incorrect calibration
- **PSM control module** incorrectly coded

Fault effects

- ♦ none or Limited function PSM