

Diagnosis information - PSM control module

Combination sensor - Signal implausible

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- while driving

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Combination sensor** Faulty
- ♦ **PSM control module** Function restriction

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Airbag triggering unit - Fault memory Check

INFORMATION

Faults for component protection of the airbag triggering unit are stored in the PSM control units. To remedy faults, check the fault memory of the airbag triggering unit and remedy the faults.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- Fault Airbag triggering unit
- **PSM control module** incorrectly coded

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Airbag triggering unit - Fault memory Check

INFORMATION

Faults for component protection of the airbag triggering unit are stored in the PSM control units. To remedy faults, check the fault memory of the airbag triggering unit and remedy the faults.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- Fault Airbag triggering unit
- **PSM control module** incorrectly coded

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Airbag triggering unit - Fault memory Check

INFORMATION

Faults for component protection of the airbag triggering unit are stored in the PSM control units. To remedy faults, check the fault memory of the airbag triggering unit and remedy the faults.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- Fault Airbag triggering unit
- **PSM control module** incorrectly coded

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Airbag triggering unit - Fault memory Check

INFORMATION

Faults for component protection of the airbag triggering unit are stored in the PSM control units. To remedy faults, check the fault memory of the airbag triggering unit and remedy the faults.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- Fault Airbag triggering unit
- **PSM control module** incorrectly coded

Fault effects

- ♦ none or Limited function PSM

Diagnosis information - PSM control module

Airbag triggering unit - Fault memory Check

INFORMATION

Faults for component protection of the airbag triggering unit are stored in the PSM control units. To remedy faults, check the fault memory of the airbag triggering unit and remedy the faults.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- Fault Airbag triggering unit
- **PSM control module** incorrectly coded

Fault effects

- ♦ none or Limited function PSM