

991 + 981 , MY 2012 =>

Diagnosis information - Power steering

00C058.....	1
010000.....	2
010002.....	3
010003.....	4
010010.....	5
010011.....	6
010012.....	7
010013.....	8
010014.....	9
010015.....	10
010019.....	11
01001A.....	12
01001B.....	13
01001C.....	14
01001D.....	15
01001E.....	16
01001F.....	17
010020.....	18
010021.....	19
010022.....	20
010024.....	21
010025.....	22
010026.....	23
010027.....	24
01002A.....	25
01002B.....	26
01002C.....	27
01002D.....	28
01002E.....	29
01002F.....	30
010030.....	31
010031.....	32
010032.....	33
010033.....	34
010050.....	35
010065.....	36
020000.....	37
020001.....	38
020002.....	39

C11006.....

Diagnosis information - Power steering

Production mode Active

Diagnostic conditions

- Ignition on or Engine running

Possible fault causes

- ♦ Production mode Active

Fault setting condition(s)

- Production mode Active switched

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

010000

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

Diagnosis information - Power steering

Steering stops

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Steering stops not taught
- ♦ Steering stops incorrect taught

Fault effects

none or Limited function Power steering

Diagnosis information - Power steering

Signal Steering-angle sensor

INFORMATION

The steering angle calculated in the power steering control unit does not match the steering angle of the steering-angle sensor in the steering-wheel electronics control unit received via CAN.

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Axle geometry (**Front axle** / Rear axle) incorrectly set
- ♦ **Steering-angle sensor** incorrect or not calibrated
- ♦ Fault entry **Steering wheel electronics control module**
- ♦ **Steering-angle sensor** Faulty
- ♦ **Control module** Power steering Function restriction

Fault effects

none or Limited function Power steering

Diagnosis information - Power steering

Lead Terminal 15 - Electrical fault

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running

Possible fault causes

- ♦ Terminal 15 Lead : Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ **Control module** Power steering Function restriction

Fault effects

none or Limited function Power steering

Diagnosis information - Power steering

Steering stops

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Steering stops not taught
- ♦ Steering stops incorrect taught

Fault effects

none or Limited function Power steering