

991/ 981, MY 2012 =>

Diagnosis information - Passenger's door

0003.....	1
0214.....	2
0398.....	3
0412.....	4
0840.....	5
0841.....	6
0843.....	7
0844.....	8
0845.....	9
0846.....	10
0847.....	11
0848.....	12
0851.....	13
0852.....	14
006E.....	15
01BE.....	16
01BF.....	17
053C.....	18
05CA.....	19
083E.....	20
083F.....	21
084A.....	22
084B.....	23
084C.....	24
084E.....	25
084F.....	26
0C67.....	27
0CE1.....	28
0D25.....	29

Diagnostic information - Door control unit

Control unit faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, delete the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

Control unit faulty

Fault effects

Function not available or available only to a limited extent

Diagnostic information - Door control unit

Power supply

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, delete the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Power supply - below limit value - 9 V
- Power supply - above limit value - 16 V

Fault effects

- ♦ It may no longer be possible to activate the actuators

Diagnostic information

Mirror heating, driver

INFORMATION

This fault was detected by the driver door control unit.

Diagnostic conditions

- Ignition on
- Battery voltage OK (11.4 to 14.5 V)
- Internal function test on driver door control unit
- Engine on
- Switch on mirror heating

Possible fault causes

- ♦ Mirror heating in door mirror glass faulty
- ♦ Lines faulty

Function restrictions

- ♦ No function or restricted function

Diagnostic information - Door control unit

No/incorrect coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, delete the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Coding incorrect or not carried out

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnostic information - Door control unit

Power windows motor - thermal protection active

Diagnostic conditions

- Ignition on
- Power windows switch actuated

Possible fault causes

- ♦ Window guides stiff
- ♦ Frequent actuation of power windows switch

Fault setting condition(s)

- Power windows motor, temperature too high

Fault effects

- ♦ Function available to a limited extent; power windows can still only be moved towards open

Diagnostic information - Door

Central locking system button - signal implausible

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, delete the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Button pressed > 60 second(s)
- Short circuit to ground

Fault effects

- ♦ Central locking system button does not work

Diagnostic information - door control unit

05CA - Central locking motors, short circuit to B+

0843 - Central locking closing unit, implausible signal

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Central locking system actuated

Fault setting condition(s)

- Short circuit to B+
- Signal implausible

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the lines to the central locking motor
- ♦ Central locking motor faulty
- ♦ Door control unit faulty

Fault effects

- ♦ No function

Diagnostic information

Door mirror adjusting motor

Diagnostic conditions

- Ignition on
- Battery positive voltage OK (11.4 to 14.5 V)
- Internal function test on door control unit
- Door mirror actuated with the mirror adjustment switch

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the lines
- ♦ Door mirror adjusting motor faulty
- ♦ Door control unit faulty

Diagnostic information

Door mirror folding motor

Diagnostic conditions

- Ignition on
- Battery positive voltage OK (11.4 to 14.5 V)
- Door mirror folding function active

Possible fault causes

- ♦ Folding mirror mechanically stiff/blocked
- ♦ Door mirror folding motor faulty
- ♦ Door control unit faulty

Diagnostic information

Door mirror adjusting motor

Diagnostic conditions

- Ignition on
- Battery positive voltage OK (11.4 to 14.5 V)
- Internal function test on door control unit
- Door mirror actuated with the mirror adjustment switch

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the lines
- ♦ Door mirror adjusting motor faulty
- ♦ Door control unit faulty

Diagnostic information

Door mirror adjusting motor

Diagnostic conditions

- Ignition on
- Battery positive voltage OK (11.4 to 14.5 V)
- Internal function test on door control unit
- Door mirror actuated with the mirror adjustment switch

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the lines
- ♦ Door mirror adjusting motor faulty
- ♦ Door control unit faulty

Diagnostic information - Control unit

Button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, delete the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- ♦ The button is stuck or permanently actuated.

Fault effects

- ♦ The affected function no longer reacts

Diagnostic information - Door control unit

Exterior mirror dimming - electrical fault

Diagnostic conditions

- Ignition on
- Automatic dimming active

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line

Function restrictions

- ♦ No function or restricted function

Diagnosis information - Control module

Lamp

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Short circuit to ground
- Open circuit
- Short circuit between the lines
- Faulty

Fault effects

- Light does not function

Diagnostic information - Door control unit

Lamp for mirror indicator

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, delete the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Short circuit to B+/ground or open circuit
- Faulty

Fault effects

- ♦ Lamp does not function

Diagnostic information - Door control unit

Power supply

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, delete the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Power supply - below limit value - 9 V
- Power supply - above limit value - 16 V

Fault effects

- ♦ It may no longer be possible to activate the actuators

Diagnostic information - Door control unit

Power supply

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, delete the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Power supply - below limit value - 9 V
- Power supply - above limit value - 16 V

Fault effects

- ♦ It may no longer be possible to activate the actuators

Diagnostic information - Control unit

Button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, delete the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- ♦ The button is stuck or permanently actuated.

Fault effects

- ♦ The affected function no longer reacts

Diagnostic information - door control unit

05CA - Central locking motors, short circuit to B+
0843 - Central locking closing unit, implausible signal

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Central locking system actuated

Fault setting condition(s)

- Short circuit to B+
- Signal implausible

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the lines to the central locking motor
- ♦ Central locking motor faulty
- ♦ Door control unit faulty

Fault effects

- ♦ No function

Diagnostic information - Control unit

Driver power window button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, delete the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- ♦ The button is stuck or permanently actuated.

Fault effects

- ♦ The window cannot be opened or closed

Diagnostic information - Door control unit

Power windows motor - mechanical fault

Diagnostic conditions

- Ignition on
- Supply voltage > 12 V
- Power windows switch actuated

Possible fault causes

- ♦ Window guides stiff
- ♦ Power windows mechanism stiff

Diagnostic information - Control unit

Button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, delete the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- ♦ The button is stuck or permanently actuated.

Fault effects

- ♦ The affected function no longer reacts

Diagnosis information - Component(s)

Function light

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Open circuit
- Faulty

Fault effects

Light does not function

084C

Diagnostic information - door control unit

084C - Outer door handle switch, continuously actuated

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- The button is stuck or permanently actuated

Possible fault causes

- ♦ The button is stuck or permanently actuated
- ♦ Short circuit to ground

Fault effects

- ♦ No function

Diagnostic information - door control unit

084C - Outer door handle switch, continuously actuated

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- The button is stuck or permanently actuated

Possible fault causes

- ♦ The button is stuck or permanently actuated
- ♦ Short circuit to ground

Fault effects

- ♦ No function

Diagnosis information - Component(s)

Function light

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Open circuit
- Faulty

Fault effects

Light does not function

Diagnostic information - Door control unit

Data record invalid

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, delete the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Control unit data record faulty or incorrect

Possible fault causes

- ♦ Incorrect data record programmed
- ♦ Data record faulty

Fault effects

- ♦ Restricted door functionality

Diagnosis information - Control module

Lock cylinder

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault setting condition(s)

The button is stuck or permanently actuated.

Fault effects

No function

Diagnosis information - Control module

Lamp

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Short circuit to ground
- Open circuit
- Short circuit between the lines
- Faulty

Fault effects

- Light does not function