

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Drive **Motor, sliding roof**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive Engine

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Drive **Motor, sliding roof**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive Engine

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Drive **Motor, sliding roof**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive Engine

Fault effects

The affected function no longer reacts

Diagnosis information - Control module

Control unit faulty

WARNING

- ♦ Danger of injury and crushing when components are moved.
- ♦ Open or close the rear lid only if there are neither persons, animals nor objects in the movement range of the lid.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

Control unit faulty

Fault effects

Function not available or available only to a limited extent

84030E

Diagnosis information - Component(s)

Function light

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Open circuit
- Faulty

Fault effects

Light does not function

Diagnosis information - Component(s)

Function light

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Open circuit
- Faulty

Fault effects

Light does not function

Diagnosis information - Control module

Temperature

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- **Device temperature** - Limit exceeded
- **Device temperature** - Below limit

Fault effects

Function not available or available only to a limited extent

Diagnosis information - Component(s)

Button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

The button is stuck or permanently actuated.

Fault effects

The affected function no longer reacts

Diagnosis information - Component(s)

Button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

The button is stuck or permanently actuated.

Fault effects

The affected function no longer reacts

Diagnosis information - Component(s)

Button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

The button is stuck or permanently actuated.

Fault effects

The affected function no longer reacts

Diagnosis information - Component(s)

Button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

The button is stuck or permanently actuated.

Fault effects

The affected function no longer reacts

Diagnosis information - Component(s)

Button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

The button is stuck or permanently actuated.

Fault effects

The affected function no longer reacts

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

High-volume horn for alarm system

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Lines/connections
- **High-volume horn for alarm system**

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Convertible top control module

Convertible-top drive

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Current Too high
- ♦ Current too low

Fault effects

- none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Latching hook

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Current Too high
- ♦ Current too low

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function

Diagnosis information - Rear-end electronics

Light bulb

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Light bulb Faulty
- **Power supply** Faulty
- Ground supply Faulty
- Light unit Faulty

Fault effects

Light does not function