

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

Diagnosis information - Component(s)

Button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

The button is stuck or permanently actuated.

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Electronic steering column lock (ELV) ELV enable line

Diagnostic conditions

- The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Below limit
- ELV enable line, Short circuit to ground
- ELV enable line, Short circuit to B+
- ELV enable line, Open circuit

Fault effects

Electronic steering column lock (ELV) No function

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Short circuit between lines :

- ♦ Setpoint resistance **> 0.9 MOhm**

Diagnosis information - Rear-end electronics

Electronic steering column lock (ELV) ELV enable line

Diagnostic conditions

- The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Below limit
- ELV enable line, Short circuit to ground
- ELV enable line, Short circuit to B+
- ELV enable line, Open circuit

Fault effects

Electronic steering column lock (ELV) No function

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Short circuit between lines :

- ♦ Setpoint resistance **> 0.9 MOhm**

Diagnosis information - Rear-end electronics

Electronic steering column lock (ELV) ELV enable line

Diagnostic conditions

- The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Below limit
- ELV enable line, Short circuit to ground
- ELV enable line, Short circuit to B+
- ELV enable line, Open circuit

Fault effects

Electronic steering column lock (ELV) No function

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Short circuit between lines :

- ♦ Setpoint resistance **> 0.9 MOhm**

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

8C1005

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

8C110E

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

8C200B

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

8C210B

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

8C220C

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

8C230C

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

8C240C

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

8C260E

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

8C270E

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

Diagnosis information - Rear-end electronics

Sun blind motor drive mechanism

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive Engine

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Drive **Air deflector**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive **Air deflector** Engine
- **Control module Air deflector**
- No/incorrect calibration **Air deflector**

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Wiring harness Front spoiler, pneumatic - Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- No pressure increase/decrease in the system
- Pressure too high
- Loss of pressure

Fault effects

- Function not available or available only to a limited extent

Possible fault causes

1. Leak in the **System**
2. **Connecting hose/line** Blocked

8E0108

Diagnosis information - Rear-end electronics

8E0108 Linear sensor Front spoiler - Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Linear sensor sends fault value
- Power supply Faulty
- Signal voltage: Outside the valid value range ($0.2\text{ V} < u < 4.8\text{ V}$)

Fault effects

- Function not available or available only to a limited extent

Possible fault causes

1. In general: Loose contact or corrosion on connectors or lines
2. Power supply: Short circuit to B+/ground or open circuit in the line
3. Signal lead: Short circuit to B+/ground or open circuit in the line

Diagnosis information - Rear-end electronics

Pressure sensors Front spoiler - Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- **Pressure sensor** , Signal implausible

Fault effects

- Function not available or available only to a limited extent

Possible fault causes

1. **Pressure sensor** Faulty
2. Short circuit to B+/ground or open circuit in the line

Diagnosis information - Rear-end electronics

Valve Front spoiler - Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- No pressure increase/decrease in the system
- Valve No function

Fault effects

- Function not available or available only to a limited extent

Possible fault causes

1. Valve Faulty
2. Short circuit to B+/ground or open circuit in the line

Diagnosis information - Rear-end electronics

Compressor Front spoiler - Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- No pressure increase/decrease in the system
- **Compressor** No function

Fault effects

- Function not available or available only to a limited extent

Possible fault causes

1. **Compressor** blocked / Faulty
2. Short circuit to B+/ground or open circuit in the line

8E0608

Diagnosis information - Rear-end electronics

8E0608 Linear sensor Front spoiler - Malfunction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Linear sensor, Value implausible

Fault effects

- Function not available or available only to a limited extent

Possible fault causes

1. Linear sensor not adjusted correctly
2. **Front spoiler** blocked / jammed

Nominal values Linear sensor:

- Spoiler position: retracted
- Linear-sensor value: approx. 90%

C11000

Diagnosis information - Rear-end electronics

Rear-end electronics power supply

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Short circuit to ground
- Short circuit to B+
- Short circuit between the lines
- Faulty

Fault effects

The affected function no longer reacts

C11001

Diagnosis information - Rear-end electronics

Rear-end electronics power supply

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Short circuit to ground
- Short circuit to B+
- Short circuit between the lines
- Faulty

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Control module Rear-end electronics, Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Rear-end electronics** No/incorrect coding
- ♦ **Control module Rear-end electronics** Faulty

C11005

Diagnosis information - Rear-end electronics

Rear-end electronics Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault effects

- **Rear-end electronics** No function

Diagnostic information - Rear-end electronics

Production mode active/Coding Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault setting condition(s)

- One or more production modes or production interventions are activated.
- No/incorrect coding
- **Rear-end electronics** control unit faulty

Fault effects

- ♦ Comfort functions: Function not available or available only to a limited extent

Diagnosis information - Rear-end electronics

Rear-end electronics Calibration

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault setting condition(s)

- **Panorama roof system**, Calibration incorrect or not carried out
- **Rear spoiler**, Calibration incorrect or not carried out
- **Roof console Control module Rear-end electronics** incomplete taught
- **Control module Rear-end electronics** not taught (**Control module Rear-end electronics** new)

► In the >PIWIS Tester II< ⇒ >Diagnostics< ⇒ Rear-end electronics => Drive links/tests => Teaching <, perform the respective **standardization/calibration/teaching** operations.

Fault effects

- ♦ Function not available or available only to a limited extent

C13006

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.