

C13010

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

C13012

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

C13013

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Drive **Motor, sliding roof**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive Engine

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Sun blind motor drive mechanism

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive Engine

Fault effects

The affected function no longer reacts

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

C13035

Diagnosis information - Rear-end electronics

Drive **Air deflector**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive **Air deflector** Engine
- **Control module Air deflector**
- No/incorrect calibration **Air deflector**

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Front-spoiler control unit, Communication (LIN bus 2)

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- no communication with **Front-spoiler control unit** for $t > 4$ s

Fault effects

- **Front spoiler** No function

Possible fault causes

1. In general: Loose contact or corrosion on connectors or lines
2. Power supply Short circuit to B+/ground/between lines or open circuit in the lines
3. LIN bus 2: Short circuit to B+/ground or open circuit in the line
4. **Front-spoiler control unit**: Faulty

C13106

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Drive **Motor, sliding roof**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive Engine

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Sun blind motor drive mechanism

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive Engine

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Drive **Air deflector**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive **Air deflector** Engine
- **Control module Air deflector**
- No/incorrect calibration **Air deflector**

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Front-spoiler control unit, Function restriction (LIN bus 2)

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- **Front-spoiler control unit**, Implausible signal

Fault effects

- **Front spoiler** No function

Possible fault causes

- **Front-spoiler control unit**, Faulty

C13206

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

C13210

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

C13213

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Drive **Motor, sliding roof**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive Engine

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Sun blind motor drive mechanism

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive Engine

Fault effects

The affected function no longer reacts

C13232

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Drive **Air deflector**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive **Air deflector** Engine
- **Control module Air deflector**
- No/incorrect calibration **Air deflector**

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Front-spoiler control unit, Communication (LIN bus 2)

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- no communication with **Front-spoiler control unit** for $t > 4$ s

Fault effects

- **Front spoiler** No function

Possible fault causes

1. In general: Loose contact or corrosion on connectors or lines
2. Power supply Short circuit to B+/ground/between lines or open circuit in the lines
3. LIN bus 2: Short circuit to B+/ground or open circuit in the line
4. **Front-spoiler control unit**: Faulty

C13306

Diagnosis information - Rear-end electronics

NOTE

For vehicles with **Porsche Vehicle Tracking System (PVTS)**, see **Tequipment (TEQ) instructions**, main group **9063**!

► This fault code relates to the **Porsche Vehicle Tracking System (PVTS)**.
More information is available in attached documents or from the respective service provider.

C13310

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

C13312

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

C13313

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Drive **Motor, sliding roof**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive Engine

Fault effects

The affected function no longer reacts

C13332

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

C13335

Diagnosis information - Rear-end electronics

Drive **Air deflector**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Mechanical fault
- Drive **Air deflector** Engine
- **Control module Air deflector**
- No/incorrect calibration **Air deflector**

Fault effects

The affected function no longer reacts

Diagnosis information - Rear-end electronics

Front-spoiler control unit, Communication (LIN bus 2)

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- no communication with **Front-spoiler control unit** for $t > 4$ s

Fault effects

- **Front spoiler** No function

Possible fault causes

1. In general: Loose contact or corrosion on connectors or lines
2. Power supply Short circuit to B+/ground/between lines or open circuit in the lines
3. LIN bus 2: Short circuit to B+/ground or open circuit in the line
4. **Front-spoiler control unit**: Faulty

C13412

Diagnosis information - Component(s)

LIN user

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

No signal/communication

Fault effects

The affected function no longer reacts

Diagnosis information - LIN bus Master

LIN master - no communication

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault setting condition(s)

- Communication on the LIN bus was cancelled.

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line
- ♦ Cancellation of communication due to detected bit error

Fault effects

- ♦ Functions in the control unit are available only with restrictions.
- ♦ Functions in the control unit are not available.
- ♦ Fahrzeug übergreifende Funktionen sind nicht verfügbar.

Diagnosis information - LIN bus Master

LIN master - no communication

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault setting condition(s)

- Communication on the LIN bus was cancelled.

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line
- ♦ Cancellation of communication due to detected bit error

Fault effects

- ♦ Functions in the control unit are available only with restrictions.
- ♦ Functions in the control unit are not available.
- ♦ Fahrzeug übergreifende Funktionen sind nicht verfügbar.