

981 , MY 2013 =>

Diagnosis information - Convertible top

001001.....	1
001002.....	2
001002.....	3
001003.....	4
001004.....	5
001005.....	6
001006.....	7
001007.....	8
001007.....	9
001008.....	10
001009.....	11
00100A.....	12
00100B.....	13
00100C.....	14
00100D.....	15
00100E.....	16
00100F.....	17
001010.....	18
001011.....	19
00C058.....	20
B20050.....	21
B20050.....	22
C11000.....	23
C11001.....	24
C11002.....	25
C11003.....	26
C11004.....	27
C11004.....	28
C11005.....	29
C11006.....	30
C11007.....	31

Diagnosis information - Convertible top control module

Engine **left**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ thermo-protection Open circuit
- ♦ Current Too high, Short circuit to ground
- ♦ Current too low, Open circuit/short circuit to B+
- ♦ **Hall-effect sensor, Hall-effect sensor Power supply**

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Engine **left**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ thermo-protection Open circuit
- ♦ Current Too high, Short circuit to ground
- ♦ Current too low, Open circuit/short circuit to B+
- ♦ **Hall-effect sensor, Hall-effect sensor Power supply**

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Engine **right**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ thermo-protection Open circuit
- ♦ Current Too high, Short circuit to ground
- ♦ Current too low, Open circuit/short circuit to B+
- ♦ **Hall-effect sensor, Hall-effect sensor Power supply**

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Engine **left**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ thermo-protection Open circuit
- ♦ Current Too high, Short circuit to ground
- ♦ Current too low, Open circuit/short circuit to B+
- ♦ **Hall-effect sensor, Hall-effect sensor Power supply**

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Engine **left**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ thermo-protection Open circuit
- ♦ Current Too high, Short circuit to ground
- ♦ Current too low, Open circuit/short circuit to B+
- ♦ **Hall-effect sensor, Hall-effect sensor Power supply**

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Engine **left**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ thermo-protection Open circuit
- ♦ Current Too high, Short circuit to ground
- ♦ Current too low, Open circuit/short circuit to B+
- ♦ **Hall-effect sensor, Hall-effect sensor Power supply**

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Engine **right**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ thermo-protection Open circuit
- ♦ Current Too high, Short circuit to ground
- ♦ Current too low, Open circuit/short circuit to B+
- ♦ **Hall-effect sensor, Hall-effect sensor Power supply**

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Engine **right**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ thermo-protection Open circuit
- ♦ Current Too high, Short circuit to ground
- ♦ Current too low, Open circuit/short circuit to B+
- ♦ **Hall-effect sensor, Hall-effect sensor Power supply**

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Engine **left**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ thermo-protection Open circuit
- ♦ Current Too high, Short circuit to ground
- ♦ Current too low, Open circuit/short circuit to B+
- ♦ **Hall-effect sensor, Hall-effect sensor Power supply**

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Engine **right**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ thermo-protection Open circuit
- ♦ Current Too high, Short circuit to ground
- ♦ Current too low, Open circuit/short circuit to B+
- ♦ **Hall-effect sensor, Hall-effect sensor Power supply**

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Engine **right**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ thermo-protection Open circuit
- ♦ Current Too high, Short circuit to ground
- ♦ Current too low, Open circuit/short circuit to B+
- ♦ **Hall-effect sensor, Hall-effect sensor Power supply**

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Engine **right**

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ thermo-protection Open circuit
- ♦ Current Too high, Short circuit to ground
- ♦ Current too low, Open circuit/short circuit to B+
- ♦ **Hall-effect sensor, Hall-effect sensor Power supply**

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Convertible top raised microswitch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Convertible top raised microswitch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

none / Limited function **Convertible top**

Diagnosis information - Convertible top control module

Convertible top control module Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Control module Temperature** too high
- ♦ **Control module Temperature sensor, internal** faulty
- ♦ Internal control unit fault

Switch off ignition and again Switch on ignition
allow to cool down

Fault effects

No function **Convertible top**

Diagnosis information - Convertible top control module

Convertible top control module Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Control module Temperature** too high
- ♦ **Control module Temperature sensor, internal** faulty
- ♦ Internal control unit fault

Switch off ignition and again Switch on ignition
allow to cool down

Fault effects

No function **Convertible top**

Diagnosis information - Convertible top control module

Convertible top control module Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Control module Temperature** too high
- ♦ **Control module Temperature sensor, internal** faulty
- ♦ Internal control unit fault

Switch off ignition and again Switch on ignition
allow to cool down

Fault effects

No function **Convertible top**

Diagnosis information - Convertible top control module

Convertible top control module Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Control module Temperature** too high
- ♦ **Control module Temperature sensor, internal** faulty
- ♦ Internal control unit fault

Switch off ignition and again Switch on ignition
allow to cool down

Fault effects

No function **Convertible top**

Diagnosis information - Convertible top control module

Convertible top control module Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Control module Temperature** too high
- ♦ **Control module Temperature sensor, internal** faulty
- ♦ Internal control unit fault

Switch off ignition and again Switch on ignition
allow to cool down

Fault effects

No function **Convertible top**

Diagnosis information - Convertible top control module

Convertible top control module Production mode

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

Convertible top control module in the Production mode

Vehicle hand-over perform

Fault effects

No function **Convertible top**

Diagnosis information - Control module

Coding

WARNING

- ◆ Danger of injury and crushing when components are moved.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

Coding incorrect or not carried out

No/incorrect programming

Fault effects

Function not available or available only to a limited extent

Diagnosis information - Convertible top control module

Convertible top control module Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Programming incorrect or not carried out
- ♦ No/incorrect programming

Fault effects

No function **Convertible top**

C11000

Diagnosis information - Convertible top control module

Convertible top control module Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Control module Temperature** too high
- ♦ **Control module Temperature sensor, internal** faulty
- ♦ Internal control unit fault

Switch off ignition and again Switch on ignition
allow to cool down

Fault effects

No function **Convertible top**

C11001

Diagnosis information - Convertible top control module

Convertible top control module Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Control module Temperature** too high
- ♦ **Control module Temperature sensor, internal** faulty
- ♦ Internal control unit fault

Switch off ignition and again Switch on ignition
allow to cool down

Fault effects

No function **Convertible top**

Diagnosis information - Convertible top control module

Convertible top control module Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Control module Temperature** too high
- ♦ **Control module Temperature sensor, internal** faulty
- ♦ Internal control unit fault

Switch off ignition and again Switch on ignition
allow to cool down

Fault effects

No function **Convertible top**

C11003

Diagnosis information - Convertible top control module

Convertible top control module Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Control module Temperature** too high
- ♦ **Control module Temperature sensor, internal** faulty
- ♦ Internal control unit fault

Switch off ignition and again Switch on ignition
allow to cool down

Fault effects

No function **Convertible top**

Diagnosis information - Control module

Coding

WARNING

♦ Danger of injury and crushing when components are moved.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

Coding incorrect or not carried out

No/incorrect programming

Fault effects

Function not available or available only to a limited extent

Diagnosis information - Convertible top control module

Convertible top control module Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Programming incorrect or not carried out
- ♦ No/incorrect programming

Fault effects

No function **Convertible top**

C11005

Diagnosis information - Convertible top control module

Convertible top control module Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Control module Temperature** too high
- ♦ **Control module Temperature sensor, internal** faulty
- ♦ Internal control unit fault

Switch off ignition and again Switch on ignition
allow to cool down

Fault effects

No function **Convertible top**

Diagnosis information - Control module

Coding

WARNING

♦ Danger of injury and crushing when components are moved.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

Coding incorrect or not carried out

No/incorrect programming

Fault effects

Function not available or available only to a limited extent

Diagnosis information - Control module

No/incorrect calibration

WARNING

♦ Danger of injury and crushing when components are moved.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

Calibration incorrect or not carried out

Fault effects

Function not available or available only to a limited extent