

991 + 981 , MY 2012 =>

Diagnosis information - Airbag

000001.....	1
000002.....	3
000003.....	5
000004.....	7
000020.....	9
000101.....	11
000102.....	13
000103.....	15
000104.....	17
000120.....	19
000201.....	21
000202.....	23
000203.....	25
000204.....	27
000220.....	29
000301.....	31
000302.....	33
000303.....	35
000304.....	37
000320.....	39
000401.....	41
000402.....	43
000403.....	45
000404.....	47
000420.....	49
000501.....	51
000502.....	53
000503.....	55
000504.....	57
000520.....	59
000601.....	61
000602.....	63
000603.....	65
000604.....	67
000620.....	69
000701.....	71
000702.....	73
000703.....	75
000704.....	77

000720.....	79
000801.....	81
000802.....	83
000803.....	85
000804.....	87
000820.....	89
000901.....	91
000902.....	93
000903.....	95
000904.....	97
000920.....	99
000A01.....	101
000A02.....	103
000A03.....	105
000A04.....	107
000A20.....	109
000B01.....	111
000B02.....	113
000B03.....	115
000B04.....	117
000B20.....	119
000C01.....	121
000C02.....	123
000C03.....	125
000C04.....	127
000C20.....	129
000D01.....	131
000D02.....	133
000D03.....	135
000D04.....	137
000D20.....	139
000E01.....	141
000E02.....	143
000E03.....	145
000E04.....	147
000E20.....	149
000F01.....	151
000F02.....	153
000F03.....	155

000F04.....	157
000F20.....	159
001001.....	161
001002.....	163
001003.....	165
001004.....	167
001020.....	169
001201.....	171
001202.....	173
001203.....	175
001204.....	177
001220.....	179
001301.....	181
001302.....	183
001303.....	185
001304.....	187
001305.....	189
001401.....	191
001402.....	193
001403.....	195
001501.....	197
001502.....	199
001503.....	201
001504.....	203
001520.....	205
001601.....	207
001602.....	209
001603.....	211
001604.....	213
001620.....	215
001801.....	217
001802.....	219
001803.....	221
001804.....	223
001820.....	225
001C01.....	227
001C02.....	229
001C03.....	231
001C04.....	233

001C20.....	235
001D01.....	237
001D02.....	239
001D03.....	241
001D04.....	243
001D20.....	245
001E01.....	247
001E02.....	249
001E03.....	251
001E04.....	253
001E05.....	255
001F01.....	257
001F02.....	259
001F03.....	261
001F04.....	263
001F20.....	265
002002.....	267
002004.....	269
002005.....	271
002007.....	273
002020.....	275
002102.....	277
002104.....	279
002105.....	281
002107.....	283
002120.....	285
002302.....	287
002304.....	289
002305.....	291
002307.....	293
002320.....	295
002502.....	297
002504.....	299
002505.....	301
002507.....	303
002520.....	305
002602.....	307
002604.....	309
002605.....	311

002607.....	313
002620.....	315
002707.....	317
002802.....	319
002804.....	321
002805.....	323
002806.....	325
002807.....	327
002820.....	329
002902.....	331
002904.....	333
002905.....	335
002906.....	337
002907.....	339
002920.....	341
002A07.....	343
002B02.....	345
002B04.....	347
002B05.....	349
002B07.....	351
002B20.....	353
002C20.....	355
002D02.....	357
002D04.....	359
002D05.....	361
002D07.....	363
002D20.....	365
002E07.....	367
002E20.....	369
002E26.....	371
002E29.....	373
002E2A.....	375
002E2B.....	377
002E2C.....	379
002F07.....	381
002F20.....	383
002F26.....	385
002F29.....	387
002F2A.....	389

002F2B.....	391
002F2C.....	393
003005.....	395
003006.....	397
003007.....	399
003009.....	401
00300B.....	403
003020.....	405
003110.....	407
003205.....	409
003206.....	411
003207.....	413
003209.....	415
00320B.....	417
003220.....	419
003310.....	421
003405.....	423
003406.....	425
003407.....	427
003409.....	429
00340B.....	431
003420.....	433
003510.....	435
003610.....	437
003705.....	439
003706.....	441
003707.....	443
003709.....	445
00370B.....	447
003720.....	449
003810.....	451
003910.....	453
003A05.....	455
003A06.....	457
003A07.....	459
003A09.....	461
003A0B.....	463
003A20.....	465
003B10.....	467

003C10.....	469
003D05.....	471
003D06.....	473
003D07.....	475
003D09.....	477
003D0B.....	479
003D20.....	481
003E10.....	483
003F10.....	485
004005.....	487
004006.....	489
004007.....	491
004009.....	493
00400B.....	495
004020.....	497
004110.....	499
004205.....	501
004206.....	503
004207.....	505
004209.....	507
00420B.....	509
004220.....	511
004310.....	513
004405.....	515
004406.....	517
004407.....	519
004409.....	521
00440B.....	523
004420.....	525
004510.....	527
004605.....	529
004606.....	531
004607.....	533
004609.....	535
00460B.....	537
004620.....	539
004710.....	541
004901.....	543
004902.....	545

004D03.....	547
004E03.....	549
004F07.....	551
005008.....	552
005108.....	554
005208.....	556
005308.....	558
005408.....	560
005508.....	562
005608.....	564
00570A.....	566
006109.....	568
006111.....	570
006114.....	572
006115.....	574
006116.....	576
006118.....	578
00611E.....	580
00611F.....	582
006120.....	584
006121.....	586
006301.....	588
006302.....	590
006304.....	592
00631A.....	594
006401.....	596
006402.....	598
006404.....	600
00641B.....	602
006501.....	604
006502.....	606
006504.....	608
006507.....	610
006514.....	612
00702C.....	614
007032.....	616
007102.....	618
007120.....	620
00712D.....	622

007207.....	624
00721A.....	626
00722C.....	628
007232.....	630
00802E.....	632
00802F.....	633
008130.....	634
008231.....	636
008307.....	637
008407.....	638
008507.....	639
008607.....	640
001405.....	641
002202.....	643
002204.....	645
002205.....	647
002207.....	649
002220.....	651
002402.....	653
002404.....	655
002405.....	657
002407.....	659
002420.....	661
C11000.....	663
C11001.....	665
C11002.....	667
C11003.....	668
C11004.....	669
C11005.....	670
C11006.....	672
C11007.....	673

Diagnosis information - Airbag

Ignition circuit Driver's airbag Stage 1

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver's airbag Stage 1

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver's airbag Stage 1

⚠ WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver's airbag Stage 1

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver's airbag Stage 1

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver's airbag Stage 2

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

When you connect the test tool 5056/C and then switch the ignition on and off, the fault code for stage 2 is detected because there is no airbag unit connected to it. The fault code must be deleted after removal of test tool 5056/C and after performing the repair or must be processed in accordance with the corresponding instructions.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver's airbag Stage 2

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

When you connect the test tool 5056/C and then switch the ignition on and off, the fault code for stage 2 is detected because there is no airbag unit connected to it. The fault code must be deleted after removal of test tool 5056/C and after performing the repair or must be processed in accordance with the corresponding instructions.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver's airbag Stage 2

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

When you connect the test tool 5056/C and then switch the ignition on and off, the fault code for stage 2 is detected because there is no airbag unit connected to it. The fault code must be deleted after removal of test tool 5056/C and after performing the repair or must be processed in accordance with the corresponding instructions.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver's airbag Stage 2

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

When you connect the test tool 5056/C and then switch the ignition on and off, the fault code for stage 2 is detected because there is no airbag unit connected to it. The fault code must be deleted after removal of test tool 5056/C and after performing the repair or must be processed in accordance with the corresponding instructions.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver's airbag Stage 2

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

When you connect the test tool 5056/C and then switch the ignition on and off, the fault code for stage 2 is detected because there is no airbag unit connected to it. The fault code must be deleted after removal of test tool 5056/C and after performing the repair or must be processed in accordance with the corresponding instructions.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Passenger's airbag Stage 1

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Passenger's airbag Stage 1

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Passenger's airbag Stage 1

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Passenger's airbag Stage 1

⚠ WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Passenger's airbag Stage 1

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Passenger's airbag Stage 2

⚠ WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

When you connect the test tool 5056/C and then switch the ignition on and off, the fault code for stage 2 is detected because there is no airbag unit connected to it. The fault code must be deleted after removal of test tool 5056/C and after performing the repair or must be processed in accordance with the corresponding instructions.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects