

Diagnosis information - Airbag

Ignition circuit Side airbag Passenger's side rear

WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Side airbag Passenger's side rear

WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Side airbag Passenger's side rear

WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Side airbag Passenger's side rear

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver Roll-over protection system

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

⚠ WARNING

High risk of injury to persons remaining close to the roll-over bars or if objects are placed in this area.

- ♦ Always ensure that body parts are kept away from the functional area of the roll-over bars.
- ♦ Always ensure that objects are kept away from the functional areas of the roll-over bars.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver Roll-over protection system

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

⚠ WARNING

High risk of injury to persons remaining close to the roll-over bars or if objects are placed in this area.

- ♦ Always ensure that body parts are kept away from the functional area of the roll-over bars.
- ♦ Always ensure that objects are kept away from the functional areas of the roll-over bars.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver Roll-over protection system

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

⚠ WARNING

High risk of injury to persons remaining close to the roll-over bars or if objects are placed in this area.

- ♦ Always ensure that body parts are kept away from the functional area of the roll-over bars.
- ♦ Always ensure that objects are kept away from the functional areas of the roll-over bars.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver Roll-over protection system

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

⚠ WARNING

High risk of injury to persons remaining close to the roll-over bars or if objects are placed in this area.

- ♦ Always ensure that body parts are kept away from the functional area of the roll-over bars.
- ♦ Always ensure that objects are kept away from the functional areas of the roll-over bars.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Driver Roll-over protection system

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

⚠ WARNING

High risk of injury to persons remaining close to the roll-over bars or if objects are placed in this area.

- ♦ Always ensure that body parts are kept away from the functional area of the roll-over bars.
- ♦ Always ensure that objects are kept away from the functional areas of the roll-over bars.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Passenger Roll-over protection system

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

⚠ WARNING

High risk of injury to persons remaining close to the roll-over bars or if objects are placed in this area.

- ♦ Always ensure that body parts are kept away from the functional area of the roll-over bars.
- ♦ Always ensure that objects are kept away from the functional areas of the roll-over bars.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Passenger Roll-over protection system

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

⚠ WARNING

High risk of injury to persons remaining close to the roll-over bars or if objects are placed in this area.

- ♦ Always ensure that body parts are kept away from the functional area of the roll-over bars.
- ♦ Always ensure that objects are kept away from the functional areas of the roll-over bars.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Passenger Roll-over protection system

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

⚠ WARNING

High risk of injury to persons remaining close to the roll-over bars or if objects are placed in this area.

- ♦ Always ensure that body parts are kept away from the functional area of the roll-over bars.
- ♦ Always ensure that objects are kept away from the functional areas of the roll-over bars.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Passenger Roll-over protection system

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

⚠ WARNING

High risk of injury to persons remaining close to the roll-over bars or if objects are placed in this area.

- ♦ Always ensure that body parts are kept away from the functional area of the roll-over bars.
- ♦ Always ensure that objects are kept away from the functional areas of the roll-over bars.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Passenger Roll-over protection system

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

⚠ WARNING

High risk of injury to persons remaining close to the roll-over bars or if objects are placed in this area.

- ♦ Always ensure that body parts are kept away from the functional area of the roll-over bars.
- ♦ Always ensure that objects are kept away from the functional areas of the roll-over bars.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Head airbag Driver's side

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Head airbag Driver's side

WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Head airbag Driver's side

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Head airbag Driver's side

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Head airbag Driver's side

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Head airbag Passenger's side

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.