

Diagnosis information - Airbag

Airbag control unit Plug contacts - Electrical fault

⚠ WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

❏ This fault is set even though the corresponding component is not installed in the vehicle. However, the contact pins for these components are present on the control unit. If moisture now penetrates into the connector, for example, this can produce short circuits and cause electrical faults to be set.

- ♦ Short circuits at the pins of the control unit/within the connector housing of the control unit, e.g. due to moisture

Fault effects

- No functional restrictions

Diagnosis information - Airbag

Airbag control unit Plug contacts - Electrical fault

⚠ WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

❏ This fault is set even though the corresponding component is not installed in the vehicle. However, the contact pins for these components are present on the control unit. If moisture now penetrates into the connector, for example, this can produce short circuits and cause electrical faults to be set.

- ♦ Short circuits at the pins of the control unit/within the connector housing of the control unit, e.g. due to moisture

Fault effects

- No functional restrictions

Diagnosis information - Airbag

Ignition circuit Seat belt force limiter Driver's side front

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Seat belt force limiter Driver's side front

⚠ **WARNING**

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ **WARNING**

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Seat belt force limiter Driver's side front

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Seat belt force limiter Driver's side front

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Seat belt force limiter Driver's side front

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Seat belt force limiter Passenger's side front

⚠ WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Seat belt force limiter Passenger's side front

⚠ WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Seat belt force limiter Passenger's side front

WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Seat belt force limiter Passenger's side front

WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Ignition circuit Seat belt force limiter Passenger's side front

⚠ WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnostic information - airbag

Open circuit in battery (pyrotechnical)

WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ Never hang the **PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Internal function test on airbag triggering unit

Possible fault causes

- ◆ Coding - ignition circuit is connected and OK, but is not coded.
- ◆ Electrical fault in circuit - electrical connection between two ignition circuits (mutual short circuit). Short circuit in wiring harness of two ignition circuits.
- ◆ Short circuit to B+/ground/between lines or open circuit in the lines
- ◆ Pyrotechnical disconnection element faulty
- ◆ Airbag control unit faulty

Fault effects

- ♦ Airbag warning light is **ON**
- ♦ Restricted function/no function of airbag control unit

Diagnostic information - airbag

Open circuit in battery (pyrotechnical)

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ Never hang the **PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Internal function test on airbag triggering unit

Possible fault causes

- ♦ Coding - ignition circuit is connected and OK, but is not coded.
- ♦ Electrical fault in circuit - electrical connection between two ignition circuits (mutual short circuit). Short circuit in wiring harness of two ignition circuits.
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Pyrotechnical disconnection element faulty
- ♦ Airbag control unit faulty

Fault effects

- ♦ Airbag warning light is **ON**
- ♦ Restricted function/no function of airbag control unit

Diagnostic information - airbag

Open circuit in battery (pyrotechnical)

WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ Never hang the **PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Internal function test on airbag triggering unit

Possible fault causes

- ◆ Coding - ignition circuit is connected and OK, but is not coded.
- ◆ Electrical fault in circuit - electrical connection between two ignition circuits (mutual short circuit). Short circuit in wiring harness of two ignition circuits.
- ◆ Short circuit to B+/ground/between lines or open circuit in the lines
- ◆ Pyrotechnical disconnection element faulty
- ◆ Airbag control unit faulty

Fault effects

- ♦ Airbag warning light is **ON**
- ♦ Restricted function/no function of airbag control unit

Diagnostic information - airbag

Open circuit in battery (pyrotechnical)

WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ Never hang the **PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Internal function test on airbag triggering unit

Possible fault causes

- ◆ Coding - ignition circuit is connected and OK, but is not coded.
- ◆ Electrical fault in circuit - electrical connection between two ignition circuits (mutual short circuit). Short circuit in wiring harness of two ignition circuits.
- ◆ Short circuit to B+/ground/between lines or open circuit in the lines
- ◆ Pyrotechnical disconnection element faulty
- ◆ Airbag control unit faulty

Fault effects

- ♦ Airbag warning light is **ON**
- ♦ Restricted function/no function of airbag control unit

Diagnostic information - airbag

Open circuit in battery (pyrotechnical)

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ Never hang the **PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Internal function test on airbag triggering unit

Possible fault causes

- ♦ Coding - ignition circuit is connected and OK, but is not coded.
- ♦ Electrical fault in circuit - electrical connection between two ignition circuits (mutual short circuit). Short circuit in wiring harness of two ignition circuits.
- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Pyrotechnical disconnection element faulty
- ♦ Airbag control unit faulty

Fault effects

- ♦ Airbag warning light is **ON**
- ♦ Restricted function/no function of airbag control unit

Diagnosis information - Airbag

Airbag control unit Plug contacts - Electrical fault

⚠ WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

❏ This fault is set even though the corresponding component is not installed in the vehicle. However, the contact pins for these components are present on the control unit. If moisture now penetrates into the connector, for example, this can produce short circuits and cause electrical faults to be set.

- ♦ Short circuits at the pins of the control unit/within the connector housing of the control unit, e.g. due to moisture

Fault effects

- No functional restrictions

Diagnosis information - Airbag

Airbag control unit Plug contacts - Electrical fault

⚠ WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

❏ This fault is set even though the corresponding component is not installed in the vehicle. However, the contact pins for these components are present on the control unit. If moisture now penetrates into the connector, for example, this can produce short circuits and cause electrical faults to be set.

- ◆ Short circuits at the pins of the control unit/within the connector housing of the control unit, e.g. due to moisture

Fault effects

- No functional restrictions

Diagnosis information - Airbag

Airbag control unit Plug contacts - Electrical fault

⚠ WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

❏ This fault is set even though the corresponding component is not installed in the vehicle. However, the contact pins for these components are present on the control unit. If moisture now penetrates into the connector, for example, this can produce short circuits and cause electrical faults to be set.

- ◆ Short circuits at the pins of the control unit/within the connector housing of the control unit, e.g. due to moisture

Fault effects

- No functional restrictions