

Diagnosis information - Airbag

Triggering event occurred

WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ At least one ignition circuit in the airbag system was triggered (see fault code description)

❏ If fault code 00570A is also entered, the airbag control unit must be replaced because at least one ignition circuit has been triggered the maximum number of times.

Fault effects

- none or Limited function

Diagnosis information - Airbag

Triggering event occurred

WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ At least one ignition circuit in the airbag system was triggered (see fault code description)

❏ If fault code 00570A is also entered, the airbag control unit must be replaced because at least one ignition circuit has been triggered the maximum number of times.

Fault effects

- none or Limited function

Diagnosis information - Airbag

Triggering event occurred

WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ At least one ignition circuit in the airbag system was triggered (see fault code description)

❏ If fault code 00570A is also entered, the airbag control unit must be replaced because at least one ignition circuit has been triggered the maximum number of times.

Fault effects

- none or Limited function

Diagnosis information - Airbag

Triggering event occurred

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ At least one ignition circuit in the airbag system was triggered (see fault code description)

❗ If fault code 00570A is also entered, the airbag control unit must be replaced because at least one ignition circuit has been triggered the maximum number of times.

Fault effects

- none or Limited function

Diagnosis information - Airbag

Triggering event occurred

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ At least one ignition circuit in the airbag system was triggered (see fault code description)

❗ If fault code 00570A is also entered, the airbag control unit must be replaced because at least one ignition circuit has been triggered the maximum number of times.

Fault effects

- none or Limited function

Diagnosis information - Airbag

Triggering event occurred

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ At least one ignition circuit in the airbag system was triggered (see fault code description)

❗ If fault code 00570A is also entered, the airbag control unit must be replaced because at least one ignition circuit has been triggered the maximum number of times.

Fault effects

- none or Limited function

Diagnosis information - Airbag

Triggering event occurred

WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ At least one ignition circuit in the airbag system was triggered (see fault code description)

 If fault code 00570A is also entered, the airbag control unit must be replaced because at least one ignition circuit has been triggered the maximum number of times.

Fault effects

- none or Limited function

Diagnosis information - Airbag

Triggering event occurred

WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ◆ At least one ignition circuit in the airbag system was triggered (see fault code description)

❏ If fault code 00570A is also entered, the airbag control unit must be replaced because at least one ignition circuit has been triggered the maximum number of times.

Fault effects

- none or Limited function

Diagnosis information - Airbag

Seat occupancy detection

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)
- ♦ Software version of Seat occupancy detection control unit implausible (fault 006109)

Fault effects

- ♦ Automatic deactivation of the front-passenger airbag does not work

♦ Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)
- ♦ Software version of Seat occupancy detection control unit implausible (fault 006109)

Fault effects

- ♦ Automatic deactivation of the front-passenger airbag does not work

♦ Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)
- ♦ Software version of Seat occupancy detection control unit implausible (fault 006109)

Fault effects

- ♦ Automatic deactivation of the front-passenger airbag does not work

♦ Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)
- ♦ Software version of Seat occupancy detection control unit implausible (fault 006109)

Fault effects

- ♦ Automatic deactivation of the front-passenger airbag does not work

♦ Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)
- ♦ Software version of Seat occupancy detection control unit implausible (fault 006109)

Fault effects

- ♦ Automatic deactivation of the front-passenger airbag does not work

♦ Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)
- ♦ Software version of Seat occupancy detection control unit implausible (fault 006109)

Fault effects

- ♦ Automatic deactivation of the front-passenger airbag does not work

♦ Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)
- ♦ Software version of Seat occupancy detection control unit implausible (fault 006109)

Fault effects

- ♦ Automatic deactivation of the front-passenger airbag does not work

♦ Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)
- ♦ Software version of Seat occupancy detection control unit implausible (fault 006109)

Fault effects

- ♦ Automatic deactivation of the front-passenger airbag does not work

♦ Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)
- ♦ Software version of Seat occupancy detection control unit implausible (fault 006109)

Fault effects

- ♦ Automatic deactivation of the front-passenger airbag does not work

♦ Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)
- ♦ Software version of Seat occupancy detection control unit implausible (fault 006109)

Fault effects

- ♦ Automatic deactivation of the front-passenger airbag does not work

♦ Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection pressure sensor

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Seat occupancy detection pressure sensor

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

