

Diagnosis information - Airbag

Seat occupancy detection pressure sensor

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Seat occupancy detection pressure sensor

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Ignition circuit is connected and OK, but is not coded.
- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Fault Belt force sensor / belt buckle switch

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

❗ The belt force sensor/belt buckle switch is installed in the front-passenger buckle and monitors the tensile force acting on the buckle. The belt force sensor/belt buckle switch is powered by the seat occupancy detection control unit.

The belt buckle itself (inserted/not inserted) is wired with the airbag control unit.

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Part stuck and exerting pressure or tension on the belt buckle while the front-passenger seat belt is not fastened
- ♦ Belt force sensor/belt buckle switch faulty
- ♦ Seat occupancy detection control unit faulty

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Fault Belt force sensor / belt buckle switch

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

❗ The belt force sensor/belt buckle switch is installed in the front-passenger buckle and monitors the tensile force acting on the buckle. The belt force sensor/belt buckle switch is powered by the seat occupancy detection control unit.

The belt buckle itself (inserted/not inserted) is wired with the airbag control unit.

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Part stuck and exerting pressure or tension on the belt buckle while the front-passenger seat belt is not fastened
- ♦ Belt force sensor/belt buckle switch faulty
- ♦ Seat occupancy detection control unit faulty

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Fault Belt force sensor / belt buckle switch

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

❗ The belt force sensor/belt buckle switch is installed in the front-passenger buckle and monitors the tensile force acting on the buckle. The belt force sensor/belt buckle switch is powered by the seat occupancy detection control unit.

The belt buckle itself (inserted/not inserted) is wired with the airbag control unit.

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Part stuck and exerting pressure or tension on the belt buckle while the front-passenger seat belt is not fastened
- ♦ Belt force sensor/belt buckle switch faulty
- ♦ Seat occupancy detection control unit faulty

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Fault Belt force sensor / belt buckle switch

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

❗ The belt force sensor/belt buckle switch is installed in the front-passenger buckle and monitors the tensile force acting on the buckle. The belt force sensor/belt buckle switch is powered by the seat occupancy detection control unit.

The belt buckle itself (inserted/not inserted) is wired with the airbag control unit.

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines
- ♦ Part stuck and exerting pressure or tension on the belt buckle while the front-passenger seat belt is not fastened
- ♦ Belt force sensor/belt buckle switch faulty
- ♦ Seat occupancy detection control unit faulty

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Diagnosis information - Airbag

Seat occupancy detection - fault in LIN line

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

♦ If fault indicating implausible signal on the LIN line is permanently present: Airbag control unit function is restricted or occupant detection function is restricted

❏ Fault 006501 (LIN - short circuit to ground) can also be triggered if there is no power supply for the occupant detection control unit (e.g. due to a faulty fuse).

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Fault effects

Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection - fault in LIN line

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

♦ If fault indicating implausible signal on the LIN line is permanently present: Airbag control unit function is restricted or occupant detection function is restricted

❏ Fault 006501 (LIN - short circuit to ground) can also be triggered if there is no power supply for the occupant detection control unit (e.g. due to a faulty fuse).

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Fault effects

Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection - fault in LIN line

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

- ♦ If fault indicating implausible signal on the LIN line is permanently present: Airbag control unit function is restricted or occupant detection function is restricted

❗ Fault 006501 (LIN - short circuit to ground) can also be triggered if there is no power supply for the occupant detection control unit (e.g. due to a faulty fuse).

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Fault effects

Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection - fault in LIN line

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

♦ If fault indicating implausible signal on the LIN line is permanently present: Airbag control unit function is restricted or occupant detection function is restricted

❏ Fault 006501 (LIN - short circuit to ground) can also be triggered if there is no power supply for the occupant detection control unit (e.g. due to a faulty fuse).

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Fault effects

Airbag system does not trigger optimally.

Diagnosis information - Airbag

Seat occupancy detection - fault in LIN line

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

- ♦ Short circuit to ground (Electrical fault in circuit)
- ♦ Short circuit to B+ (Electrical fault in circuit)

- ♦ If fault indicating implausible signal on the LIN line is permanently present: Airbag control unit function is restricted or occupant detection function is restricted

❗ Fault 006501 (LIN - short circuit to ground) can also be triggered if there is no power supply for the occupant detection control unit (e.g. due to a faulty fuse).

Fault effects

Affected ignition circuit does not ignite or does not ignite in the specified time.

Fault effects

Airbag system does not trigger optimally.

Diagnosis information - Airbag

Indicator light Airbag Instrument cluster

WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Activation of instrument cluster light by airbag control unit

Possible fault causes

- ♦ Instrument cluster sends a message to the airbag control unit reporting that the warning lamp is switched off although this was activated by the airbag control unit. (007032)
- ♦ Instrument cluster does not send any (valid) feedback to the airbag control unit about the current status of the warning light (00702C)

Fault effects

- ♦ Limited function Warning light for Airbag

Diagnosis information - Airbag

Indicator light Airbag Instrument cluster

WARNING

Uncontrolled triggering of the airbag

- Contusions, crushing injuries or death

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- Contusions, crushing injuries or death
- Traffic hazard

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Activation of instrument cluster light by airbag control unit

Possible fault causes

- ♦ Instrument cluster sends a message to the airbag control unit reporting that the warning lamp is switched off although this was activated by the airbag control unit. (007032)
- ♦ Instrument cluster does not send any (valid) feedback to the airbag control unit about the current status of the warning light (00702C)

Fault effects

- ♦ Limited function Warning light for Airbag

Diagnosis information - Airbag

Indicator light, passenger airbag OFF

WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

When you connect the test tool 5056/C and then switch the ignition on and off, the fault code for stage 2 is detected because there is no airbag unit connected to it. The fault code must be deleted after removal of test tool 5056/C and after performing the repair or must be processed in accordance with the corresponding instructions.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

NOTE

Sporadic faults.

- ♦ Sporadically occurring faults (loose contact, etc.) in the airbag ignition circuits are indicated by the airbag warning light lighting up in the instrument cluster.
- ♦ In difficult cases of faults that are **not currently present, it is a good idea to:** erase the fault

memory and observe whether the fault is entered again when you simulate a loose contact.

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Diagnosis information - Airbag

Indicator light, passenger airbag OFF

WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

When you connect the test tool 5056/C and then switch the ignition on and off, the fault code for stage 2 is detected because there is no airbag unit connected to it. The fault code must be deleted after removal of test tool 5056/C and after performing the repair or must be processed in accordance with the corresponding instructions.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

NOTE

Sporadic faults.

- ♦ Sporadically occurring faults (loose contact, etc.) in the airbag ignition circuits are indicated by the airbag warning light lighting up in the instrument cluster.
- ♦ In difficult cases of faults that are **not currently present, it is a good idea to:** erase the fault

memory and observe whether the fault is entered again when you simulate a loose contact.

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Diagnosis information - Airbag

Indicator light, passenger airbag OFF

WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

When you connect the test tool 5056/C and then switch the ignition on and off, the fault code for stage 2 is detected because there is no airbag unit connected to it. The fault code must be deleted after removal of test tool 5056/C and after performing the repair or must be processed in accordance with the corresponding instructions.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

NOTE

Sporadic faults.

- ♦ Sporadically occurring faults (loose contact, etc.) in the airbag ignition circuits are indicated by the airbag warning light lighting up in the instrument cluster.
- ♦ In difficult cases of faults that are **not currently present, it is a good idea to:** erase the fault

memory and observe whether the fault is entered again when you simulate a loose contact.

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Diagnosis information - Airbag

Indicator light, passenger airbag OFF

WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

When you connect the test tool 5056/C and then switch the ignition on and off, the fault code for stage 2 is detected because there is no airbag unit connected to it. The fault code must be deleted after removal of test tool 5056/C and after performing the repair or must be processed in accordance with the corresponding instructions.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

NOTE

Sporadic faults.

- ♦ Sporadically occurring faults (loose contact, etc.) in the airbag ignition circuits are indicated by the airbag warning light lighting up in the instrument cluster.
- ♦ In difficult cases of faults that are **not currently present, it is a good idea to:** erase the fault

memory and observe whether the fault is entered again when you simulate a loose contact.

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Diagnosis information - Airbag

Indicator light, passenger airbag OFF

WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

When you connect the test tool 5056/C and then switch the ignition on and off, the fault code for stage 2 is detected because there is no airbag unit connected to it. The fault code must be deleted after removal of test tool 5056/C and after performing the repair or must be processed in accordance with the corresponding instructions.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

NOTE

Sporadic faults.

- ♦ Sporadically occurring faults (loose contact, etc.) in the airbag ignition circuits are indicated by the airbag warning light lighting up in the instrument cluster.
- ♦ In difficult cases of faults that are **not currently present, it is a good idea to:** erase the fault

memory and observe whether the fault is entered again when you simulate a loose contact.

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Diagnosis information - Airbag

Indicator light, passenger airbag OFF

WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

When you connect the test tool 5056/C and then switch the ignition on and off, the fault code for stage 2 is detected because there is no airbag unit connected to it. The fault code must be deleted after removal of test tool 5056/C and after performing the repair or must be processed in accordance with the corresponding instructions.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

NOTE

Sporadic faults.

- ♦ Sporadically occurring faults (loose contact, etc.) in the airbag ignition circuits are indicated by the airbag warning light lighting up in the instrument cluster.
- ♦ In difficult cases of faults that are **not currently present, it is a good idea to:** erase the fault

memory and observe whether the fault is entered again when you simulate a loose contact.

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)

Diagnosis information - Airbag

Indicator light, passenger airbag OFF

⚠ WARNING

Uncontrolled triggering of the airbag

- **Contusions, crushing injuries or death**

- ▶ **Never hang the PIWIS Tester** on or over the steering wheel.
- ▶ Before working on the ignition circuits of the airbag system, always disconnect the battery from the vehicle electrical system and ensure that the vehicle electrical system is de-energized.
- ▶ Wait for at least one minute before starting work on the airbag system.
- ▶ Perform fault finding on the ignition circuits of the airbag system and its lines only using approved special tools.

⚠ WARNING

Driving with attached/connected special tools or commercially available tools

- **Contusions, crushing injuries or death**
- **Traffic hazard**

- ▶ Never drive with special tools and/ or commercially available tools attached instead of the airbag units.

When you connect the test tool 5056/C and then switch the ignition on and off, the fault code for stage 2 is detected because there is no airbag unit connected to it. The fault code must be deleted after removal of test tool 5056/C and after performing the repair or must be processed in accordance with the corresponding instructions.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Airbag triggering unit Internal function test

Possible fault causes

NOTE

Sporadic faults.

- ♦ Sporadically occurring faults (loose contact, etc.) in the airbag ignition circuits are indicated by the airbag warning light lighting up in the instrument cluster.
- ♦ In difficult cases of faults that are **not currently present, it is a good idea to:** erase the fault

memory and observe whether the fault is entered again when you simulate a loose contact.

- ◆ Ignition circuit is connected and OK, but is not coded.
- ◆ Short circuit to ground (Electrical fault in circuit)
- ◆ Short circuit to B+ (Electrical fault in circuit)