

991 + 981 , MY 2012 =>

Diagnosis information - Memory seat adjustment driver

01BE.....	1
01BF.....	2
0214.....	3
0412.....	4
0758.....	5
0759.....	6
075A.....	7
075B.....	8
076D.....	9
076E.....	10
077B.....	11
077C.....	12
077D.....	13
077D.....	14
07B1.....	15
07B2.....	16
07B5.....	17
07B8.....	18
07D5.....	19
0CF1.....	20
0CF2.....	21
0CF3.....	22
0CF4.....	23
0CF6.....	24
0CF7.....	25
0CF8.....	26
0CF9.....	27
0CFA.....	28
0CFB.....	29
0CFC.....	30
0CFD.....	31
0D02.....	32
0D03.....	33
0D04.....	34
0D05.....	35
3D00.....	36
3D01.....	37
3D02.....	38
3D03.....	39

3D04.....	40
3D05.....	41
3D06.....	42
3D07.....	43
3D07.....	44
3D07.....	45
3D08.....	46
3D09.....	47
3D09.....	48
3D09.....	49
3D0A.....	50
3D0B.....	51
3D0B.....	52
3D0C.....	53
3D0C.....	54
3D0D.....	55
3FDA.....	56
3FDB.....	57

01BE

Diagnosis information - Seat adjustment memory control module

Supply voltage

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Supply voltage** Terminal 30 < 9 V

Fault effects

- ♦ **Memory seat adjustment** No function

01BF

Diagnosis information - Seat adjustment memory control module

Supply voltage

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Supply voltage** Terminal 30 < 9 V

Fault effects

- ♦ **Memory seat adjustment** No function

Diagnosis information - Seat adjustment memory control module

Supply voltage

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Supply voltage** Terminal 30 < 9 V

Fault effects

- ♦ **Memory seat adjustment** No function

Diagnostic information - memory seat adjustment control unit

Control unit, **coding**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- No/incorrect coding

Fault effects

- ♦ Restricted function of **memory seat adjustment control unit**

Diagnosis information - Seat adjustment memory control module

Lumbar support switch

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Limited function **Lumbar support adjustment**

Diagnosis information - Seat adjustment memory control module

Lumbar support switch

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Limited function **Lumbar support adjustment**

Diagnosis information - Seat adjustment memory control module

Lumbar support switch

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Limited function **Lumbar support adjustment**

Diagnosis information - Seat adjustment memory control module

Lumbar support switch

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Limited function **Lumbar support adjustment**

Diagnosis information - Seat adjustment memory control module

Engine Lumbar height adjustment, vertical

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Overtemperature **Seat adjustment motor**

Fault effects

- ◆ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Lumbar curvature motor

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Overtemperature **Seat adjustment motor**

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Hall-effect sensor, Engine Lumbar height adjustment, vertical

INFORMATION

From model year 2012 onwards, the seat positions are no longer detected by a hall sender in the electric motor. The control unit detects the fluctuations in current in the supply lines that occur when the motor is running and converts these to revolutions.

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Hall sensor signal does not change at Activation **Adjusting motor**
- Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ Affected axis limp-home mode
- ♦ The memory seat adjustment control unit cannot store the position of the affected axis or cannot move to the stored position.

Diagnosis information - Seat adjustment memory control module

Hall-effect sensor, Lumbar curvature motor

INFORMATION

From model year 2012 onwards, the seat positions are no longer detected by a hall sender in the electric motor. The control unit detects the fluctuations in current in the supply lines that occur when the motor is running and converts these to revolutions.

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Hall sensor signal does not change at Activation **Adjusting motor**
- Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ Affected axis limp-home mode
- ♦ The memory seat adjustment control unit cannot store the position of the affected axis or cannot move to the stored position.

077D

Diagnostic information - memory seat adjustment control unit

Control unit, **coding**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- No/incorrect coding

Fault effects

- ♦ Restricted function of **memory seat adjustment control unit**

077D

Diagnosis information - Seat adjustment memory control module

Coding pin (Fault code 07D5)

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Seat adjustment memory control module** adapted to wrong seat (Driver's side or Passenger's side)
- Line from coding pin to ground pin in plug Faulty (connector B)

Fault effects

- ♦ No seat function restriction
- ♦ CAN bus function restriction

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Hall-effect sensor, Seat depth adjustment motor

INFORMATION

From model year 2012 onwards, the seat positions are no longer detected by a hall sender in the electric motor. The control unit detects the fluctuations in current in the supply lines that occur when the motor is running and converts these to revolutions.

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Hall sensor signal does not change at Activation **Adjusting motor**
- Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ Affected axis limp-home mode
- ♦ The memory seat adjustment control unit cannot store the position of the affected axis or cannot move to the stored position.

Diagnosis information - Seat adjustment memory control module

Seat adjustment motor

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Overtemperature **Seat adjustment motor**

Fault effects

- ◆ Affected axis does not function

07D5

Diagnosis information - Seat adjustment memory control module

Coding pin (Fault code 07D5)

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Seat adjustment memory control module** adapted to wrong seat (Driver's side or Passenger's side)
- Line from coding pin to ground pin in plug Faulty (connector B)

Fault effects

- ♦ No seat function restriction
- ♦ CAN bus function restriction

Diagnosis information - Seat adjustment memory control module

Hall-effect sensor, Seat fore-and-aft adjustment motor

INFORMATION

From model year 2012 onwards, the seat positions are no longer detected by a hall sender in the electric motor. The control unit detects the fluctuations in current in the supply lines that occur when the motor is running and converts these to revolutions.

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Hall sensor signal does not change at Activation **Adjusting motor**
- Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ Affected axis limp-home mode
- ♦ The memory seat adjustment control unit cannot store the position of the affected axis or cannot move to the stored position.

Diagnosis information - Seat adjustment memory control module

Hall-effect sensor, Motor for backrest adjustment

INFORMATION

From model year 2012 onwards, the seat positions are no longer detected by a hall sender in the electric motor. The control unit detects the fluctuations in current in the supply lines that occur when the motor is running and converts these to revolutions.

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Hall sensor signal does not change at Activation **Adjusting motor**
- Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ Affected axis limp-home mode
- ♦ The memory seat adjustment control unit cannot store the position of the affected axis or cannot move to the stored position.

Diagnosis information - Seat adjustment memory control module

Hall-effect sensor, Seat height adjustment motor

INFORMATION

From model year 2012 onwards, the seat positions are no longer detected by a hall sender in the electric motor. The control unit detects the fluctuations in current in the supply lines that occur when the motor is running and converts these to revolutions.

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Hall sensor signal does not change at Activation **Adjusting motor**
- Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ Affected axis limp-home mode
- ♦ The memory seat adjustment control unit cannot store the position of the affected axis or cannot move to the stored position.

Diagnosis information - Seat adjustment memory control module

Hall-effect sensor, Seat angle adjustment motor

INFORMATION

From model year 2012 onwards, the seat positions are no longer detected by a hall sender in the electric motor. The control unit detects the fluctuations in current in the supply lines that occur when the motor is running and converts these to revolutions.

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Hall sensor signal does not change at Activation **Adjusting motor**
- Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ♦ Affected axis limp-home mode
- ♦ The memory seat adjustment control unit cannot store the position of the affected axis or cannot move to the stored position.

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Seat adjustment motor

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Overtemperature **Seat adjustment motor**

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Seat adjustment motor

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Overtemperature **Seat adjustment motor**

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Seat adjustment motor

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Overtemperature **Seat adjustment motor**

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Seat adjustment motor

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Overtemperature **Seat adjustment motor**

Fault effects

- ♦ Affected axis does not function

3D00

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

3D01

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

3D02

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function