

3D02

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

3D03

Diagnosis information - Seat adjustment memory control module

Switch, memory seat adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Button** stuck outside **neutral** position
- Short circuit between the lines

Fault effects

- ♦ Affected axis does not function

3D04

Diagnosis information - Seat adjustment memory control module

Pump Lumbar support adjustment

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Short circuit to B+/ground/between lines or open circuit in the lines
- **Pump** Seat contour Faulty

Fault effects

- ♦ **Lumbar support adjustment** No function

3D05

Diagnosis information - Seat adjustment memory control module

Pump valve unit Seat contour

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Short circuit to B+/ground or open circuit in the line
- **Pump valve unit** Faulty

Fault effects

- ♦ Adjustment Seat contour Faulty

3D06

Diagnosis information - Seat adjustment memory control module

Lumbar curvature motor

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Overtemperature **Seat adjustment motor**

Fault effects

- ◆ Affected axis does not function

3D07

Diagnosis information - Seat adjustment memory control module

Activation Ventil unit **Lumbar support adjustment**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Short circuit to B+/ground or open circuit in the line
- Ventil unit **Lumbar support adjustment** Faulty

Fault effects

- ♦ **Lumbar support adjustment** No function

Diagnosis information - Seat adjustment memory control module

Ventil unit **Lumbar support adjustment**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Drive link is electrically actuated without detectable mechanical reaction.

Fault effects

- ♦ **Lumbar support adjustment** up or down No function

3D07

Diagnosis information - Seat adjustment memory control module

Supply voltage Ventil unit **Lumbar support adjustment**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Supply voltage** Terminal 30 < 9 V

Fault effects

- ♦ **Lumbar support adjustment** No function

3D08

Diagnosis information - Seat adjustment memory control module

Lumbar curvature motor

Diagnostic conditions

- Ignition on
- ► Activation of the affected axle in both directions

Fault setting condition(s)

- Overtemperature **Seat adjustment motor**

Fault effects

- ♦ Affected axis does not function

Diagnosis information - Seat adjustment memory control module

Activation Ventil unit **Lumbar support adjustment**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Short circuit to B+/ground or open circuit in the line
- Ventil unit **Lumbar support adjustment** Faulty

Fault effects

- ♦ **Lumbar support adjustment** No function

Diagnosis information - Seat adjustment memory control module

Ventil unit **Lumbar support adjustment**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Drive link is electrically actuated without detectable mechanical reaction.

Fault effects

- ♦ **Lumbar support adjustment** up or down No function

3D09

Diagnosis information - Seat adjustment memory control module

Supply voltage Ventil unit **Lumbar support adjustment**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Supply voltage** Terminal 30 < 9 V

Fault effects

- ♦ **Lumbar support adjustment** No function

3D0A

Diagnosis information - Seat adjustment memory control module

Activation Ventil unit **Lumbar support adjustment**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Short circuit to B+/ground or open circuit in the line
- Ventil unit **Lumbar support adjustment** Faulty

Fault effects

- ♦ **Lumbar support adjustment** No function

3D0B

Diagnosis information - Seat adjustment memory control module

Activation Ventil unit **Lumbar support adjustment**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Short circuit to B+/ground or open circuit in the line
- Ventil unit **Lumbar support adjustment** Faulty

Fault effects

- ♦ **Lumbar support adjustment** No function

3D0B

Diagnosis information - Seat adjustment memory control module

Ventil unit **Lumbar support adjustment**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Drive link is electrically actuated without detectable mechanical reaction.

Fault effects

- ♦ **Lumbar support adjustment** up or down No function

3D0C

Diagnosis information - Seat adjustment memory control module

Activation Ventil unit **Lumbar support adjustment**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Short circuit to B+/ground or open circuit in the line
- Ventil unit **Lumbar support adjustment** Faulty

Fault effects

- ♦ **Lumbar support adjustment** No function

3D0C

Diagnosis information - Seat adjustment memory control module

Ventil unit **Lumbar support adjustment**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Drive link is electrically actuated without detectable mechanical reaction.

Fault effects

- ♦ **Lumbar support adjustment** up or down No function

3D0D

Diagnosis information - Seat adjustment memory control module

Supply voltage Ventil unit **Lumbar support adjustment**

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Supply voltage** Terminal 30 < 9 V

Fault effects

- ♦ **Lumbar support adjustment** No function

3FDA

Diagnosis information - Seat adjustment memory control module

Seat adjustment memory control module

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Internal control unit fault

Fault effects

- ♦ Limited function **Seat adjustment memory control module**

3FDB

Diagnosis information - Seat adjustment memory control module

Seat adjustment memory control module

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Internal control unit fault

Fault effects

- ♦ Limited function **Seat adjustment memory control module**