

# 991 + 981 , MY 2012 =>

## Diagnosis information - Air-conditioning system

|             |    |
|-------------|----|
| 000010..... | 1  |
| 001000..... | 2  |
| 001002..... | 3  |
| 001004..... | 4  |
| 001020..... | 5  |
| 001021..... | 6  |
| 001100..... | 7  |
| 001104..... | 8  |
| 001110..... | 9  |
| 001114..... | 10 |
| 001141..... | 11 |
| 001143..... | 12 |
| 001151..... | 13 |
| 001153..... | 14 |
| 001170..... | 15 |
| 001172..... | 16 |
| 001174..... | 17 |
| 001180..... | 18 |
| 001182..... | 19 |
| 001184..... | 20 |
| 001190..... | 21 |
| 001194..... | 22 |
| 001300..... | 23 |
| 001304..... | 24 |
| 001310..... | 25 |
| 001314..... | 26 |
| 001320..... | 27 |
| 001324..... | 28 |
| 001330..... | 29 |
| 001334..... | 30 |
| 001340..... | 31 |
| 001344..... | 32 |
| 001350..... | 33 |
| 001354..... | 34 |
| 001360..... | 35 |
| 001364..... | 36 |
| 001370..... | 37 |
| 001374..... | 38 |
| 001380..... | 39 |

|             |    |
|-------------|----|
| 001384..... | 40 |
| 001390..... | 41 |
| 001394..... | 42 |
| 0013A0..... | 43 |
| 0013A4..... | 44 |
| 001400..... | 45 |
| 001404..... | 46 |
| 001410..... | 47 |
| 001414..... | 48 |
| 001420..... | 49 |
| 001424..... | 50 |
| 001601..... | 51 |
| 001603..... | 52 |
| 001605..... | 53 |
| 001610..... | 54 |
| 001705..... | 55 |
| 001706..... | 56 |
| 001707..... | 57 |
| 001715..... | 58 |
| 001716..... | 59 |
| 001717..... | 61 |
| 001725..... | 62 |
| 001726..... | 63 |
| 001727..... | 64 |
| 001735..... | 65 |
| 001736..... | 66 |
| 001737..... | 67 |
| 001745..... | 68 |
| 001746..... | 69 |
| 001747..... | 70 |
| 001755..... | 71 |
| 001756..... | 72 |
| 001757..... | 73 |
| 001765..... | 74 |
| 001766..... | 75 |
| 001767..... | 76 |
| 001775..... | 77 |
| 001776..... | 78 |
| 001777..... | 79 |

|             |     |
|-------------|-----|
| 001805..... | 80  |
| 001806..... | 81  |
| 001807..... | 82  |
| 001820..... | 83  |
| 001821..... | 84  |
| 001900..... | 85  |
| 00C058..... | 86  |
| C11005..... | 87  |
| C11006..... | 88  |
| C11007..... | 89  |
| C13000..... | 90  |
| C13001..... | 91  |
| C13002..... | 92  |
| C13003..... | 93  |
| C13004..... | 94  |
| C13005..... | 95  |
| C13006..... | 96  |
| C13007..... | 97  |
| C13008..... | 98  |
| C13009..... | 99  |
| C1300A..... | 100 |
| C1300B..... | 101 |
| C13038..... | 102 |
| C13039..... | 103 |
| C1303A..... | 104 |
| C13060..... | 105 |
| C13061..... | 106 |
| C13063..... | 107 |
| C13064..... | 108 |
| C13065..... | 109 |
| C13066..... | 110 |
| C13067..... | 111 |
| C13068..... | 112 |
| C1306A..... | 113 |
| C1306C..... | 114 |

# 000010

## Diagnosis information - Air-conditioning system

### Operating button stuck

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

One **Operating button** for longer than 16 Second(s) pressed

#### Fault effects

- ♦ Limited function
- ♦ **Operating button** No function

# 001000

## Diagnosis information - Air-conditioning system

### Power supply LIN bus Servo motor 5 V

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

Short circuit to B+

- Signal Voltage  
 $U > 4.9 \text{ V}$

Short circuit to ground

- Signal Voltage  
 $U < 0.1 \text{ V}$

Open circuit

#### Fault effects

- ♦ Limited function

## Diagnosis information - Air-conditioning system

### Power supply LIN bus Servo motor 5 V

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

Short circuit to B+

- Signal Voltage  
 $U > 4.9 \text{ V}$

Short circuit to ground

- Signal Voltage  
 $U < 0.1 \text{ V}$

Open circuit

#### Fault effects

- ♦ Limited function

## Diagnosis information - Air-conditioning system

### Power supply LIN bus Servo motor 5 V

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

Short circuit to B+

- Signal Voltage  
 $U > 4.9 \text{ V}$

Short circuit to ground

- Signal Voltage  
 $U < 0.1 \text{ V}$

Open circuit

#### Fault effects

- ♦ Limited function

## Diagnosis information - Air-conditioning system

### Power supply Sensors 5 V

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

Short circuit to B+

- Voltage  
U > 4.9 V

Short circuit to ground

- Voltage  
U < 0.1 V

Open circuit

#### Fault effects

- ♦ Limited function

## Diagnosis information - Air-conditioning system

### Power supply Sensors 5 V

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

Short circuit to B+

- Voltage  
U > 4.9 V

Short circuit to ground

- Voltage  
U < 0.1 V

Open circuit

#### Fault effects

- ♦ Limited function

## Diagnosis information - Air-conditioning system

### Power supply Seat heating

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Seat heating **ON** (Engine running

)

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ No function

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnosis information - Air-conditioning system

### Power supply Seat heating

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Seat heating **ON** (Engine running

)

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ No function

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnosis information - Air-conditioning system

### Power supply Seat heating

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Seat heating **ON** (Engine running

)

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ No function

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnosis information - Air-conditioning system

### Power supply Seat heating

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Seat heating **ON** (Engine running

)

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ No function

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnosis information - Air-conditioning system

### Power supply Suction fan Ventilation Front seat

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

#### • Ventilation Front seat ON

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ No function

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnosis information - Air-conditioning system

### Power supply Suction fan Ventilation Front seat

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

#### • Ventilation Front seat ON

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ No function

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnosis information - Air-conditioning system

### Power supply Suction fan Ventilation Front seat

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

#### • Ventilation Front seat ON

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ No function

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnosis information - Air-conditioning system

### Power supply Suction fan Ventilation Front seat

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

#### • Ventilation Front seat ON

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ No function

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnosis information - Air-conditioning system

### Power supply Coolant Switch-over valve Heating

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Engine running

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Heating permanent **ON** (Short circuit to B+ ) or **OFF** (Short circuit to ground , Open circuit)

## Diagnosis information - Air-conditioning system

### Power supply Coolant Switch-over valve Heating

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Engine running

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Heating permanent **ON** (Short circuit to B+ ) or **OFF** (Short circuit to ground , Open circuit)

## Diagnosis information - Air-conditioning system

### Power supply Coolant Switch-over valve Heating

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Engine running

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Heating permanent **ON** (Short circuit to B+ ) or **OFF** (Short circuit to ground , Open circuit)

## Diagnosis information - Air-conditioning system

### Power supply Compressor

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Engine running

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ **Air-conditioning system** none Cooling performance

## Diagnosis information - Air-conditioning system

### Power supply Compressor

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Engine running

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ **Air-conditioning system** none Cooling performance

## Diagnosis information - Air-conditioning system

### Power supply Compressor

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Engine running

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ **Air-conditioning system** none Cooling performance

## Diagnosis information - Air-conditioning system

### Power supply Fan

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Fan **ON**

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ **Air-conditioning system** none Cooling performance

## Diagnosis information - Air-conditioning system

### Power supply Fan

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Fan **ON**

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ **Air-conditioning system** none Cooling performance

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".

## Diagnostic information - air conditioning

### Temperature sensor **power supply**

#### Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

#### Fault setting condition(s)

- Short circuit to B+
- Short circuit to ground
- Open circuit

#### Fault effects

- ♦ Restricted function of **air conditioner**

See document "Tequipment Installation and Conversion Instructions, 7201 Sports bucket seat (I-no. 388/389)".