

991 + 981 , MY 2012 =>

Diagnosis information - Instrument cluster

000003.....	1
000004.....	2
000006.....	3
000007.....	4
000009.....	5
000013.....	6
00C058.....	7
010000.....	8
010001.....	10
010002.....	12
010003.....	14
010008.....	16
01000A.....	18
01000B.....	19
010015.....	20
010016.....	22
010017.....	23
010018.....	25
010019.....	27
01001A.....	29
C11000.....	31
C11001.....	33
C11004.....	35
C11005.....	36
C11006.....	37
C11007.....	38

Diagnosis information - Instrument cluster

Instrument cluster

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Safety light in the instrument cluster faulty

Fault effects

- ♦ Function not available or available only to a limited extent

000004

Diagnosis information - Instrument cluster

Instrument cluster

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Safety light in the instrument cluster faulty

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Instrument cluster

Instrument cluster

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Safety light in the instrument cluster faulty

Fault effects

- ♦ Function not available or available only to a limited extent

000007

Diagnosis information - Instrument cluster

Instrument cluster

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Safety light in the instrument cluster faulty

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Instrument cluster

TFT screen, Lights

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Faulty

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Instrument cluster

Internal loudspeaker

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Faulty

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Instrument cluster

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- incorrectly coded
- not coded

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Instrument cluster

Fuel level sensor

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Limit exceeded
- ♦ Signal implausible
- ♦ Short circuit to ground
- ♦ Short circuit to B+
- ♦ Short circuit between the lines

Fault setting condition(s)

- Supply voltage 9 ... 16 V

Fault effects

- ♦ Fuel level display at position ZERO

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

◆ Setpoint resistance < **2 Ohm**

Short circuit between lines :

◆ Setpoint resistance > **0.9 MOhm**

Diagnosis information - Instrument cluster

Fuel level sensor

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Limit exceeded
- ♦ Signal implausible
- ♦ Short circuit to ground
- ♦ Short circuit to B+
- ♦ Short circuit between the lines

Fault setting condition(s)

- Supply voltage 9 ... 16 V

Fault effects

- ♦ Fuel level display at position ZERO

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

◆ Setpoint resistance < **2 Ohm**

Short circuit between lines :

◆ Setpoint resistance > **0.9 MOhm**

Diagnosis information - Instrument cluster

Fuel level sensor

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Limit exceeded
- ♦ Signal implausible
- ♦ Short circuit to ground
- ♦ Short circuit to B+
- ♦ Short circuit between the lines

Fault setting condition(s)

- Supply voltage 9 ... 16 V

Fault effects

- ♦ Fuel level display at position ZERO

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

◆ Setpoint resistance < **2 Ohm**

Short circuit between lines :

◆ Setpoint resistance > **0.9 MOhm**

Diagnosis information - Instrument cluster

Fuel level sensor

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Limit exceeded
- ♦ Signal implausible
- ♦ Short circuit to ground
- ♦ Short circuit to B+
- ♦ Short circuit between the lines

Fault setting condition(s)

- Supply voltage 9 ... 16 V

Fault effects

- ♦ Fuel level display at position ZERO

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

◆ Setpoint resistance < **2 Ohm**

Short circuit between lines :

◆ Setpoint resistance > **0.9 MOhm**

Diagnosis information - Instrument cluster

Fuel level sensor

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Limit exceeded
- ♦ Signal implausible
- ♦ Short circuit to ground
- ♦ Short circuit to B+
- ♦ Short circuit between the lines

Fault setting condition(s)

- Supply voltage 9 ... 16 V

Fault effects

- ♦ Fuel level display at position ZERO

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

◆ Setpoint resistance < **2 Ohm**

Short circuit between lines :

◆ Setpoint resistance > **0.9 MOhm**

Diagnosis information - Instrument cluster

Calibration

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Calibration incorrect or not carried out

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Instrument cluster

Calibration

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Calibration incorrect or not carried out

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Instrument cluster

Selector lever

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Signal implausible
- ♦ Open circuit
- ♦ Short circuit to ground
- ♦ Short circuit to B+
- ♦ Short circuit between the lines

Fault setting condition(s)

- Supply voltage 9 ... 16 V

Fault effects

- ♦ Function not available or available only to a limited extent

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

◆ Setpoint resistance < **2 Ohm**

Short circuit between lines :

◆ Setpoint resistance > **0.9 MOhm**

Diagnosis information - Instrument cluster

Selector lever

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Faulty

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Instrument cluster

Instrument lighting

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Open circuit
- ♦ Short circuit to ground
- ♦ Short circuit to B+
- ♦ Short circuit between the lines

Fault setting condition(s)

- Supply voltage 9 ... 16 V

Fault effects

- ♦ Function not available or available only to a limited extent

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Short circuit between lines :

◆ Setpoint resistance > **0.9 MOhm**

Diagnosis information - Instrument cluster

Instrument lighting

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Open circuit
- ♦ Short circuit to ground
- ♦ Short circuit to B+
- ♦ Short circuit between the lines

Fault setting condition(s)

- Supply voltage 9 ... 16 V

Fault effects

- ♦ Function not available or available only to a limited extent

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Short circuit between lines :

◆ Setpoint resistance > **0.9 MOhm**

Diagnosis information - Instrument cluster

Selector lever

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Signal implausible
- ♦ Open circuit
- ♦ Short circuit to ground
- ♦ Short circuit to B+
- ♦ Short circuit between the lines

Fault setting condition(s)

- Supply voltage 9 ... 16 V

Fault effects

- ♦ Function not available or available only to a limited extent

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

◆ Setpoint resistance < **2 Ohm**

Short circuit between lines :

◆ Setpoint resistance > **0.9 MOhm**

Diagnosis information - Instrument cluster

Selector lever

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Signal implausible
- ♦ Open circuit
- ♦ Short circuit to ground
- ♦ Short circuit to B+
- ♦ Short circuit between the lines

Fault setting condition(s)

- Supply voltage 9 ... 16 V

Fault effects

- ♦ Function not available or available only to a limited extent

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

◆ Setpoint resistance < **2 Ohm**

Short circuit between lines :

◆ Setpoint resistance > **0.9 MOhm**

C11000

Diagnosis information - Instrument cluster

Power supply

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Limit exceeded
- ♦ Below limit

Fault setting condition(s)

- Supply voltage 9 ... 16 V

Fault effects

- ♦ Function not available or available only to a limited extent

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **-0.5 V** ⇒ **+0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

Short circuit between lines :

◆ Setpoint resistance > **0.9 MOhm**

C11001

Diagnosis information - Instrument cluster

Power supply

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Limit exceeded
- ♦ Below limit

Fault setting condition(s)

- Supply voltage 9 ... 16 V

Fault effects

- ♦ Function not available or available only to a limited extent

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **-0.5 V** ⇒ **+0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance > **0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance < **2 Ohm**

Short circuit between lines :

◆ Setpoint resistance > **0.9 MOhm**

Diagnosis information - Instrument cluster

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- incorrectly programmed
- not programmed

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Instrument cluster

Instrument cluster

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Faulty

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Instrument cluster

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- incorrectly coded
- not coded

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Instrument cluster

Calibration

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Calibration incorrect or not carried out

Fault effects

- ♦ Function not available or available only to a limited extent