

991 + 981 , MY 2012 =>

Diagnosis information - Stopwatch

008000.....	1
008001.....	2
008002.....	3
008003.....	4
008004.....	5
008005.....	6
C11000.....	7
C11001.....	8
C11005.....	9
C11006.....	10

008000

Diagnosis information - Control module Stopwatch

Control module faulty

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Control module Stopwatch** Faulty
- The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs. In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault effects

- ♦ **Control module Stopwatch** Limited function

Diagnosis information - Control module Stopwatch

Control module faulty

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Control module Stopwatch** Faulty
- The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs. In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault effects

- ♦ **Control module Stopwatch** Limited function

Diagnosis information - Control module Stopwatch

Control module faulty

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Control module Stopwatch** Faulty
- The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs. In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault effects

- ♦ **Control module Stopwatch** Limited function

Diagnosis information - Control module Stopwatch

Control module faulty

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Control module Stopwatch** Faulty
- The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs. In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault effects

- ♦ **Control module Stopwatch** Limited function

Diagnosis information - Control module Stopwatch

Control module faulty

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Control module Stopwatch** Faulty
- The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs. In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault effects

- ♦ **Control module Stopwatch** Limited function

Diagnosis information - Control module Stopwatch

Control module faulty

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Control module Stopwatch** Faulty
- The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs. In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault effects

- ♦ **Control module Stopwatch** Limited function

C11000

Diagnosis information - Control module Stopwatch

Supply voltage

DANGER

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Supply voltage < 9 V
- Supply voltage > 16 V

Fault effects

- ♦ Control module Stopwatch Limited function

C11001

Diagnosis information - Control module Stopwatch

Supply voltage

DANGER

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Supply voltage < 9 V
- Supply voltage > 16 V

Fault effects

- ♦ Control module Stopwatch Limited function

C11005

Diagnosis information - Control module Stopwatch

Control module faulty

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Control module Stopwatch** Faulty
- The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs. In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault effects

- ♦ **Control module Stopwatch** Limited function

C11006

Diagnosis information - Control module Stopwatch

Control module Coding

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- **Control module Stopwatch** no/incorrect coding/calibration

Fault effects

- ♦ **Control module Stopwatch** Limited function