

991/ 982, MY 2017-

Diagnosis information - Amplifier

000200.....	1
000202.....	2
000203.....	3
000204.....	4
000205.....	5
000207.....	6
000208.....	7
000209.....	8
000211.....	9
000212.....	10
000213.....	11
000230.....	12
000232.....	13
000233.....	14
000234.....	15
000235.....	16
000237.....	17
000238.....	18
000239.....	19
000241.....	20
000242.....	21
000243.....	22
000244.....	23
000246.....	24
000247.....	25
000248.....	26
000250.....	27
000251.....	28
000252.....	29
000254.....	30
000255.....	31
000256.....	32
000257.....	33
000259.....	34
000260.....	35
000261.....	36
000290.....	37
000291.....	38
000296.....	39

000297.....	40
000298.....	41
000299.....	42
000600.....	43
000601.....	44
000602.....	45
000603.....	46
000606.....	47
000607.....	48
000608.....	49
000614.....	50
000617.....	51
000631.....	52
000633.....	53
000635.....	54
000636.....	55
000640.....	56
000660.....	57
000661.....	58
000662.....	59
000663.....	60
000664.....	61
001003.....	62
001007.....	63
00020F.....	64
00023A.....	65
00023C.....	66
00023D.....	67
00023E.....	68
00023F.....	69
00024F.....	70
00025A.....	71
00025B.....	72
00025C.....	73
00025E.....	74
00025F.....	75
00028A.....	76
00028B.....	77
00028C.....	78

00028D.....	79
00029A.....	80
00029B.....	81
00029C.....	82
00029D.....	83
00029E.....	84
00029F.....	85
0002A2.....	86
0002A3.....	87
0002A4.....	88
0002A5.....	89
0002A6.....	90
0002A7.....	91
0002A8.....	92
0002A9.....	93
00060A.....	94
00060B.....	95
00060C.....	96
00060D.....	97
00061A.....	98
00061B.....	99
00061C.....	100
00063B.....	101
00100B.....	102
001A25.....	103
001A26.....	104
001A27.....	105
B106C96.....	106
B106CF3.....	107
B126B01.....	108
B129B11.....	109
B129B12.....	110
B129B13.....	111
B129C11.....	112
B129C12.....	113
B129C13.....	114
B13A001.....	115
B13A101.....	116
B13A401.....	117

B13A501.....	118
B13A801.....	119
B13A901.....	120
B13AA01.....	121
B13AB01.....	122
B13AC01.....	123
B13AD01.....	124
B13AE01.....	125
B13AF01.....	126
B15E811.....	127
B15E812.....	129
B15E813.....	131
B1765F0.....	133
B1853F1.....	134
B1853F5.....	135
B1853F8.....	136
B1853F9.....	137
B200045.....	138
B200046.....	139
B200500.....	140
B200500.....	141
B2008F0.....	142
B2008F0.....	143
B2009F0.....	144
B201200.....	145
B201200.....	146
D10000.....	147
EA6100.....	148
EA6200.....	149
EA6300.....	150
EA6400.....	151
U101100.....	152
U101200.....	153
U101300.....	154
U101400.....	155
U110000.....	156
U110100.....	157
U110100.....	158
U110100.....	159

U110100.....	160
U112100.....	161
U112200.....	162
U112300.....	163
U140000.....	164
U140100.....	165

Diagnostic information - amplifier

Front left/right loudspeaker - mid-range/woofer - open circuit

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance > **20 ohm**

Possible fault cause(s)

- Open circuit
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Front left/right loudspeaker - mid-range/woofer - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Front left/right loudspeaker - mid-range/woofer - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Front left/right loudspeaker - mid-range/woofer - short circuit between lines

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 0.5 ohm**

Possible fault cause(s)

- Short circuit between lines
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Front left/right loudspeaker - mid-range/woofer - open circuit

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance > **20 ohm**

Possible fault cause(s)

- Open circuit
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Front left/right loudspeaker - mid-range/woofer - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Front left/right loudspeaker - mid-range/woofer - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Front left/right loudspeaker - mid-range/woofer - short circuit between lines

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 0.5 ohm**

Possible fault cause(s)

- Short circuit between lines
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Subwoofer - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Internal fault in subwoofer
- Implausible signal

Fault effect(s)

- Subwoofer does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Subwoofer - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Internal fault in subwoofer
- Implausible signal

Fault effect(s)

- Subwoofer does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Subwoofer - short circuit between lines

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 0.5 ohm**

Possible fault cause(s)

- Short circuit between lines
- Lines and/or connectors corroded
- Internal fault in subwoofer
- Implausible signal

Fault effect(s)

- Subwoofer does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - mid-range - open circuit

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance > **20 ohm**

Possible fault cause(s)

- Open circuit
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - mid-range - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - mid-range - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - mid-range - short circuit between lines

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 0.5 ohm**

Possible fault cause(s)

- Short circuit between lines
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - mid-range - open circuit

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance > **20 ohm**

Possible fault cause(s)

- Open circuit
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - mid-range - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - mid-range - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - mid-range - short circuit between lines

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 0.5 ohm**

Possible fault cause(s)

- Short circuit between lines
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Front left/right loudspeaker - mid-range/woofer - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Front left/right loudspeaker - mid-range/woofer - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Front left/right loudspeaker - mid-range/woofer - short circuit between lines

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 0.5 ohm**

Possible fault cause(s)

- Short circuit between lines
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Center loudspeaker - open circuit

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance $\geq$ **20 ohm**

Possible fault cause(s)

- Open circuit
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V $\Rightarrow$ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance $\square$ **0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Center loudspeaker - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Center loudspeaker - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Center loudspeaker - short circuit between lines

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 0.5 ohm**

Possible fault cause(s)

- Short circuit between lines
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - tweeter - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - tweeter - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - tweeter - short circuit between lines

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 0.5 ohm**

Possible fault cause(s)

- Short circuit between lines
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - tweeter - open circuit

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance > **35 ohm**

Possible fault cause(s)

- Open circuit
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - tweeter - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - tweeter - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Rear left/right loudspeaker - tweeter - short circuit between lines

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 0.5 ohm**

Possible fault cause(s)

- Short circuit between lines
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Front left/right loudspeaker - tweeter - open circuit

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance > **35 ohm**

Possible fault cause(s)

- Open circuit
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**

Diagnostic information - amplifier

Front left/right loudspeaker - tweeter - short circuit to ground/B+

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on
- Battery positive voltage **10.8 V - 16 V**

Fault setting condition(s)

- Load resistance **< 3 ohm**

Possible fault cause(s)

- Short circuit to ground/B+
- Lines and/or connectors corroded
- Loudspeaker diaphragm faulty
- Internal fault in loudspeaker
- Implausible signal

Fault effect(s)

- Loudspeaker does not work
- Changed sound

Setpoint values for line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V ⇒ + 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **□ 0.9 Mohm**

Open circuit:

- ♦ Setpoint resistance **< 2 ohm**