

991 + 981 , MY 2012 =>

Diagnosis information - Steering wheel electronics

801004.....	1
801101.....	2
801102.....	3
801103.....	4
801203.....	5
801207.....	6
801301.....	7
801303.....	8
801304.....	9
801305.....	10
801401.....	11
801402.....	12
801403.....	13
801501.....	14
801601.....	15
801603.....	16
801605.....	17
801701.....	18
801703.....	19
801706.....	20
801710.....	21
801711.....	22
801712.....	23
801713.....	24
801901.....	25
802001.....	26
802100.....	27
802110.....	28
802201.....	29
802202.....	30
802203.....	31
802204.....	32
802210.....	33
802230.....	34
802231.....	35
802232.....	36
802304.....	37
802400.....	38
802401.....	39

802404.....	40
802410.....	41
802411.....	42
802414.....	43
802420.....	44
802421.....	45
802424.....	46
803001.....	47
803002.....	48
805001.....	49
805002.....	50
805003.....	51
805004.....	52
C11000.....	53
C11001.....	54
C11004.....	55
C11005.....	56
C11006.....	57
C11007.....	58

Diagnosis information - Steering wheel electronics control module

Steering-wheel lighting

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Short circuit to ground

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Steering-angle sensor

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Faulty
- Mechanical fault

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Steering-angle sensor

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Faulty
- Mechanical fault

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Steering-angle sensor

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Faulty
- Mechanical fault

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

High-beam/direction-indicator light switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, high-beam/direction-indicator light switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

High-beam/direction-indicator light switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, high-beam/direction-indicator light switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Wiper/washer system switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, wiper/washer system switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Wiper/washer system switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, wiper/washer system switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Wiper/washer system switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, wiper/washer system switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Wiper/washer system switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, wiper/washer system switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Front-wiper interval switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, front-wiper interval switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Front-wiper interval switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, front-wiper interval switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Front-wiper interval switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, front-wiper interval switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Windshield washer system (SRA) switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, headlight washer system button**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Switch, on-board computer

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, on-board computer switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Switch, on-board computer

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, on-board computer switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Switch, on-board computer

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, on-board computer switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Cruise-control/ACC ON/OFF button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, cruise-control/ACC ON/OFF button** , Signal not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Cruise-control/ACC ON/OFF button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, cruise-control/ACC ON/OFF button** , Signal not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Cruise-control/ACC ON/OFF button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, cruise-control/ACC ON/OFF button** , Signal not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Cruise control/adaptive cruise control (ACC) switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, cruise-control/ACC switch** , Signal not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Cruise control/adaptive cruise control (ACC) switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, cruise-control/ACC switch** , Signal not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Cruise control/adaptive cruise control (ACC) switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, cruise-control/ACC switch** , Signal not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Cruise control/adaptive cruise control (ACC) switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, cruise-control/ACC switch** , Signal not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Horn button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Button is stuck or permanently actuated.
- **Voltage value, horn button**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Voice-control button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, Voice-control button**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Rocker switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, rocker switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Rocker switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, rocker switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Steering-wheel heater

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Short circuit to ground
- Open circuit
- Current consumption Too high
- Current consumption too low

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Steering-wheel heater

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Short circuit to ground
- Open circuit
- Current consumption Too high
- Current consumption too low

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Steering-wheel heater

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Short circuit to ground
- Open circuit
- Current consumption Too high
- Current consumption too low

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Steering-wheel heater

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Short circuit to ground
- Open circuit
- Current consumption Too high
- Current consumption too low

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Steering-wheel heating switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Button is stuck or permanently actuated.
- **Voltage value, steering-wheel heating switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Steering-wheel heating switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Button is stuck or permanently actuated.
- **Voltage value, steering-wheel heating switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Steering-wheel temperature sensor

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Open circuit
- Signal implausible

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Steering-wheel temperature sensor

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Open circuit
- Signal implausible

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Windshield washer system (SRA) switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, headlight washer system button**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Remote control

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Signal implausible
- Short circuit to ground
- no communication

Fault effects

- ♦ Function not available or available only to a limited extent