

Diagnosis information - Steering wheel electronics control module

Remote control

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Signal implausible
- Short circuit to ground
- no communication

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Remote control

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Signal implausible
- Short circuit to ground
- no communication

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Remote control

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Signal implausible
- Short circuit to ground
- no communication

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Remote control

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Signal implausible
- Short circuit to ground
- no communication

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Remote control

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Signal implausible
- Short circuit to ground
- no communication

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Multi-function control unit

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Supply voltage**
- no communication

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Multi-function control unit

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Faulty

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Multi-function control unit

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Faulty

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Cruise-control/ACC ON/OFF button

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, cruise-control/ACC ON/OFF button** , Signal not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Rear-wiper switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, rear-wiper switch**, not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

ACC rocker switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, ACC rocker switch** , Signal not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

ACC rocker switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, ACC rocker switch** , Signal not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

ACC rocker switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, ACC rocker switch** , Signal not OK

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

ACC rocker switch

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- **Voltage value, ACC rocker switch** , Signal not OK

Fault effects

- ♦ Function not available or available only to a limited extent

C11000

Diagnosis information - Steering wheel electronics control module

Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Limit exceeded
- Below limit

Fault effects

- ♦ Function not available or available only to a limited extent

C11001

Diagnosis information - Steering wheel electronics control module

Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Limit exceeded
- Below limit

Fault effects

- ♦ Function not available or available only to a limited extent

C11004

Diagnosis information - Steering wheel electronics control module

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- - The data record does not match the vehicle.

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Steering wheel electronics control module

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Faulty

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Steering wheel electronics control module

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Coding incorrect or not carried out

Fault effects

◆ Only functions that are coded and are supported by the control unit are active.

Diagnosis information - Steering wheel electronics control module

Steering-angle sensor

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Supply voltage** 8 ... 16 V
- Terminal 15 (via CAN) Active

Fault setting condition(s)

- Calibration

Fault effects

- ♦ Function not available or available only to a limited extent