

991/ 982, MY 2017-

Diagnosis information - Lane Change Assist

B200000.....	1
B200043.....	2
B200044.....	3
B200045.....	4
B200047.....	5
B200087.....	6
B200087.....	7
B2000F0.....	8
B200100.....	9
B200100.....	10
B200500.....	11
B200500.....	12
B2008F0.....	13
B200FF0.....	14
B201200.....	15
B201200.....	16
B202200.....	17
C10C200.....	18
C111454.....	19
C1114F0.....	20
C1114F3.....	21
C111554.....	22
C11E7F0.....	23
C11E8F0.....	24
C11E900.....	25
C11F312.....	26
C11F313.....	28
U101100.....	30
U101200.....	31
U101300.....	32
U101400.....	33
U110000.....	34
U110100.....	35
U110300.....	36
U110500.....	37
U140000.....	38
U140100.....	39
999999.....	40

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault effects

- ♦ No function

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ◆ Function restriction

Fault effects

- ◆ No function

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ◆ Function restriction

Fault effects

- ◆ No function

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ◆ Function restriction

Fault effects

- ◆ No function

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ◆ Function restriction

Fault effects

- ◆ No function

Diagnosis information - Lane Change Assist control unit Master

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Programming incorrect or not carried out

Fault effects

- ♦ No function

Diagnosis information - Lane Change Assist control unit Slave

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Programming incorrect or not carried out

Fault effects

- ♦ No function

B2000F0

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault effects

- ♦ No function

Diagnosis information - Lane Change Assist control unit Master

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Programming incorrect or not carried out

Fault effects

- ♦ No function

Diagnosis information - Lane Change Assist control unit Slave

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Programming incorrect or not carried out

Fault effects

- ♦ No function

Diagnosis information - Lane Change Assist control unit Master

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Programming incorrect or not carried out

Fault effects

- ♦ No function

Diagnosis information - Lane Change Assist control unit Slave

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ◆ Programming incorrect or not carried out

Fault effects

- ◆ No function

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault effects

- ♦ No function

B200FF0

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault effects

- ♦ No function

Diagnosis information - Lane Change Assist control unit Master

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Programming incorrect or not carried out

Fault effects

- ♦ No function

Diagnosis information - Lane Change Assist control unit Slave

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ◆ Programming incorrect or not carried out

Fault effects

- ◆ No function

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ◆ Function restriction

Fault effects

- ◆ No function

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault effects

- ♦ No function

C111454

Diagnosis information - Lane Change Assist control unit

Calibration

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Calibration incorrect or not carried out

Fault effects

- ♦ Function not available or available only to a limited extent

C1114F0

Diagnosis information - Lane Change Assist control unit

Calibration

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Calibration incorrect or not carried out

Fault effects

- ♦ Function not available or available only to a limited extent

C1114F3

Diagnosis information - Lane Change Assist control unit

Calibration

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Calibration incorrect or not carried out

Fault effects

- ♦ Function not available or available only to a limited extent

C111554

Diagnosis information - Lane Change Assist control unit

Calibration

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Calibration incorrect or not carried out

Fault effects

- ♦ Function not available or available only to a limited extent

C11E7F0

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault effects

- ♦ No function

C11E8F0

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault effects

- ♦ No function

C11E900

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ◆ Function restriction

Fault effects

- ◆ No function

Diagnosis information - Lane Change Assist control unit

Lane Change Assist indicator light

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to ground
- ♦ Short circuit to B+
- ♦ Open circuit

Affected contacts on the control unit connector

- ♦ Contact 3

Fault effects

- ♦ No function

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

C11F313

Diagnosis information - Lane Change Assist control unit

Lane Change Assist indicator light

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to ground
- ♦ Short circuit to B+
- ♦ Open circuit

Affected contacts on the control unit connector

- ♦ Contact 3

Fault effects

- ♦ No function

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

U101100

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault effects

- ♦ No function

U101200

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault effects

- ♦ No function

U101300

Diagnosis information - Lane Change Assist control unit Master

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ◆ Coding incorrect or not carried out

Fault effects

- ◆ No function

U101400

Diagnosis information - Lane Change Assist control unit Master

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Coding incorrect or not carried out

Fault effects

- ♦ No function

U110000

Diagnosis information - Lane Change Assist control unit Master

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Coding incorrect or not carried out

Fault effects

- ♦ No function

U110100

Diagnosis information - Lane Change Assist control unit Master

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Coding incorrect or not carried out

Fault effects

- ♦ No function

U110300

Diagnosis information - Lane Change Assist control unit Master

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Coding incorrect or not carried out

Fault effects

- ♦ No function

U110500

Diagnosis information - Lane Change Assist control unit Master

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Coding incorrect or not carried out

Fault effects

- ♦ No function

U140000

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ◆ Function restriction

Fault effects

- ◆ No function

U140100

Diagnosis information - Lane Change Assist control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault effects

- ♦ No function