

Diagnosis information - Reversing camera control unit

Activation line to PCM

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Short circuit to ground : Voltage internal < (internal monitoring voltage - 5,7 V)
- Short circuit to B+ : Voltage internal > (internal monitoring voltage + 0,4 V) with Activation Active or Voltage internal > 6 V at Activation not active
- Open circuit: internal monitoring voltage - 1,48 V to + 0,4 V

Fault effects

- ♦ none Activation of PCM

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Diagnosis information - Reversing camera control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault setting condition(s)

- Internal control unit fault

Fault effects

- ♦ No function

Diagnosis information - Reversing camera control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault setting condition(s)

- Internal control unit fault

Fault effects

- ♦ No function

Diagnosis information - Reversing camera control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault setting condition(s)

- Internal control unit fault

Fault effects

- ♦ No function

Diagnosis information - Reversing camera control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault setting condition(s)

- Internal control unit fault

Fault effects

- ♦ No function

Diagnosis information - Reversing camera control unit

Function restriction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Function restriction

Fault setting condition(s)

- Internal control unit fault

Fault effects

- ♦ No function

Diagnosis information - Reversing camera control unit

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- PCM on

Possible fault causes

- ♦ Coding incorrect or not carried out

Fault effects

- ♦ Function temporarily unavailable or available only to a limited extent

Diagnosis information - Reversing camera control unit

Camera not calibrated

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- At least one of the coded cameras is not calibrated

Fault effects

- ♦ Function not available or available only to a limited extent

A010F1

Diagnosis information - Reversing camera control unit

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- PCM on

Possible fault causes

- ♦ Coding incorrect or not carried out

Fault effects

- ♦ Function temporarily unavailable or available only to a limited extent

Diagnosis information - Reversing camera control unit

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- PCM on

Possible fault causes

- ♦ Coding incorrect or not carried out

Fault effects

- ♦ Function temporarily unavailable or available only to a limited extent

Diagnosis information - Reversing camera control unit

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- PCM on

Possible fault causes

- ♦ Coding incorrect or not carried out

Fault effects

- ♦ Function temporarily unavailable or available only to a limited extent

Diagnostic information - reversing camera control unit

Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Battery
- ♦ **Three-phase generator**
- ♦ Fuse
- ♦ Wiring harness
- ♦ **Reversing camera control unit**

Check affected contacts on plug A of the reversing-camera control unit

- ♦ Check power supply at terminals 30 and 31 according to the current wiring diagram

Fault setting condition(s)

- **Supply voltage** < 9 V
- **Supply voltage** > 15 V

Fault effects

- ♦ No function

Diagnostic information - reversing camera control unit

Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Battery
- ♦ **Three-phase generator**
- ♦ Fuse
- ♦ Wiring harness
- ♦ **Reversing camera control unit**

Check affected contacts on plug A of the reversing-camera control unit

- ♦ Check power supply at terminals 30 and 31 according to the current wiring diagram

Fault setting condition(s)

- **Supply voltage** < 9 V
- **Supply voltage** > 15 V

Fault effects

- ♦ No function

D01300

Diagnosis information - Reversing camera control unit

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- PCM on

Possible fault causes

- ♦ Coding incorrect or not carried out

Fault effects

- ♦ Function temporarily unavailable or available only to a limited extent