

Diagnostic information - ParkAssist

ParkAssist ultrasound sensor

DANGER

Increased risk of accidents due to movement of the vehicle!

- ♦ Never step in front of or behind a vehicle unless it has been secured against rolling by the parking brake and transmission.
- ♦ The ParkAssist is subject to physical detection limits and does not free the driver from his/her responsibility to be careful.
- ♦ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavourable reflective characteristics, e.g. snow or glass.

Diagnostic conditions

- Internal function test on ParkAssist control unit
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

INFORMATION

Fault entry due to ambient conditions: this fault can also occur if the sensors are heavily soiled, iced-up or have been painted. In addition, intense sound sources such as pneumatic hammers can cause interference.

- Signal lead Short circuit to B+/ground or open circuit in the line
- **Supply line**
- **Ground line**
- **ParkAssist ultrasound sensor** faulty

Fault effects

- ♦ System switches off
- ♦ Display in instrument cluster

Diagnostic information - ParkAssist

ParkAssist ultrasound sensor

DANGER

Increased risk of accidents due to movement of the vehicle!

- ♦ Never step in front of or behind a vehicle unless it has been secured against rolling by the parking brake and transmission.
- ♦ The ParkAssist is subject to physical detection limits and does not free the driver from his/her responsibility to be careful.
- ♦ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavourable reflective characteristics, e.g. snow or glass.

Diagnostic conditions

- Internal function test on ParkAssist control unit
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

i INFORMATION

Fault entry due to ambient conditions: this fault can also occur if the sensors are heavily soiled, iced-up or have been painted. In addition, intense sound sources such as pneumatic hammers can cause interference.

- Signal lead Short circuit to B+/ground or open circuit in the line
- **Supply line**
- **Ground line**
- **ParkAssist ultrasound sensor** faulty

Fault effects

- ♦ System switches off
- ♦ Display in instrument cluster

Diagnostic information - ParkAssist

ParkAssist ultrasound sensor

DANGER

Increased risk of accidents due to movement of the vehicle!

- ♦ Never step in front of or behind a vehicle unless it has been secured against rolling by the parking brake and transmission.
- ♦ The ParkAssist is subject to physical detection limits and does not free the driver from his/her responsibility to be careful.
- ♦ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavourable reflective characteristics, e.g. snow or glass.

Diagnostic conditions

- Internal function test on ParkAssist control unit
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

i INFORMATION

Fault entry due to ambient conditions: this fault can also occur if the sensors are heavily soiled, iced-up or have been painted. In addition, intense sound sources such as pneumatic hammers can cause interference.

- Signal lead Short circuit to B+/ground or open circuit in the line
- **Supply line**
- **Ground line**
- **ParkAssist ultrasound sensor** faulty

Fault effects

- ♦ System switches off
- ♦ Display in instrument cluster

Diagnostic information - ParkAssist

ParkAssist ultrasound sensor

DANGER

Increased risk of accidents due to movement of the vehicle!

- ♦ Never step in front of or behind a vehicle unless it has been secured against rolling by the parking brake and transmission.
- ♦ The ParkAssist is subject to physical detection limits and does not free the driver from his/her responsibility to be careful.
- ♦ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavourable reflective characteristics, e.g. snow or glass.

Diagnostic conditions

- Internal function test on ParkAssist control unit
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

i INFORMATION

Fault entry due to ambient conditions: this fault can also occur if the sensors are heavily soiled, iced-up or have been painted. In addition, intense sound sources such as pneumatic hammers can cause interference.

- Signal lead Short circuit to B+/ground or open circuit in the line
- **Supply line**
- **Ground line**
- **ParkAssist ultrasound sensor** faulty

Fault effects

- ♦ System switches off
- ♦ Display in instrument cluster

Diagnostic information - ParkAssist

ParkAssist ultrasound sensor

DANGER

Increased risk of accidents due to movement of the vehicle!

- ♦ Never step in front of or behind a vehicle unless it has been secured against rolling by the parking brake and transmission.
- ♦ The ParkAssist is subject to physical detection limits and does not free the driver from his/her responsibility to be careful.
- ♦ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavourable reflective characteristics, e.g. snow or glass.

Diagnostic conditions

- Internal function test on ParkAssist control unit
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

INFORMATION

Fault entry due to ambient conditions: this fault can also occur if the sensors are heavily soiled, iced-up or have been painted. In addition, intense sound sources such as pneumatic hammers can cause interference.

- Signal lead Short circuit to B+/ground or open circuit in the line
- **Supply line**
- **Ground line**
- **ParkAssist ultrasound sensor** faulty

Fault effects

- ♦ System switches off
- ♦ Display in instrument cluster

Diagnostic information - ParkAssist

ParkAssist control module

DANGER

Increased risk of accidents due to movement of the vehicle!

- ♦ Never step in front of or behind a vehicle unless it has been secured against rolling by the parking brake and transmission.
- ♦ The ParkAssist is subject to physical detection limits and does not free the driver from his/her responsibility to be careful.
- ♦ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavourable reflective characteristics, e.g. snow or glass.

Diagnostic conditions

- Internal function test on ParkAssist control unit
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

INFORMATION

Fault entry due to ambient conditions: this fault can also occur if the sensors are heavily soiled, iced-up or have been painted. In addition, intense sound sources such as pneumatic hammers can cause interference.

- ParkAssist control unit faulty

Fault effects

- ♦ System switches off
- ♦ Display in instrument cluster

Diagnostic information - ParkAssist

ParkAssist control module

DANGER

Increased risk of accidents due to movement of the vehicle!

- ♦ Never step in front of or behind a vehicle unless it has been secured against rolling by the parking brake and transmission.
- ♦ The ParkAssist is subject to physical detection limits and does not free the driver from his/her responsibility to be careful.
- ♦ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavourable reflective characteristics, e.g. snow or glass.

Diagnostic conditions

- Internal function test on ParkAssist control unit
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

INFORMATION

Fault entry due to ambient conditions: this fault can also occur if the sensors are heavily soiled, iced-up or have been painted. In addition, intense sound sources such as pneumatic hammers can cause interference.

- ParkAssist control unit faulty

Fault effects

- ♦ System switches off
- ♦ Display in instrument cluster

Diagnostic information - ParkAssist

ParkAssist control module

DANGER

Increased risk of accidents due to movement of the vehicle!

- ♦ Never step in front of or behind a vehicle unless it has been secured against rolling by the parking brake and transmission.
- ♦ The ParkAssist is subject to physical detection limits and does not free the driver from his/her responsibility to be careful.
- ♦ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavourable reflective characteristics, e.g. snow or glass.

Diagnostic conditions

- Internal function test on ParkAssist control unit
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

INFORMATION

Fault entry due to ambient conditions: this fault can also occur if the sensors are heavily soiled, iced-up or have been painted. In addition, intense sound sources such as pneumatic hammers can cause interference.

- ParkAssist control unit faulty

Fault effects

- ♦ System switches off
- ♦ Display in instrument cluster

Diagnostic information - ParkAssist

Incorrect programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Programming incorrect or not carried out
- ♦ No/incorrect programming

Fault effects

No function

Diagnostic information - ParkAssist

No/incorrect coding

DANGER

Increased risk of accidents due to movement of the vehicle!

- ♦ Never step in front of or behind a vehicle unless it has been secured against rolling by the parking brake and transmission.
- ♦ The ParkAssist is subject to physical detection limits and does not free the driver from his/her responsibility to be careful.
- ♦ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavourable reflective characteristics, e.g. snow or glass.

INFORMATION

- The sensors are supplied with power only when the ignition is switched on and with the Shift lever or selector lever in position R.

Diagnostic conditions

- Internal function test on ParkAssist control unit
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

- ParkAssist control unit not coded or incorrect coding/parameters set
- Control unit is in wrong mode (Production) --> Perform coding
- ParkAssist control unit faulty

Fault effects

- ♦ System does not function
- ♦ Display in instrument cluster

Diagnostic information - ParkAssist

ParkAssist control unit, supply voltage

DANGER

Increased risk of accidents due to movement of the vehicle!

- ◆ Never stand in front of or behind a vehicle that has not been secured against rolling away by the parking brake and transmission.
- ◆ The **ParkAssist** system has physical detection limits. The driver is ultimately responsible for taking utmost care while driving.
- ◆ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavorable reflective characteristics, e.g. snow or glass.

INFORMATION

- The sensors are supplied with power only when the ignition is switched on and with the shift lever or selector lever in position R.

Diagnostic conditions

- Internal function test on **ParkAssist control unit**
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

- Supply voltage, overvoltage or undervoltage
- Supply voltage, below limit value
- Supply voltage, above limit value

Possible fault causes

- Fuse (terminal 15) in fuse box faulty
- Faulty line connection between fuse box and **ParkAssist control unit** (open circuit, short circuit to ground)
- Relay (terminal 15) faulty
- Relay (terminal 15) activation faulty
- Main fuse in main fuse box faulty
- Line connection between fuse box and main fuse faulty
- **ParkAssist control unit** faulty

Fault effects

- ◆ System switches off
- ◆ Display in instrument cluster

Diagnostic information - ParkAssist

ParkAssist control unit, supply voltage

⚠ DANGER

Increased risk of accidents due to movement of the vehicle!

- ◆ Never stand in front of or behind a vehicle that has not been secured against rolling away by the parking brake and transmission.
- ◆ The **ParkAssist** system has physical detection limits. The driver is ultimately responsible for taking utmost care while driving.
- ◆ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavorable reflective characteristics, e.g. snow or glass.

i INFORMATION

- The sensors are supplied with power only when the ignition is switched on and with the shift lever or selector lever in position R.

Diagnostic conditions

- Internal function test on **ParkAssist control unit**
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

- Supply voltage, overvoltage or undervoltage
- Supply voltage, below limit value
- Supply voltage, above limit value

Possible fault causes

- Fuse (terminal 15) in fuse box faulty
- Faulty line connection between fuse box and **ParkAssist control unit** (open circuit, short circuit to ground)
- Relay (terminal 15) faulty
- Relay (terminal 15) activation faulty
- Main fuse in main fuse box faulty
- Line connection between fuse box and main fuse faulty
- **ParkAssist control unit** faulty

Fault effects

- ◆ System switches off
- ◆ Display in instrument cluster

Diagnostic information - ParkAssist

No/incorrect coding

DANGER

Increased risk of accidents due to movement of the vehicle!

- ♦ Never step in front of or behind a vehicle unless it has been secured against rolling by the parking brake and transmission.
- ♦ The ParkAssist is subject to physical detection limits and does not free the driver from his/her responsibility to be careful.
- ♦ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavourable reflective characteristics, e.g. snow or glass.

INFORMATION

- The sensors are supplied with power only when the ignition is switched on and with the Shift lever or selector lever in position R.

Diagnostic conditions

- Internal function test on ParkAssist control unit
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

- ParkAssist control unit not coded or incorrect coding/parameters set
- Control unit is in wrong mode (Production) --> Perform coding
- ParkAssist control unit faulty

Fault effects

- ♦ System does not function
- ♦ Display in instrument cluster

Diagnostic information - ParkAssist

ParkAssist control unit, supply voltage

⚠ DANGER

Increased risk of accidents due to movement of the vehicle!

- ◆ Never stand in front of or behind a vehicle that has not been secured against rolling away by the parking brake and transmission.
- ◆ The **ParkAssist** system has physical detection limits. The driver is ultimately responsible for taking utmost care while driving.
- ◆ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavorable reflective characteristics, e.g. snow or glass.

i INFORMATION

- The sensors are supplied with power only when the ignition is switched on and with the shift lever or selector lever in position R.

Diagnostic conditions

- Internal function test on **ParkAssist control unit**
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

- Supply voltage, overvoltage or undervoltage
- Supply voltage, below limit value
- Supply voltage, above limit value

Possible fault causes

- Fuse (terminal 15) in fuse box faulty
- Faulty line connection between fuse box and **ParkAssist control unit** (open circuit, short circuit to ground)
- Relay (terminal 15) faulty
- Relay (terminal 15) activation faulty
- Main fuse in main fuse box faulty
- Line connection between fuse box and main fuse faulty
- **ParkAssist control unit** faulty

Fault effects

- ◆ System switches off
- ◆ Display in instrument cluster

Diagnostic information - ParkAssist

ParkAssist control unit, supply voltage

DANGER

Increased risk of accidents due to movement of the vehicle!

- ◆ Never stand in front of or behind a vehicle that has not been secured against rolling away by the parking brake and transmission.
- ◆ The **ParkAssist** system has physical detection limits. The driver is ultimately responsible for taking utmost care while driving.
- ◆ The system cannot detect short, thin and small obstacles and persons who are lying on the ground. It also cannot detect surfaces with unfavorable reflective characteristics, e.g. snow or glass.

INFORMATION

- The sensors are supplied with power only when the ignition is switched on and with the shift lever or selector lever in position R.

Diagnostic conditions

- Internal function test on **ParkAssist control unit**
- Ignition on
- Reverse gear or transmission range R selected
- Vehicle speed briefly higher than 14 km/h (9 mph)

Fault setting condition(s)

- Supply voltage, overvoltage or undervoltage
- Supply voltage, below limit value
- Supply voltage, above limit value

Possible fault causes

- Fuse (terminal 15) in fuse box faulty
- Faulty line connection between fuse box and **ParkAssist control unit** (open circuit, short circuit to ground)
- Relay (terminal 15) faulty
- Relay (terminal 15) activation faulty
- Main fuse in main fuse box faulty
- Line connection between fuse box and main fuse faulty
- **ParkAssist control unit** faulty

Fault effects

- ◆ System switches off
- ◆ Display in instrument cluster