

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ♦ Do not look directly into the light beam.

NOTE

- ♦ The lights should always be switched off before removing and installing the headlights.
- ♦ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line
- ♦ Line connection or contacts to **Servo motor** faulty
- ♦ Power or ground supply faulty
- ♦ **Servo motor** overheated
- ♦ **Servo motor** mechanical blocked
- ♦ **Servo motor** Faulty
- ♦ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ♦ Do not look directly into the light beam.

NOTE

- ♦ The lights should always be switched off before removing and installing the headlights.
- ♦ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line
- ♦ Line connection or contacts to **Servo motor** faulty
- ♦ Power or ground supply faulty
- ♦ **Servo motor** overheated
- ♦ **Servo motor** mechanical blocked
- ♦ **Servo motor** Faulty
- ♦ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Headlights

Bulb stat. Cornering light

WARNING

HBA Xenon: Electric shock and burns from high voltage.

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Only operate the gas-discharge lamp when installed in the headlight.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

- Headlights switched on
- Ignition on

Fault setting condition(s)

- Bulb Cornering light
- Lines/connections

Fault effects

- ◆ System switches off
- ◆ Display in instrument cluster

Diagnostic information - Headlights

Bulb stat. Cornering light

WARNING

HBA Xenon: Electric shock and burns from high voltage.

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Only operate the gas-discharge lamp when installed in the headlight.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

- Headlights switched on
- Ignition on

Fault setting condition(s)

- Bulb Cornering light
- Lines/connections

Fault effects

- ◆ System switches off
- ◆ Display in instrument cluster

Diagnosis information - Lamp adjustment control unit

Supply voltage

⚠ CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Undervoltage (Voltage < 8 V)
- Overvoltage (Voltage > 16 V)

Fault effects

- ◆ **Adaptive Frontlighting System** Function not available or available only to a limited extent

Diagnosis information - Headlight control unit (central)

Control module , not coded

Control module , incorrectly coded

NOTE

- ♦ The lights should always be switched off before removing and installing the headlights.
- ♦ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Headlight control unit (central) not coded
- ♦ Headlight control unit (central) incorrectly coded
- ♦ Headlight control unit (central) Faulty

Diagnosis information - Headlight control unit (central)

Control module , not coded

Control module , incorrectly coded

NOTE

- ♦ The lights should always be switched off before removing and installing the headlights.
- ♦ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Headlight control unit (central) not coded
- ♦ Headlight control unit (central) incorrectly coded
- ♦ Headlight control unit (central) Faulty

Diagnostic information - CAN

Fault entry in the specified control unit

INFORMATION

Internal function test completed.

Diagnostic conditions

The control unit initially tests internal function sequences during wake-up. If these are OK, all diagnosable outputs are then tested and any faults are stored.

Wake-up of the control unit by:

- Event-controlled CAN message
- Wake-up signal via wake-up line
- Key contact (terminal S)
- Ignition on

Possible fault causes

- ♦ Incorrect control unit coding
- ♦ The peripheral equipment connected to the specified control unit is faulty
- ♦ Control unit faulty (in most cases, faulty coding is the cause and not the control unit)

Fault effects

- ♦ The stated control unit sends only substitute values via the CAN
- ♦ Other control units detect these substitute values and set this fault code

Diagnosis information - Lamp adjustment control unit

LIN bus

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Servo motor** no communication

Possible fault causes

- ◆ Unjustified entry due to software error in some cases; this can be deleted with dipped beam ON
- ◆ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ◆ **Adaptive Frontlighting System** Function not available or available only to a limited extent

Diagnosis information - Lamp adjustment control unit

LIN bus

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Servo motor** no communication

Possible fault causes

- ◆ Unjustified entry due to software error in some cases; this can be deleted with dipped beam ON
- ◆ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ◆ **Adaptive Frontlighting System** Function not available or available only to a limited extent

Diagnosis information - Lamp adjustment control unit

LIN bus

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- **Servo motor** no communication

Possible fault causes

- ◆ Unjustified entry due to software error in some cases; this can be deleted with dipped beam ON
- ◆ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

- ◆ **Adaptive Frontlighting System** Function not available or available only to a limited extent

00C058

INFORMATION

No information is available at present for this fault code.

Please contact your importer if necessary.

Diagnosis information - Lamp adjustment control unit

Supply voltage

⚠ CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Undervoltage (Voltage < 8 V)
- Overvoltage (Voltage > 16 V)

Fault effects

- ◆ **Adaptive Frontlighting System** Function not available or available only to a limited extent

Diagnosis information - Lamp adjustment control unit

Supply voltage

⚠ CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Undervoltage (Voltage < 8 V)
- Overvoltage (Voltage > 16 V)

Fault effects

- ◆ **Adaptive Frontlighting System** Function not available or available only to a limited extent

Diagnosis information - Lamp adjustment control unit

Supply voltage

⚠ CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Undervoltage (Voltage < 8 V)
- Overvoltage (Voltage > 16 V)

Fault effects

- ◆ **Adaptive Frontlighting System** Function not available or available only to a limited extent

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ♦ Do not look directly into the light beam.

NOTE

- ♦ The lights should always be switched off before removing and installing the headlights.
- ♦ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line
- ♦ Line connection or contacts to **Servo motor** faulty
- ♦ Power or ground supply faulty
- ♦ **Servo motor** overheated
- ♦ **Servo motor** mechanical blocked
- ♦ **Servo motor** Faulty
- ♦ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ♦ Do not look directly into the light beam.

NOTE

- ♦ The lights should always be switched off before removing and installing the headlights.
- ♦ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line
- ♦ Line connection or contacts to **Servo motor** faulty
- ♦ Power or ground supply faulty
- ♦ **Servo motor** overheated
- ♦ **Servo motor** mechanical blocked
- ♦ **Servo motor** Faulty
- ♦ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ♦ Do not look directly into the light beam.

NOTE

- ♦ The lights should always be switched off before removing and installing the headlights.
- ♦ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line
- ♦ Line connection or contacts to **Servo motor** faulty
- ♦ Power or ground supply faulty
- ♦ **Servo motor** overheated
- ♦ **Servo motor** mechanical blocked
- ♦ **Servo motor** Faulty
- ♦ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded

Diagnostic information - Lamp adjustment control unit

Servo motor / Adjusting motor

CAUTION

Danger of eye injuries due to bright light!

- ◆ Do not look directly into the light beam.

NOTE

- ◆ The lights should always be switched off before removing and installing the headlights.
- ◆ Carry out repair work on the headlight or wiring only with the component removed and separated from the voltage supply.

Diagnostic conditions

The control unit tests internal functional sequences when the ignition is switched on (terminal 15).

All diagnosable connections are checked and any faults are stored.

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Headlights switched on

Possible fault causes

- ◆ Short circuit to B+/ground or open circuit in the line
- ◆ Line connection or contacts to **Servo motor** faulty
- ◆ Power or ground supply faulty
- ◆ **Servo motor** overheated
- ◆ **Servo motor** mechanical blocked
- ◆ **Servo motor** Faulty
- ◆ **Lamp adjustment control unit** incorrectly coded