

Diagnosis information - Front-end electronics

Electronic ignition starting switch Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Keys in the **Ignition lock**

Possible fault causes

- ♦ Switch in the **Ignition lock** faulty
- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

Engine start **not** possible

Diagnosis information - Front-end electronics

Electronic ignition starting switch Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Keys in the **Ignition lock**

Possible fault causes

- ♦ Switch in the **Ignition lock** faulty
- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

Engine start **not** possible

Diagnosis information - Front-end electronics

Electronic ignition starting switch Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Keys in the **Ignition lock**

Possible fault causes

- ♦ Switch in the **Ignition lock** faulty
- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

Engine start **not** possible

Diagnosis information - Front-end electronics

Electronic ignition starting switch Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Keys in the **Ignition lock**

Possible fault causes

- ♦ Switch in the **Ignition lock** faulty
- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

Engine start **not** possible

Diagnosis information - Front-end electronics

Electronic ignition starting switch Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Keys in the **Ignition lock**

Possible fault causes

- ♦ Switch in the **Ignition lock** faulty
- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

Engine start **not** possible

Diagnosis information - Front-end electronics

Electronic ignition starting switch Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Keys in the **Ignition lock**

Possible fault causes

- ♦ Switch in the **Ignition lock** faulty
- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

Engine start **not** possible

Diagnosis information - Front-end electronics

Electronic ignition starting switch Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Keys in the **Ignition lock**

Possible fault causes

- ♦ Switch in the **Ignition lock** faulty
- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

Engine start **not** possible

Diagnosis information - Front-end electronics

Heating Windscreen washer system spray nozzle Short circuit

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

♦ **Supply line Front-end electronics <-> Windscreen washer system spray nozzle:** Short circuit to ground

Fault effects

Heating **Windscreen washer system spray nozzle** No function

Diagnosis information - Front-end electronics

Direction indicator light Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Direction indicator light No function

Diagnosis information - Front-end electronics

Direction indicator light Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Direction indicator light No function

Diagnosis information - Front-end electronics

Direction indicator light Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Direction indicator light No function

Diagnosis information - Front-end electronics

Direction indicator light Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Direction indicator light No function

Diagnosis information - Front-end electronics

Side direction indicator Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Side direction indicator No function

Diagnosis information - Front-end electronics

Side direction indicator Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Side direction indicator No function

Diagnosis information - Front-end electronics

Side light Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault setting condition(s)

- Ignition on

Fault effects

Side light No function

Diagnosis information - Front-end electronics

Side light Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Fault setting condition(s)

- Ignition on

Fault effects

Side light No function

Diagnosis information - Front-end electronics

Dipped beam headlight Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Dipped beam headlight No function

Diagnosis information - Front-end electronics

Dipped beam headlight Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Dipped beam headlight No function

件上的泄漏：

必须使用查漏喷剂或肥皂水鉴定，并且在施加所需压力之后，必须通过拍照或拍摄视频进行记录。

：

形成或已形成液滴的雾化/冷凝相关，则在烘干受影响区域之前和之后必须拍照或拍摄视频，以便记录部件中

部件上的泄漏。区分如下：

形成液滴的泄漏（“出油”）：

，因为这在保修和善意索赔情况下并非缺陷。

的泄漏：

立即验证，则只需在 PQIS 中提供清楚显示受影响部件的图片以及问题的正确详细信息即可。

立即验证，则必须使用以下程序使问题清楚可见并进行相应的记录。

影响区域存在严重的污渍，则应在清洁区域之前拍照，以便记录涉及的其他工作。

关区域之后，为其喷洒滑石粉/Spotcheck。

行试驾或让发动机运转，直至达到部件的工作温度。（随后必须让部件冷却下来，因为部件可能仅在冷却下才发生泄漏）

确认准确的泄漏源位置或发生泄漏的部件。

在可验证，则必须通过拍摄更多照片来记录泄漏原因。

即重现故障，则与客户进行交谈，以确定如何处理。

正的投诉：

可通过声音察觉到（表现为噪音）。

可能涉及到来自以下系统或部件的异常噪音：

件。

，需要提供声音文件，以便在质量分析和质量保证（保时捷股份公司）期间找到造成噪音的原因。

缺陷和噪音，通过视频短片展示问题/缺陷非常有必要/有用。对于视频，同样存在与文件大小、文件格式和的规范（参见上文）。

必须包含损坏/损坏环境的详细描述（如准确的故障位置、天气和路况、变速箱档位、行驶速度和发动机转

-众筹联盟】每人/年2千G，1万G好资料/视频/教程/数据！新会员先送1千G！还有红包！

国产-新能源-柴油-工程师-改装-专检-防盗-电脑板-案例-课程-数据 V: 1529-888-2340

s and diagnosable

To perform the check,
fault memory again.

Diagnosis information - Front-end electronics

High beam Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

High beam No function

Diagnosis information - Front-end electronics

Auxiliary high beam headlight Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Auxiliary high beam headlight No function

Diagnosis information - Front-end electronics

Auxiliary high beam headlight Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Auxiliary high beam headlight No function

Diagnosis information - Front-end electronics

Side direction indicator Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Side direction indicator No function

Diagnosis information - Front-end electronics

Side direction indicator Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

Possible fault causes

- ◆ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Side direction indicator No function

Diagnosis information - Front-end electronics

Dipped-beam screen Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Headlight cover No function

Diagnosis information - Front-end electronics

Dipped-beam screen Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Headlight cover No function

Diagnosis information - Front-end electronics

Servo motor for headlight beam adjustment Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line
- ♦ **Servo motor for headlight beam adjustment** Faulty

Fault effects

Servo motor for headlight beam adjustment No function

Diagnosis information - Front-end electronics

Servo motor for headlight beam adjustment Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line
- ♦ **Servo motor for headlight beam adjustment** Faulty

Fault effects

Servo motor for headlight beam adjustment No function

Diagnosis information - Front-end electronics

Angle sensor Headlight beam adjustment not calibrated

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- **Angle sensor Headlight beam adjustment** not calibrated

Fault effects

Headlight beam adjustment No function

Diagnostic information - front-end electronics

Headlight beam adjustment angle sensor - short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Short circuit to B+/ground or open circuit in the line

Fault finding notes

- Separate lines for power supply and signal transmission between the sensor and control unit

Fault effects

- ♦ Headlight beam adjustment does not function

Diagnostic information - front-end electronics

Headlight beam adjustment angle sensor - short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Short circuit to B+/ground or open circuit in the line

Fault finding notes

- Separate lines for power supply and signal transmission between the sensor and control unit

Fault effects

- ♦ Headlight beam adjustment does not function

Diagnosis information - Front-end electronics

Headlight washer system pump Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground/between lines or open circuit in the lines

Fault effects

Headlight washer system pump No function

Diagnosis information - Front-end electronics

Antenna Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

- Vehicle access system (KESSY): Function not available or available only to a limited extent

Diagnosis information - Front-end electronics

Antenna Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

- Vehicle access system (KESSY): Function not available or available only to a limited extent

Diagnosis information - Front-end electronics

Antenna Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

- Vehicle access system (KESSY): Function not available or available only to a limited extent

Diagnosis information - Front-end electronics

Antenna Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

- Vehicle access system (KESSY): Function not available or available only to a limited extent

Diagnosis information - Front-end electronics

Antenna Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

- Vehicle access system (KESSY): Function not available or available only to a limited extent

Diagnosis information - Front-end electronics

Antenna Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

- Vehicle access system (KESSY): Function not available or available only to a limited extent

Diagnosis information - Front-end electronics

Antenna Short circuit to B+/ground or open circuit in the line

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to B+/ground or open circuit in the line

Fault effects

- Vehicle access system (KESSY): Function not available or available only to a limited extent

Diagnosis information - Front-end electronics

Front-end electronics Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault effects

- **Front-end electronics** No function