

Diagnosis information - Front camera control unit

Front camera glass heating

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Short circuit to ground
- ♦ Short circuit to B+
- ♦ Open circuit
- ♦ Short circuit between the lines

Fault effects

- ♦ Function not available or available only to a limited extent

Setpoint definitions

NOTE

The specified values and value ranges correspond to the OK state in each case.

Line test

Short circuit to B+:

- ♦ Setpoint voltage **- 0.5 V** $\Rightarrow$ **+ 0.5 V**

Short circuit to ground:

- ♦ Setpoint resistance **> 0.9 MOhm**

Open circuit:

- ♦ Setpoint resistance **< 2 Ohm**

Short circuit between lines :

- ♦ Setpoint resistance **> 0.9 MOhm**

Diagnosis information - Front camera control unit

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Coding incorrect or not carried out
- ♦ Faulty data record
- ♦ Incorrect data record
- ♦ Vehicle Identification Number (VIN) incorrect

Fault effects

- ♦ Function temporarily unavailable or available only to a limited extent

Diagnosis information - Front camera control unit

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Coding incorrect or not carried out
- ♦ Faulty data record
- ♦ Incorrect data record
- ♦ Vehicle Identification Number (VIN) incorrect

Fault effects

- ♦ Function temporarily unavailable or available only to a limited extent

Diagnosis information - Front camera control unit

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Programming incorrect or not carried out
- ♦ Faulty data record
- ♦ Incorrect data record

Fault effects

- ♦ Function temporarily unavailable or available only to a limited extent

Diagnosis information - Front camera control unit

Programming

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Programming incorrect or not carried out
- ♦ Faulty data record
- ♦ Incorrect data record

Fault effects

- ♦ Function temporarily unavailable or available only to a limited extent

Diagnosis information - Front camera control unit

Calibration

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Calibration incorrect or not carried out
- Calibration failed

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Front camera control unit

Calibration

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Calibration incorrect or not carried out
- Calibration failed

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Front camera control unit

Calibration

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Calibration incorrect or not carried out
- Calibration failed

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Front camera control unit

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Coding incorrect or not carried out
- ♦ Faulty data record
- ♦ Incorrect data record
- ♦ Vehicle Identification Number (VIN) incorrect

Fault effects

- ♦ Function temporarily unavailable or available only to a limited extent

Diagnosis information - Front camera control unit

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ◆ Coding incorrect or not carried out
- ◆ Faulty data record
- ◆ Incorrect data record
- ◆ Vehicle Identification Number (VIN) incorrect

Fault effects

- ◆ Function temporarily unavailable or available only to a limited extent

Diagnosis information - Front camera control unit

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Coding incorrect or not carried out
- ♦ Faulty data record
- ♦ Incorrect data record
- ♦ Vehicle Identification Number (VIN) incorrect

Fault effects

- ♦ Function temporarily unavailable or available only to a limited extent

Diagnosis information - Front camera control unit

Front camera control unit

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Function restriction

Fault effects

- ♦ Function not available or available only to a limited extent

010000

Diagnosis information - Front camera control unit

Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Battery
- ♦ **Alternator**
- ♦ Fuse
- ♦ Wiring harness

Fault setting condition(s)

- Limit exceeded
- Below limit

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - Front camera control unit

Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Battery
- ♦ **Alternator**
- ♦ Fuse
- ♦ Wiring harness

Fault setting condition(s)

- Limit exceeded
- Below limit

Fault effects

- ♦ Function not available or available only to a limited extent