

# All Models , MY 2010 =>

## Diagnosis information - CAN communication

|             |    |
|-------------|----|
| C12002..... | 1  |
| C12003..... | 2  |
| C12004..... | 3  |
| C12005..... | 4  |
| C12006..... | 5  |
| C12007..... | 6  |
| C12008..... | 7  |
| C12009..... | 8  |
| C1200A..... | 9  |
| C1200B..... | 10 |
| C1200C..... | 11 |
| C1200D..... | 12 |
| C1200E..... | 13 |
| C1200F..... | 14 |
| C12010..... | 15 |
| C12011..... | 16 |
| C12012..... | 17 |
| C12013..... | 18 |
| C12014..... | 19 |
| C12015..... | 20 |
| C12016..... | 21 |
| C12017..... | 22 |
| C12018..... | 23 |
| C12019..... | 24 |
| C1201A..... | 25 |
| C1201B..... | 26 |
| C1201C..... | 27 |
| C1201D..... | 28 |
| C1201E..... | 29 |
| C1201F..... | 30 |
| C12020..... | 31 |
| C12021..... | 32 |
| C12022..... | 33 |
| C12023..... | 34 |
| C12024..... | 35 |
| C12025..... | 36 |
| C12026..... | 37 |
| C12027..... | 38 |
| C12028..... | 39 |

|             |    |
|-------------|----|
| C12029..... | 40 |
| C12030..... | 41 |
| C12031..... | 42 |
| C12032..... | 43 |
| C12033..... | 44 |
| C12034..... | 45 |
| C12035..... | 46 |
| C12036..... | 47 |
| C12037..... | 48 |
| C12038..... | 49 |
| C12039..... | 50 |
| C1203A..... | 51 |
| C1203B..... | 52 |
| C1203C..... | 53 |
| C1203D..... | 54 |
| C1203E..... | 55 |
| C12081..... | 56 |
| C12082..... | 57 |
| C12083..... | 58 |
| C12084..... | 59 |
| C12085..... | 60 |
| C12086..... | 61 |
| C12087..... | 62 |
| C12088..... | 63 |
| C12089..... | 64 |
| C1208A..... | 65 |
| C1208B..... | 66 |
| C1208C..... | 67 |
| C1208D..... | 68 |
| C1208E..... | 69 |
| C1208F..... | 70 |
| C12090..... | 71 |
| C12091..... | 72 |
| C12092..... | 73 |
| C12093..... | 74 |
| C12094..... | 75 |
| C12095..... | 76 |
| C12096..... | 77 |
| C12097..... | 78 |

|             |     |
|-------------|-----|
| C12098..... | 79  |
| C12099..... | 80  |
| C1209A..... | 81  |
| C1209B..... | 82  |
| C1209C..... | 83  |
| C1209D..... | 84  |
| C1209E..... | 85  |
| C1209F..... | 86  |
| C120A0..... | 87  |
| C120A1..... | 88  |
| C120A2..... | 89  |
| C120A3..... | 90  |
| C120A4..... | 91  |
| C120A5..... | 92  |
| C120A6..... | 93  |
| C120A7..... | 94  |
| C120A8..... | 95  |
| C120A9..... | 96  |
| C120AA..... | 97  |
| C120AB..... | 98  |
| C120AC..... | 99  |
| C120AD..... | 100 |
| C120AE..... | 101 |
| C120AF..... | 102 |
| C120B0..... | 103 |
| C120B1..... | 104 |
| C120B2..... | 105 |
| C120B3..... | 106 |
| C120B4..... | 107 |
| C120B5..... | 108 |
| C120B6..... | 109 |
| C12207..... | 110 |
| C20000..... | 111 |
| C20001..... | 112 |
| C20002..... | 113 |
| C20003..... | 114 |
| C20004..... | 115 |

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ◆ The power supply for the designated control unit is not present or is present only to a limited extent.
- ◆ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ◆ Control unit faulty

### Fault effects

- ◆ Cross-vehicle functions are not available
- ◆ Existing substitute/emergency functions of the control units are active
- ◆ Functions in the control units are available only with restrictions
- ◆ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

# C1201E

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

## Diagnostic information - valid for all control units

### Communication with control unit

#### **INFORMATION**

Communication with the control unit designated in the fault text is/was not possible.

### Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

### Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available