

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

C12081

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

C1208E

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

C1208F

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ♦ Fault in the designated control unit
- ♦ Note in the designated control unit

Fault effects

- ♦ Functions in the control unit are available only with restrictions
- ♦ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ♦ Fault in the designated control unit
- ♦ Note in the designated control unit

Fault effects

- ♦ Functions in the control unit are available only with restrictions
- ♦ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available