AZTEEG X5 MINI V1.1
4-AXIS MOTION CONTROLLER
WIRING DIAGRAM

www.panucatt.com



Micro-stepping jumper settings

	1	1/2	1/4	1/8	1/16	1/32	1/32
M0	OFF	ON	OFF	ON	OFF	ON	ON
M1	OFF	OFF	ON	ON	OFF	OFF	ON
M2	OFF	OFF	OFF	OFF	ON	ON	ON

Hardware: V1,1
Document: V1.0

NOTES:

* NEW OR CHANGED FROM v1

PANUCATT DEVICES
METERS | CONTROLLERS | SENSORS

AZTEEG X5 MINI V1.1
4-AXIS MOTION CONTROLLER
WIRING DIAGRAM

www.panucatt.com

BOTTOM VIEW



* **Stepper Decay Setting**

OPEN - MIXED DECAY(DEFAULT)
SHORTED - FAST DECAY

J9 - EXTRUDER
J8 - Z (GAMMA)
J7 - Y (BETA)
J6 - X (ALPHA)



Hardware: V1,1
Document: V1.0

NOTES:

* NEW OR CHANGED FROM v1

PANUCATT DEVICES
METERS | CONTROLLERS | SENSORS